

Part Number	Alternate Part Number	Condition	Quantity	Part Description
382		NS	8	LAMP
415	MODEL415	SV	2	DB SYSTEMS AMP, AUDIO CTL
904	SFENA	OH	1	INDICATOR, HORI
1172	11729LW	SV	1	NAV IND
1550		NS	1	SWITCH
1638		NS	1	ANNUNCIATOR HOIST
2342		SV	4	SWITCH
2772		NS	31	GROMMET
2790		SV	2	GPS, GPS/LESS HANDHELD
2793		SV	2	GPS/4DG WITH GPS
2820		SV	8	PRESSURE SWITCH
3841		NE	8	HEATING CARTRIDGE ASSY
3841		SV	1	HEATING CARTRIDGE ASSY
5039	6615-99-712-8802	OH	4	VERTICAL GYRO
5039	NDNS039	OH	4	VERTICAL GYRO
5420		SV	1	LABEM UNIT
6920	63405	SV	1	SOLENOID VALVE
7030		SV	1	VSI
8047		OH	1	ALTIMETER
8047		OH	1	ALTIMETER
8695		SV	1	TEMP POTENTIOMETER
9560		OH	1	TURN AND BANK
10401		SV	1	ANTENNA
10706		SV	2	ANTENNA, GPS, UNS-1D
12800		OH	1	FIRE EXTINGUISHER
15625		SV	1	TRIP & DATE ENCODER
16101		AR	1	AREA MIC
16305		AR	1	STATIC W/CX
24918		AR	1	FUEL PUMP POWER DRIVEN
026953	S0085-101	SV	2	FAN
30510		SV	1	STATIC DEFECT CORRECTION MOD
31483		OH	1	ADF INDICATOR
32734		SV	1	FUEL FLOW IND
033203	BC407/332	OH	1	AMETEK ROTRON INVERTER
37100		SV	1	VHF GUARD RX
37462		SV	2	V-H-F ANT-FEED UNIT
38194		SV	1	VHF HOMER IND-
45900		OH	1	LIGHT BEACON
48165	1560-055-1616	NE	2	REELS SHOULDER HARNESS
2033-1-1		SV	1	RF/IR REMOTE CONTROLLER
56108		SV	1	RMI
61148.100		SV	1	ELECTRONIC UNIT
66501		SV	1	VDO INDICATOR
71428		SV	1	BRAKE MANIFOLD
76803		NE	3	CONTROL HANDLE
76955		SV	2	SARBE BEACON
78340		SV	1	SARBE BEACON
83021		NE	10	MICROPHONE COCKPIT RCNDR
81835	81835AOIA	SV	1	RACAL SATFONE FAX
90073	CMA-1100	NS	1	I/O CABLE ASSY
97167	704A44820006	OH	1	RELAY, BREAKING CURCUIT
99400	SAC69	SV	1	AUTO ANT TUNER
99897	SCU10	SV	1	HF CONTROL
99912		AR	2	TRANCEIVER
100140		SV	1	D1000 MODEM UNIT
100160		SV	1	CONTROL HEAD
102138		OH	1	FREE AIR TEMP IND
105145		AR	2	SPEAKER
106183		SV	1	TRANSFORMER
111302		OH	1	H-S-I
115412		OH	1	CARB AIR TEMP IND
118600	214-075-231-7	OH	3	INDICATOR, COURSE SELECTOR
125780		OH	1	GYRO INDICATOR
125810		OH	1	GYRO INDICATOR
129222	222-375-041-1	SV	2	H-S-I
129920		OH	1	ATTITUDE INDICATOR
132890		OH	1	HORIZONTAL SITUATION INDICATOR
132640		OH	2	H-S-I
137783	5998-00-337-5820	SV	1	CIRCUIT CARD ASSEMBLY
137896	5998-00-337-5821	SV	1	CIRCUIT CARD ASSEMBLY
137902	5998-00-339-6967	SV	1	DECODER CIRCUIT A5
137908	5998-00-339-6969	SV	1	CIRCUIT CARD ASSEMBLY
137914	5998-00-337-5822	SV	1	CIRCUIT CARD ASSEMBLY
137944	5998-00-337-5832	SV	1	CIRCUIT CARD ASSEMBLY
138614	5998-00-337-5928	SV	2	BUILT IN TEST CIRCUIT CARD

138644	5998-00-337-6018	SV	1	CIRCUIT CARD ASSEMBLY
139658	5998-00-339-7006	SV	1	CIRCUIT CARD ASSEMBLY
139837	5998-00-335-7385	SV	1	CIRCUIT CARD ASSEMBLY
143224	MS28004-1	OH	1	INDICATOR TEMP
150615	5998-00-558-5864	SV	1	CIRCUIT CARD ASSEMBLY
150630	5998-00-558-5865	SV	1	CIRCUIT CARD ASSEMBLY
150638	5998-00-558-5851	SV	1	CIRCUIT CARD ASSEMBLY
160154		NE	1	LOCK DOOR
176188		SV	3	ACTUATOR, LINEAR
180806		SV	1	AMP ASSY
196716	5826-00-952-3709	OH	1	ID-1103A/RN INDICATOR
213565	213723	SV	1	ENGINE SYNC UNIT
213778	213787	SV	1	ENGINE SYNC UNIT
215544	213723	SV	1	ENGINE SYNC UNIT
260128		OH	1	WINCH LOAD INDICATOR
271927	271927	NS	17	IGNITERS
280701		NE	1	50 WATT LAMP
306023		NE	1	GASKET
310102		NS	1	SWX INSERT
310140		NS	1	BUTTON
311601		NE	100	CABLE
320562		NS	100	SPLUCE
400331	704A49430068	SV	1	IHM RS422/485 JVN
407240		SV	1	CONTROL UNIT, SIGNAL DEICING
416159		NE	1	CELL EXTRACTION TOOL
3040-05-02		SV	2	COCKPIT DISPLAY COMPUTER
3040-06-02		SV	1	APPLICATION SERVER UNIT
450004		SV	2	REMOTE
7-3133		SV	1	ACTUATOR, ROTARY
508534	1159SCAV381-3	SV	3	FAN MODULE
508617		SV	3	FAN MODULE
521645		NE	3	INDICATOR
521645		OH	1	INDICATOR
522246		SV	1	POWER SUPPLY
536834	A141936	NE	2	SLEEVE
3402-1-1		SV	1	VIDEO RECORDER MULTI SYSTEM
550986		NE	1	RAD ANGULAR BALL BEARING
610000	1666955	SV	1	7" BLOWER ASSEMBLY DC BRUSHLESS
616042		NS	1	CONNECTOR INSERT
618050		NS	14	CONTACT
656520		SV	3	FLUX VALVE
707395		NE	1	BURIN
707718	222-375-012-101	SV	1	DIMMER POWER SUPPLY
710104		OH	1	MOTOR
725222		SV	1	HOMING UNIT, VHF
728221		SV	1	RECEIVER VHF/AM
744619		NE	1	CONNECTOR
749823	704A47653101	SV	1	UNIT, FUEL INDICATORS
764591	7050C4284022	SV	1	GAGE, LOWER FUEL TANK
782013		NE	1	WHEEL WITH COMPONENT
800567		NE	1	STATIC SHIELDING
843772	76550-01001-103	SV	1	MASTER CAUTION/ADVISORY PANEL
902205		SV	1	CABIN DISTRIBUTION BUS RPT
912000		SV	4	AIRSHOW VIDEO SWITCH
912001		NE	1	AIRSHOW VIDEO SWITCH
914026		SV	1	AIRSHOW MOUNT
938012		SV	1	LAB TOP CABLE
962600		NE	1	ICG KIT
962601		NE	2	ICG KIT
1007783	3009514	SV	1	ANTENNA CONTROL UNIT
1122505		SV	1	TEMP PROBE
1242346		NS	1	GASKET
6001-1-1		SV	1	DISPLAY SWITCHING UNIT
1510113		NE	1	EXTERIOR MIRROR
6123-1-1		SV	4	COMM CTL
1741394		NE	1	BRACKET ASSY
1775143		SV	2	POWER SUPPLY
1775277		SV	4	FLUX VALVE
7-8159		NS	1	RECEIVER DRIVER
7-8159		SV	1	RECEIVER DRIVER
2583379		OH	1	DUAL REMOTE COMPENSATOR
3022375		NS	2	SEAL
3039305		NE	1	SENSOR
3039310		SV	1	LOW FUEL PRESSURE SWITCH
3043013		OH	1	BLEED VALVE
3066671		NE	1	RESISTOR

3071434		AR	1	CHP DETECTOR
3073728		NS	1	TUBE
3201104		SV	2	JUNCTION BOX
3202311		NE	1	FLUR KIT
3202315		NE	1	FLUR KIT
3205495	3205495K	NE	2	FLUR KIT
3205581		NE	2	FLUR CONNECTOR KIT
3322412	5340-01-179-3507	NS	10	BUMPER
3322577	5845-01-178-9418	NS	10	COVER
3322599	5315-01-102-0448	NS	10	PIN
3329802		NS	30	CAP
3329806		NS	20	GASKET
4002001	8330-01-179-1455	SV	1	APOSVC-032-01
4002001		OH	1	APOSVC-032-01
4012568		FN	1	BRUSH ASSY
4016636		NS	1	LENS
4103052		NE	1	RECEIVER DRYER
4171072	704A46820007	OH	1	LANDING LIGHT
4202104		OH	5	LIGHT, LANDING
4217212	704A46820022	SV	1	LIGHT RETRACTABLE
4217228		OH	4	LANDING LIGHT
4361646	L334M3820101A003	SV	1	LANDING LIGHT
5006052	6150-01-103-1066	NE	3	CABLE ASSY
6004137		SV	1	BRAKE TEMP MONITOR IND
6020277		NE	1	LOCKING BARREL CATCH
6815120		SV	1	PHASE DETECTOR TORQUEMETER
6896482		NS	1	PLUG
7001483	412-001-304-101	OH	1	ACTUATOR ASSY
7024317		NS	1	SCREW CAP
7513260		NE	1	FILTER
7583740		NE	1	FILTER ELEMENT
7672892		NE	1	FILTER ELEMENT
8002826		NS	50	HLDR
8002827	5365-01-280-9564	NS	2	HSG
8011899	5365-01-358-1238	NS	5	RETAINER DISC
8014053	5365-01-336-0136	NS	20	RETAINER
8014054	5365-01-371-5993	NS	20	RETAINER
8014055	5365-01-335-4173	NS	20	STRAP
8015238		SV	3	TDL-711 RCU
8032705		SV	1	ALLIED SIGNAL TEST BOX
9535061		NS	4	SEAL
9543973		NS	6	PLATE
9550904		OH	1	MLG BRAKE
30300014	IFR-485-05-1	SV	1	AUDIO INTL
30300038	BBK-2AH	SV	1	AUDIO MODULE
30300051	VA-400-1	SV	1	AUDIO INTL PANEL
30300078	AI-PS13-5-3	SV	1	AUDIO INTL MODULE
30300257	AI-PS12-3	SV	1	POWER SUPPLY
30300542	AI-VIC-202-1	SV	3	AUDIO INTL PANEL
30500007	MDC-102-CH-1	SV	1	MULTI CD CHANGER
30500042	MCD-104-01-1	SV	1	CD PLAYER
30803829		SV	1	CONTROL PANEL
42623001		SV	2	CO2 CYLINDER
73844911		SV	1	UNIT CONTROL
75003298	64869-75003298	NE	1	LASER INTERLOCK REV B
83303139		NE	1	CONNECTOR
91000132		SV	1	NAV DATA LOADER
93400012		NE	1	TNLS61 PLUS SYNCRO
164548610		SV	3	FUEL CONTROL UNIT
174128150		AR	1	BLEED VALVE
177555120	6790623827	AR	1	OVERSPEED UNIT
0177987120		NE	2	CARD ASSY
292687250	0292687250	NE	2	VALVE ASSY
319307840		SV	1	IGNITION INJECTOR
319738330		SV	4	HALF MANIFOLD, RIGHT INJECTOR
319739400		SV	1	RIGHT HALF FUEL MANIFOLD
319739560		AR	1	HALF MANIFOLD ASSY
0319850750		SV	1	VALVE PUMP AND METERING ASSY
390242411		NE	1	WISCHERMOTOR
401287200		SV	1	REAR PLATE
616785024		NS	20	RADIALL CONN INSERT
619051001		NS	10	COAXIAL CONTACT
619054001		NS	4	COAXIAL CONTACT
620022001		NS	5	RADIALL CONN INSERT
620075011		NS	7	COAXIAL CONTACT
639493002		NE	2	DRAIN OIL

750133040		NE	1	FREEWHEEL UNIT
4107201222		NE	5	02 REPAIR KIT - BEACON MEDAS
4619002005		SV	1	INTERMEDIATE GEAR
4619002005		AR	3	INTERMEDIATE GEARBOX
4619003003		SV	3	TAIL ROTOR TRANSMISSION
4619003003		SV	3	TAIL ROTOR GEARBOX
4619003005		SV	1	TAIL ROTOR TRANSMISSION
4619003005		NE	1	TAIL ROTOR GEARBOX
4619003005		AR	1	TAIL ROTOR GEARBOX
4619208044		NE	2	DRAIN HOSE
4619303081		NE	1	ROLLER BEARING
4619310070		NE	1	ROLLER BEARING
4619310072		NE	3	ROLLER BEARING
4619311033		NE	2	ROLLER BEARING
4638202007		NE	3	FREEWHEEL-CLUTCH
4638302013		SV	1	FREEWHEEL UNIT SHAFT
4638302093		NE	6	FREEWHEEL WAVE
4639001006		SV	1	MAIN TRANSMISSION
4639002001		AR	1	TAIL ROTOR GEARBOX
4639002001		OH	1	TAIL ROTOR GEARBOX
4639002005		OH	1	TAIL ROTOR GEARBOX
4639003001		NE	1	TAIL ROTOR GEARBOX
4639003007		OH	2	TAIL ROTOR TRANSMISSION
4639205007		NE	1	SPACER TUBE
4639215004		NE	1	HARNES
4639302052		NE	1	FREEWHEEL SHAFT
4639310005		NE	5	BEARING
4639310039		NE	1	OIL SIGHT GLASS
4648208024		NE	1	OIL PUMP
6700518000		SV	1	INDICATOR, PRESSURE MB
6720004203		SV	2	ELECTROVALVE
6787300603		SV	1	VOLTAGE REGULATOR
6790623827		SV	1	OVERSPEED UNIT
8527400997		NE	1	OIL FILTER
8818457000		NE	1	POCKET ORESSURE GAUDE ASSY
8819329000		NE	1	ENGINE FRAME
9550164740	3162-600	SV	2	BLEED VALVE
9550166110		NE	1	OIL PRESSURE SWITCH
9550166160		SV	1	IGNITER BOX
9550171420		SV	1	TRANSMITTER P3
9550172970		NE	1	SPEED SENSOR (N1,N2) 1 NT
9560150490		SV	1	CLOGGING INDICATOR
9560170580		NE	1	MAGNETIC SEAL
9560178640		NE	1	HYDRODYNAMIC MAGNETIC SEAL
9580111170		SV	1	CLOGGING INDICATOR
9580114120		SV	1	ELECTRO VALVE
9580115210		NE	1	GENERATOR 1 NT
01302028010	7050A4331006	SV	1	POWER SUPPLY BLOCK
25900010010	704A46814115	SV	1	LIGHT PANEL
35093370700		SV	1	TOOL
70393000001		SV	1	WRENCH, SOCKET
526800163610		NS	3	SEAT BELT
864441835040		NE	1	RUBBER SEAL
56880016360012		NS	2	SEAT BELT
149E30	MS28006-1	SV	1	INDICATOR, TEMP
1945E245		SV	1	ROD END
00-200-1050		NS	1	FILTER
005002-501	FERNO-12-2-ALL6G	NS	2	STRETCHER
0100-002		SV	1	RECEPTICLE
010-00176-01		NS	3	GPS 500 black receiver w/rack
010-00286-01	GNS430A	NE	1	GNS430A NVG MOD.
010-01217-01		FN	1	GTX-345R ADS-B In/OUT Transponder
010-10201-06		NE	2	DATACARD
01-0770028-05		AR	3	POWER SUPPLY
01-0770062-03		AR	2	POWER STROBE
01-0770285		SV	1	STROBE LIGHT
01-0770948-01		SV	1	LIGHT STROBE GRN LED
011-00412-00	GPS155XL	SV	1	GPS
011-00582-00	GTX330	NE	1	BACKPLATE ASSY
011-00676-00	GNS430	NE	5	BACKPLATE ASSY
011-00676-01	GNS430	NE	1	BACKPLATE ASSY
011-00677-01		NE	2	BACKPLATE ASSY
011-00678-00		NE	1	BACKPLATE ASSY
011-00779-10	GTX33	SV	1	TRANSPONDER
011-00836-00		SV	1	GNS430A GPS/COMM/NAV
011-00870-00		AR	1	MAGNETOMETER

011-00882-00		OH	1	GDU74A ADC
011-00979-03		NE	1	CONFR MODULE
011-02278-01		SV	1	ARHS
011-02977-00	GTX335	NE	1	CONNECTOR KIT
011-03301-00	GTX335R	AR	1	TRANSPONDER
011-04340-02	GTX345	SV	1	BACK PLATE W/ SCREWS
013-00049-11	GI-106A	SV	1	INDICATOR W COURSE DATUM
0130-2002-0010	1552644	SV	1	UNIT POWER SUPPLY
013-1885-010		SV	2	ANTENNA
0132NE		NE	1	OAT-SENSOR
017500-11	SX-16	SV	1	SEARCHLIGHT ASSY
01-768230		NS	1	GALLEY SWITCH
018-1394-010		NE	2	SHIELDING GASKET
01-P24481F001	PTRA-200	SV	1	MOTOROLA CONTROL PANEL
01R43129D02		SV	1	MOTOROLA CONTROL PANEL
0201992-001		OH	1	SEARCHLIGHT ASSY
0202644-005		SV	1	LANDING LIGHT AW139
02-0350034-00	A506	NE	2	STROBE BEACON
0204-0001		OH	1	HYDRAULIC RESERVOIR
0204-001		SV	1	HYDRO RESERVOIR
020-969-018	11595CP460-18	SV	1	TANK UNIT FUEL QTY
02-1104-0006		NE	2	CABLE
02289-5600-S938		SV	1	RELAY, TIME DELAY
022TA1101	704A47723068	SV	1	FAILURE WARNING PANEL
0230191-001		SV	1	SEARCH LIGHT
0231102-004		SV	1	SEARCH LIGHT
023-138-842		NE	1	DTRESSCOVER MANGAN
024711-41	SX5	SV	1	SEARCHLIGHT ASSY
024711-41	030040	SV	1	SEARCHLIGHT W CIMBAL ASSY
024918-107		AR	1	PUMP ROTARY POWER DRIVEN
025234-11	SX5	SV	1	JUNCTION BOX ASSY
025323-150		AR	1	FUEL PUMP
02W0101633		SV	1	FILTER
030-01184-0011		NS	3	PIN
030-02070-0005		NS	3	CONNECTOR
030-02250-0000		NS	1	CONNECTOR
030-02350-0062		NS	1	CONNECTOR
030-02351-0004		NS	1	HOOD/LVR-ASSY
0300-402		SV	1	ROSEN PANEL
03024473-0002		NS	1	CONNECTOR KIT
03024473-0003		NS	1	CONNECTOR KIT
030-600-002		SV	1	PLINTH
030611-15-72	W8-2P2	NS	1	NIGHTSUN CABLE
030752-34-25		AR	1	CABLE ASSY SX-5
031-00785-0505		NS	3	ANNUNCIATOR
03-1100-0002		NE	1	LAMP
03-12-1062		NS	20	CONNECTOR
033002-1		SV	1	PENDANT, NIGHTSUN XP
038-220-2800-H	MSA00552323PSMOHGAS	SV	6	ACCORDIA WINDOW SHADE
038-220-3100-A	MSA00552323	SV	6	ACCORDIA WINDOW SHADE
03-9002-0004		NE	5	LED POSITION LIGHT GREEN
03G105		NS	2	LOCK WASHER
04-1120-0028		AR	2	POWER SUPPLY
04-327W001	04-327F001	SV	1	EGPWS RELAY/FUSE BOX
047-06054-0001		NS	1	SPACER
047-07531-0000	047-7531-00	NS	1	TRAY
0476-A-00364	AMT50	SV	1	LNA/DIPLEXER
0476-F-00364	AS100500-01-180	SV	1	LNA/DIPLEXER
050-01854-0000	KI229	NE	1	INSTALL KIT
050-01855-0001	KTU709	NE	1	INSTALL KIT
050-01864-0002	KTS156	NE	1	INSTALL KIT
050-02121-0001	KTR993	NE	1	INSTALL KIT KTR993 CRIMP
050-02251-0000	KA676/KA678	NE	1	INSTALL KIT
050-03044-0001	KA90	NE	1	INSTALL KIT
050-03392-0000		NS	1	INSTALL KIT (26)
0501002A	DEFT-1	SV	1	ELT
050-100-0248		SV	1	UNIT_PDR60 WARNING
0501-786-054		NS	3	INSTALL KIT
050-3111-00	KA670	NS	1	KA670
0511-781-954		NS	6	INSTALL KIT
0514-901-954		NS	3	INSTALL KIT
052-00009-0004		NS	4	SHOCKMOUNT
0520-110-1085		NE	1	SEAT 180/260
0520-5148-102		NE	1	CUSHION
055-1800-001		SV	2	TRANSMITTER
057-0719-002		NS	4	BACKSHELL

060-0013-01	KSG105	OH	2	DIRECTIONAL GYRO
060-0015-00	KG-102A	SV	1	DIRECTIONAL GYRO
06076-90G001-01		NE	4	RAD ALT INSTALL KITS
062-0004-00	KU193	SV	1	COMM
064-01047-0001		NE	2	RECEIVER
064-01083-0101	ITU-100	SV	1	AIRSAT 1 TRANSCIEVER
064-1009-00	KTR905	AR	2	COMM TRANSCIEVER
064-1023-00	KTR908	SV	2	COMM TRANSCIEVER
064-1029-00	KAC992	SV	1	HF PROBE COUPLER
064-1047-01	3614001-4002	NE	2	RECEIVER
064-1047-12	064-01047-0012	SV	1	VHF TRANSCIEVER
065-00663-0006		FN	4	Annunciator Panel Bil.
065-00157-0200	KLAS70	OH	1	SERVO ACTUATOR
065-00157-0300	KLAS70	OH	1	SERVO ACTUATOR
065-00157-0400	KLAS70	OH	1	SERVO ACTUATOR
065-00158-0102	KCP920	SV	2	FLIGHT COMPUTER
065-00158-0202	KCP920	SV	1	FLIGHT COMPUTER
065-00159-0402	KMS-540	SV	2	MODE SELECT PANEL
065-00162-0100	KSA572	SV	1	SERVO ACTUATOR
065-00162-0200	KSA572	SV	1	SERVO ACTUATOR
065-00165-0100	KSM575	OH	1	PITCH ACTUATOR ASSY
065-00165-0200	KSM575	OH	1	ROLL ACTUATOR ASSY
065-00165-0300	KSM575	SV	1	ACTUATOR ASSY YAW
065-00167-0200	KSM575	OH	1	YAW ACTUATOR ASSY
065-00167-0800	KSM575	NE	3	ROLL LINEAR ACTUATOR
065-00167-0900	KSM575	NE	3	PITCH LINEAR ACTUATOR
065-0064-08	KCP220	SV	1	FLIGHT COMPUTER
065-0082-12	KDC481T	SV	1	AIR DATA COMPUTER
066-0000-006	SCORPK02000	SV	2	CALEDONIAN AIR TX UNIT
066-0000-702	SCORPK02000	SV	1	TEST RCVR 470-5 MHZ
066-0000-707	SCORPK02000	SV	1	TEST HAND CONTROL
066-01066-0002	066-1066-02	SV	1	KING KDM 706
066-01069-0002		SV	1	KDI 573
066-01078-0004	KT71	SV	1	RECEIVER (KNR634)
066-01141-5101	KT71	SV	1	TRANSPONDER
066-01143-0201	MST67A	SV	1	MODE S TRANSPONDER
066-01143-0601	MST67A	SV	1	TRANSPONDER
066-01153-0101	KRA405B	OH	1	RADIO ALTIMETER RCVR
066-01153-2001	KRA405B	SV	1	RADIO ALTIMETER RT
066-01153-4001	KRA405B	OH	1	RADIO ALTIMETER RT
066-01171-2304	IVAB1D	SV	1	TCAS DISPLAY
066-01198-0102		FN	4	KXP-2290A Mode "S" Diversity Transponder
066-01201-0105		FN	4	GPS Receiver (WAAS)
066-03031-0004	066-3031-04	NE	1	KNI 415 RAD ALT INF NVG
066-03044-0000	KN416	NE	1	RAD ALT INDICATOR
066-03046-0013	066-3046-13	NE	1	KIS25A H.S.I. NVG
066-03062-0008	066-3062-08	OH	1	KEA346 ENCODING ALTMETER
066-03062-0009	066-3062-09	OH	1	KEA346 ENCODING ALTMETER
066-03062-0010	066-3062-10	OH	1	KEA346 ENCODING ALTMETER
066-03062-0011	066-3062-11	OH	1	KEA346 ENCODING ALTMETER
066-03123-1500	ED-461	AR	1	ERF INDICATOR
066-03123-1600		SV	1	EHSI
066-03125-2600	ED462	NE	3	DISPLAY
066-03125-2600		SV	1	EHSI/EADI
066-1024-03		AR	1	AUDIO CONTROL
066-1045-00	KDD693	SV	1	DME RANGE CONVERTER
066-1061-03	KRA10A	SV	1	RAD ALT RCVR
066-1061-03	KRA10A	AR	2	RAD ALT RCVR
066-1069-00	KDIS72	SV	1	DME IND
066-1071-00	KXP756	AR	1	TRANSPONDER
066-1072-00	KR87	AR	3	ADF RCVR
066-1091-04	KDIS73B	SV	2	NAV INDICATOR
066-1101-00	3614004-4101	SV	1	NAV RCVR
066-1105-00	DF431B	SV	1	ADF RCVR
066-1107-01	DM441B	SV	1	DM-441B DME TRANSCIEVER
066-3024-09	KPI552	OH	1	PICTORIAL NAV IND
066-3024-17	KPI552	OH	1	PICTORIAL NAV IND
066-3024-40	KPI552	SV	1	PICTORIAL NAV INDICATOR
066-3027-14	KPI553	OH	1	PICTORIAL NAV IND
066-3032-10	KDIS71	AR	1	INDICATOR
066-3034-02	KI204	SV	1	VOR LOC GS IND
066-3034-24	KI206	SV	1	IND
066-3044-01	KN416	OH	1	RAD ALT IND KNI 416
066-3045-14	KPI553A	OH	1	PICTORIAL NAV INDICATOR
066-3048-07	KIS25A	SV	1	H.S.I. INDICATOR
066-3054-01	KI-250	SV	1	RAD ALT INDICATOR

066-3054-01	KI250	AR	1	RAD ALT INDICATOR
066-3054-01	KI250	SV	1	RAD ALT INDICATOR
066-3056-00	KI208	AR	1	VOR/LOC/GS INDICATOR
066-3060-00	066-03060-0000	OH	1	RM1 INDICATOR
066-3063-01	KI227	SV	1	ADF IND
066-3069-09	KPI553B	OH	2	PICTORIAL NAV IND
066-3077-25	KAV485	OH	1	ALT/VIS IND
066-3096-00	IU-2023B	SV	1	REMOTE COMP UNIT
066-4004-00	KN77	SV	1	VOR/LOC CONVERTER
066-4006-01	KNR865	SV	1	NAV RCVR
066-4007-02	KNR832	SV	1	NAV RCVR
066-4009-00		SV	1	NAV CONVERTER
069-01027-0102		FN	4	KTR-2280 MULTI-MODE DIGITAL RADIO
069-1026-01		SV	1	KX99 RECEIVER
070-0900-001		SV	3	CPT900 ADELTA BEACON-
071-0006-00		SV	1	DME CODE CONVERTER
071-00158-0211	KACS02	AR	3	EGPWS MODULE
071-00166-0411	KACS04	SV	1	TRAFFIC MODULE
071-00168-0311	KACS04	SV	1	TRAFFIC MODULE
071-0025-00	CA308	SV	1	TDR94A TEST SET/MODULE
071-0031-00	KDL569R	SV	1	TEST BOX
071-01283-0012	071-1283-12	SV	1	CONTROL UNIT
071-01283-0012	071-1283-12	NE	1	CONTROL UNIT(KFS564A)
071-01315-0000		OH	1	RS181A Radar R/T Unit
071-01505-0203	GC-362A	SV	1	GRAPHICS ADAPTER
071-01507-5202		FN	1	KFS-578A TCAS CONTROL HEAD
071-01508-0201	KA90	AR	1	H-S-I APAPTER
071-01511-0101	CP469A	AR	1	CONTROL PANEL
071-01542-0401	CD671C	NE	7	TCAS-B DUAL BLK
071-01545-0100	KA91	SV	1	GPS ANTENNA
071-01546-0101	KFS599A	SV	1	UHF COMMUNICATION CONTROL
071-01596-0201		FN	4	Primary Flight Display (PFD) Controller
071-01598-0901		FN	2	Multi-Function Display (MFD)
071-01618-0105		SV	1	PS-578A Control Panel
071-01619-0022		SV	1	PS-550 Control head
071-04025-0001	071-4025-01	NE	6	MTG RACK w/ SHOCKMOUNTS
071-04030-0001	071-4030-01	NS	7	MTG RACK
071-04051-0000	071-4051-00	NE	1	NC104B MOUNTING TRAY
071-04054-0000		SV	1	MOUNTING TRAY
071-1033-00	KFS580	SV	2	CONTROL ADF
071-1034-00	KA36	SV	1	ANTENNA
071-1052-00		AR	1	FLUX VALVE
071-1059-00	DMPN3-3A	AR	1	KA54 ANT-
071-1066-00		SV	1	ADF CTL
071-1073-00		SV	1	SUPER FLAG ADAPTER
071-1148-00		SV	1	MATCHING ASSY
071-1215-70	KFS598	AR	3	COMM CONTROL
071-1216-12	KFS564	AR	1	NAV CONTROL
071-1242-01	KA51B	SV	2	SLAVING ACCY
071-1242-06		AR	1	SLAVING ACCY
071-1271-00	KA161	AR	1	EXTERNAL CAPACITOR
071-1272-00		NE	1	KAC992 WHIP ANTENNA
071-1274-01	KFS594	SV	2	HF CONTROL UNIT
071-1279-01	KA68A	NS	2	PROGRAMMER
071-1313-31		SV	1	GC-360A Radar Graphics Unit
071-1316-00	3614165-5510	SV	1	10IN ANTENNA ARRAY
071-1316-00	3614165-5510	SV	1	10IN ANTENNA ARRAY
071-1335-00	CP103D	SV	1	CONTROL
071-1377-01	8095444-4102	SV	4	NAV CONTROL CD413B
071-1446-00	8095635-1001	SV	1	EFIS CONTROL PANEL
071-1523-03	071-01523-0003	SV	1	KLN908 DATA BASE
071-2007-00	KAA455	SV	2	AUDIO CONTROL SYSTEM
071-22000-01		SV	1	ANNUNCIATOR ASSY
071-4002-00		SV	1	MOUNTING TRAY
071-4004-00		SV	1	MOUNTING TRAY
071-4022-01		SV	1	MOUNTING TRAY
071-4025-01		SV	1	KG102A MOUNT
07148.11126.2	214-075-186-1	SV	1	CONTROL UNIT TEMP
073-00044-0001		SV	1	PLATE
073-00045-0000		SV	1	PLATE
073-00866-0002		NS	2	KNOB
075-1800-005A		SV	1	HEADSET
0811-A-0001	AMT-50	SV	1	ANTENNA CONTROL UNIT
0851GE		SV	1	PILOT TUBE
0871GA1		NE	1	ICE DETECTOR
089-06159-0003		NS	6	SCREW

089-06200-0002		NS	10	SCREW
089-06592-0003		NS	4	SCREW
08GSW		NS	3	BEARING
090-00499-0003		NS	1	RING
090-00540-999		SV	1	SHEPHERD VIGILANT
090-00556-900		SV	1	SHEPHERD VIGILANT
09168P-18		NE	1	MICROPHONE
096-2100-030	SCORPIO2000	SV	2	MICROCONTROLLER MODULE
099-114-101	BHT407	SV	2	MODULE
1000670-1-006	3050087-04	SV	1	CONTROL ELECTRONIC ENGINE
100-0701-01	SECURAPLANE	SV	1	CDU
100-1057-01	SECURAPLANE	NS	1	CAMERA
100-1065-01	SECURAPLANE	SV	1	DVR-01 SECURAPLANE
100-1088-01	SLA3000	SV	1	BATTERY EMERGENCY
1-002-0102-1605	4B3500-3E-NB-CM-1605	SV	1	CONVERTER, FREQUENCY, STATIC
1002-033	USA-2	SV	1	UNIVERSAL SWITCHING UNIT
100-43677		SV	1	SELF SEALING COUPLING
100-43686M4		SV	1	VALVE
100-601260-002		AR	1	GROUNDSPEED DRIFTANGLE INDICATOR
100-601600-504		SV	2	GNSSU CMA-3012 TSO C-129
100-601721-001		AR	1	CMA 3000
10062-1-8		SV	1	TRANSMITTER
10067146-103		NE	1	CIRCUIT BOARD
10-0815-5		SV	1	DOME LIGHT
101001-10	DEI01-10	SV	1	AUDIO SELECTOR PANEL
101-00153	1811FER	SV	1	PILOT STATIC TEST SET
101-00167A0A	1811HADAA	SV	1	PILOT STATIC TEST BOX
1010-1	UNS1	SV	1	CDU
10102-0000		SV	1	ADAPTER PLATE
10-102-3C		SV	1	ANTENNA
10-104-6		SV	1	ANTENNA
10122H	MODEL010012	NS	2	EFIS BLOWER
101-380027-1		AR	1	REG VALVE
101-380031-1	70002-0131	OH	1	TURN AND SLIP INDICATOR
101-380094-3	43-206-1	OH	1	TORQUE INDICATOR
101-389025-3	424-1	SV	1	FUEL SHUTOFF VALVE
101420-11968E	102220-11886	OH	2	ALTIMETER, PRESSURE ALT REP
101435-11263	101435	OH	1	ALTIMETER
1014744-0001		NS	1	PHONE
1015-1-11		SV	2	EFIS / RADAR PANEL
1016-1-110	UNS1	AR	1	CONTROL DISPLAY UNIT
1016-2-21		SV	1	CONTROL DISPLAY UNIT
101635-11839	81408-520-LW5V	OH	1	ENCODING ALTIMETER
101641-6		SV	1	DESICCATOR, PRESSURE EQUAL
101-641-C		SV	1	DESICCATOR
10167N01W00		SV	2	TORQUE INDICATOR
101730-01467		OH	1	ALTIMETER
101735-01455		OH	1	ALTIMETER
1017-41-011		OH	1	CDU, UNS-1C
1018-2-213		FN	1	5" FPCDU Black HI-Resolution
1018-2-610	UNS-1	US	2	CONTROL DISPLAY UNIT
102-0053-02	RCA26AK-1	OH	1	ATTITUDE GYRO
102-0060-02	RCA26BK-9	OH	1	ATTITUDE GYRO
102006-1		SV	1	MODULE
102008-1		SV	1	MODULE
1020-1-3	AIRSHOW	SV	2	COMPACT AUDIO DISTRIBUTOR
102013-1		SV	2	MODULE
102089-22410001		AR	1	HEAD OF PROPELLER
1021-1-1	AIRSHOW	SV	3	VIDEO MODULE
102220-11886		OH	3	ALTIMETER
102264NVG		SV	1	DISPLAY, OXYGEN MINDER
1023-1-1	AIRSHOW	SV	1	AUDIO/VIDEO MODULE
10238-0011		NE	1	CAPACITOR
1025-1-6	AIRSHOW	SV	1	AUDIO/VIDEO MODULE
1029-1-1	AIRSHOW	SV	1	AUDIO MULTIPLEXER
102AJUJK	102	SV	1	SENSOR, TOTAL TEMPERATURE
103-0023-01	RCA15BK-2	OH	1	DIRECTIONAL GYRO
103006-1		SV	1	MODULE
1-030-069-01	5365-00-784-3994	OH	1	SPACER
1030-1-2	AIRSHOW	SV	2	INFRARED INTERPRETOR
10312N01T00	78450-01076-111	OH	1	TURB TEMP IND
10313N01R00	78450-01076-112	OH	2	TRIPLE TACH INDICATOR
1033-1-1	AIRSHOW	SV	1	RF/IR REMOTE INTERPRETER
103-5	27908-1	OH	1	AIRSPPEED
103500-103	7901-01A	SV	1	AUTO DATA ENTRY UNIT
10355N04T00	212-075-067-119	OH	1	ITT INDICATOR



10379-11-01		SV	1	ALTITUDE ALERTER
10406-12600		SV	1	FLUR LCU, LAP TOP CONTROL
10406-66110		SV	1	FLUR, QWP 640X480 PIXEL FPA-
1041-020	9200-0102-430	SV	1	DISPLAY MONITOR
10420-11968E		NE	2	ALTIMETER
104500A9		AR	1	POWER TURBINE GOVERNOR
10-4804-359		NE	1	FLOOD LIGHT PLATE
10-4804-364		NE	7	FLOOD LIGHT PANEL
105-00001		NE	1	TAIL FLOODLIGHT KIT
10-5011A		SV	1	LIGHT ASSY
105-10101W4		NE	1	CENTERING DEVICE
105-101511.07		NE	1	TENSION ROD
105-10158		NE	1	TRANSM. STAND ASSY RH
105-101731		NE	2	STRUT
1051-1-3		SV	4	CABIN MANAGEMENT MODULE
1051-1-6		SV	1	CABIN MANAGEMENT MODULE
105-131035		NE	1	SAFETY LEAVER ASSY
105-13122		NE	1	PITCH LINK ASSY
105-13221		AR	1	DRIVING LINK ASSY
105-13221.08		NE	1	SPACER
105-13241		AR	1	FORK LINK ASSY
105-14101 W1		NE	1	ABZIEHVORRICHTUNG
105-14101.91		NE	1	HEX BOLT
105-14102W1		NE	1	SUPPORT ASSY -M/R HUB
105-141081		SV	1	MAIN ROTOR HEAD
105-141081		AR	5	ROTOR HEAD
105-141091		SV	2	MAIN ROTOR HEAD
105-141091		AR	3	ROTOR HEAD
105-14181.01		SV	8	INNER SLEEVE ASSY
105-14181.03.5		NS	8	BUSHING
105-14181001		NE	1	ASSY FX NEEDLE BEARING
105-14183		NE	3	INNER SLEEVE ASSY
105-15103W2		NE	1	BENDING FIXTURE
105-151091		AR	1	ROTOR HEAD
105-15181-001		NE	1	EROSION PROTEC W.PEEL TEST
105-15853		NE	30	BLADE FITTING ASSY
105-20161-001		NE	1	FRAME9BEH
105-20301.55		NE	1	GUSSET
105-20402		NE	1	LUG ASSY
105-20501.55		NE	1	GUSSET PLATE
105210-0001	AA-506AC	SV	1	AUDIO AMPLIFIER
105-21301		SV	1	NOSE DOOR CONTROL LINKAGE
105-21706		NE	1	MOD ENGINE FLOOR
105-21721.115		NE	1	STIFFENER
105-21801-77		NE	1	ANGLE LH
105-21831-100.26		NE	1	SIDE PLATE LH
105-21841-002		NE	1	REPAIR SHEET FRAME
105-21924		NE	1	CABINROOF F SAND/FILTER MOD
105-22209		NE	1	GLASS PANE UPPER RH
105-231151		NE	1	REAR DOOR SUPPORT
105-23151		NE	1	REAR DOOR SUPPORT LH
105-23401.10		NE	1	LEVER RH
105-23587		NE	1	LINK UPPER
105-30591		SV	1	VERTICAL STABILIZER ASSY
105-30591		NE	1	VERTICAL STABILIZER ASSY
105-31702		AR	2	TAIL ROTOR HEAD
105-31702-20		NS	1	NUT
105-31702W12		NE	1	PUSHING OUT TOOL
105-31711 W1		NE	1	PULLER TAIL ROD PITCH BEARING
105-31711W5	105-31711	SV	1	MOUNTING TOOL
105-31711W5		NE	1	MOUNTING TOOL
105-31714		SV	1	TAIL ROTOR HEAD
105-31729W2		NE	1	MOUNTING SLEEVE
105-31734		AR	8	BLADE MOUNTING FORK ASSY
105-31734W1	105-31734	SV	1	EXTRACTOR
105-31734W2		NE	1	BONDING TOOL
105-317385		NE	1	CONTROL LEVER ASSY BLACK
105-317395		SV	1	TAIL ROTOR HEAD
105-31743W15		NE	2	CONTROL DEVICE
105-31754W7		NE	1	MASTER GAUGE
105-31762		AR	1	SLIDING SLEEVE ASSY
105-31784		NE	1	TAIL ROTOR HEAD
105-31796		NE	8	TAIL ROTOR BLADE PAINTED
105-31802-001		AR	3	REAR ROTOR WAWE
105-31803-01		SV	1	TAIL ROTOR SHAFT
105-31810		NE	16	TAIL ROTOR BLADE

105-40118		NE	1	BELLOWS STICK RH
105-40151		NE	1	LONGITUDINAL CONTROL LINK
105-40213		NE	1	BELLOWS
105-40213		NE	1	BELLOWS
105-41027		NE	1	LATERAL TRIMMER
105-41041		NE	1	TUBE
105-41043		NE	1	HOUSING
105-41045		NE	1	TUBE
105-41081.01.5		NE	1	ADAPTER
1054-1-1	AIRSHOW	SV	4	8 CKT SA AC/DC MODULE
105-411091		NE	1	TRANS-DUCCER
105-41221		NE	1	PITCH SHAFT
105-41227		NE	1	BRAKE BOXQ
105-41230		AR	1	COVER ASSY
105-41235		NE	1	BELLOWS ASSY
105-41237		NE	1	COLLECTIVE PITCH STICK ASSY
105-41238		NE	1	COLLECTIVE PITCH STICK ASSY
105-41247		NE	1	HANDLE
105-414861		NE	1	ACTUATOR/LATERAL ASSY
105-414861		AR	2	ACTUATOR ASSY
105-414891		NE	1	CONTROL ROD ASSY
105-42122W2		NE	1	MOUNTING TOOL
105-42123		NE	1	LAGERBOCK
105-42123W4		NE	1	PUSHING OUT TOOL
105-42124		NE	1	ADJUSTABLE SUPPOT
105-42221.36		NE	1	FITTING
105-42310		SV	3	TORSION BAR ASSY LONGITUDINAL
105-43011		SV	1	BELLCRANK ASSY
105-44001W001		NE	5	KIT
105-450121		SV	1	HYDRAULIC PACK
105-450121		NE	1	HYDRAULIC PACK
105-45021.63		NE	1	ADAPTER
105-45023		SV	1	TANDEM HYDRAULIC UNIT 7VE
105-45023		SV	1	TANDEM HYDRAULIC UNIT 7VE
105-45028		SV	1	TANDEM HYDRAULIC UNIT 7VE
105-45028		AR	1	TANDEM HYDRAULIC UNIT
105-45028W004		SV	1	TANDEM HYDRAULIC UNIT 7VE
105-450391		SV	1	TANDEM HYDRAULIC UNIT
105-45041W19		NE	1	ASSY TOOL
105-45041W30		NE	1	ASSY TOOL
105-45046		NE	2	3-AXIS ACTUATOR
105-45047		OH	1	ACTUATOR
105-45051W3		NE	2	SOCKET WRENCH
105-45054	105-45054B	NE	1	3-AXIS ACTUATOR
105-45055	105-45054	OH	1	ACTUATOR
105-45067	105-45054	OH	1	ACTUATOR
105-45077	105-45054	OH	1	ACTUATOR
105-450811		NE	1	RESERVOIR SYSTEM I
105-450861		NE	1	RESERVOIR SYSTEM II
105-45353		NE	3	PRESSURE TRANSFER VALVE
105-466071	S4-3010180	NE	1	3-AXIS ACTUATOR
105-466071B	S4-3010180	NE	1	3-AXIS ACTUATOR
105-46621B		OH	1	ACTUATOR
105-46631		NE	1	VALVE BODY MANIFOLD
105-46636		OH	1	VALVE BODY MANIFOLD
105-46648.01		NE	1	CONTROL SPOOL
105-46649	105-46649B	OH	1	VALVE BODY MANIFOLD
105-46661011	105-45054	OH	1	VALVE BODY MANIFOLD
105-46668		NE	18	CONE BYPASS
105-46671.01		NE	1	SPACER SLEEVE
105-46683		NE	5	SERVO - VALVE I
105-46686		NE	1	SERVO - VALVE II
105-46743		SV	1	HYDRAULIC RESERVOIR
105-46744		NE	1	HYDRAULIC RESERVOIR
105-46753		SV	1	TRANSFER VALVE
105-50101-22		NS	1	NUT
105-51523.12		NE	1	SKID CLIP
1055-80237		AR	1	PANEL
1055-80238		AR	1	PANEL
105-60001W2		NE	1	TOOL
105-60186		NE	1	EXHAUST PIPE LH INSIDE
105-60354		NE	2	ENGINE MOUNT ASSY RH
105-60593		NE	2	ADJUSTABLE LEVER ASSY
105-60611		NE	2	TELEFLEX-TUBE
105-612711		NE	1	OIL TRIP TRAY
105-614061		NE	1	FIRE DETECTOR ASSY

105-61704	AR	1	OIL TANK
105-61704	NE	2	OIL TANK
105-61761	NE	1	TUBE
105-61781	NE	1	FLANSCH
105-61802	NE	1	COOLER INTAKE ASSY
105-619011	NE	1	LUBRICATION TANK ASSY
105-619031	NE	1	LUBRICATION TANK ASSY
105-62456	NE	2	PANEL ASSY RH OUTSIDE
105-62457	NE	1	BACK WALL LH ASSY
105-62458 "B"	NE	1	RÜCKWAND RECHTS VOLLST.
105-62458 B	NE	1	WALL RIGHT COMPLETELY
105-62461 "B"	NE	1	MITTERWAND VOLLST.
105-62464	NE	1	CASING ASSY
105-62464 "A"	NE	1	SCHACHT VOLLST.
105-625206	NE	1	ICE PROTECTOR
105-62720V001	NE	1	VENTILATING DUCT MONTAGE
105-62725	NE	1	COOLER COVER
105-62741	NE	1	LUBRIC COOLING SYSTEM
105-62741.28	NE	1	ELBOW
105-62747	NE	1	MOD DRAIN LINE FUSELAGE
105-62904	NE	1	MUFF
105-70221	NE	1	SEAT
105-70221GRAU	NE	2	BACK CUSHION COVER
105-70322	NE	1	REWORK SHOULDER HARNESS
105-70501.08	NE	1	LAP BELT FITTING
105-71286	AR	1	SITPOLSTER
105-71286GRAU	NE	1	SEAT CUSHIONING GRAY
105-73221.01	NE	1	FLOOR PANEL
105-73205	NE	1	CABIN STRUCTURE PANNELLING
105-73207	NE	1	CABIN STRUCTURE PANNELLING
105-73212	NE	1	CABIN STRUCTURE PANNELLING
105-73215	NE	2	ROOF PANNELLING LH
105-73216	NE	1	ROOF PANNELLING RH
105-73248	NE	1	PANNELLING, CABIN REAR WALL
105-73511	NE	1	ACTUATING DEVICE LH
105-79511.87	NE	1	SCHEDULE
105-80032	NE	2	RETRO B015CBS
105-800390	NE	1	MODIFIC HYDRAULIC
105-80097	NE	2	INST. HEAT. A. VENT. SYSTEM
105-80171	NE	1	NOZZLE LH
105-80239	AR	1	PANEL
105-80240	AR	1	PANEL
105-80329	NE	1	RETR. CYC. PITCH STICK RH ASSY
105-80335	NE	1	LOAD HOOK DETACHABLE FIX
105-80335	SV	1	LOAD HOOK DETACHABLE FIX
105-80335	AR	2	LOAD HOOK DETACHABLE FIX
105-80337	NE	1	LOAD HOOK DETACHABLE FIX
105-803441	NE	1	CARGO HOOK PERM. FIXTURE
105-80351	NE	1	MOUNTING
105-80428	NE	1	KIT
105-807214	AR	1	TURBINEN EINLASS
105-81022	SV	1	VIBRATION ABSORBER
105-81022	NE	1	VIBRATION ABSORBER
105-81022.04	NE	1	SHAFT
105-81022.12	NE	2	PART BY WEIGHT
105-81110	AR	1	RESCUE WINCH DETACHABLE PART
105-81112W2	NE	1	RITZELADAPTER
105-81210	NE	1	BUMBER UNIT INSTAL
105-81511	NE	1	REVERSED COPILOT SEAT ASSY
105-81511.09	NE	2	SHEET
105-81931	NE	2	PANEL
105-81936	NE	2	PANEL
105-82101	NE	4	INST. AUXILIAR TANK. AIRCR. SIDE
105-82102	NE	1	LONG RANGE FUEL TANK FX. PROV.
105-82151	NE	1	SWITCH ASSEMBLY
105-82206	SV	1	AUXILIARY FUEL TANK ASSY RH
105-82216	NE	1	TUBE
105-82226	NE	1	BELLOWS ASSY
105-82503	NE	3	PASSENGER SEAT
105-82521	NE	1	TUBE ASSY, SHORT
105-82761	NE	2	ARM
105-83011	SV	1	TANDEM HYDRAULIC UNIT 7VE
105-83011	AR	1	TANDEM HYDRAULIC UNIT
105-83101	NE	1	PARTIAL COVER
105-83111	NE	1	REAR ROTOR GEAR COVER
105-83116	NE	1	REAR ROTOR BLADE COVER

105-83121		NE	1	COVER ROTOR HEAD
105-83196		NE	1	ENGINE COVER
105-832061		NE	1	COVER ENGINE INTAKE
105-832111		NE	1	COVER ENGINE OUTLET
105-83216		NE	1	COVER EXHAUST AND AIR INTAKE
105-83221		NE	1	TIE-DOWN FOR MAIN ROTO
105-83231		NE	1	SACK AND BELT
105-83516		NE	1	DRAINING TANK
105-83591		NE	1	FAD FILTER
105-83869		NE	1	EXT LOUJST PERM FIXED
105-83956		NE	2	MEDICAL EQUIP WALL ARMAN
105-84002		NE	1	STR RAIL LH FIXED PT
105-84007		NE	1	STR RAIL RH FIXED PT
105-84115		NE	1	YUBE PIPE
105-84717.05		NE	1	SKID PROTECTIVE PLATE
105-84831		NE	1	SIDE SECTION LH
105-84832		NE	1	SIDE SECTION RH
105-84835		NE	1	U-PROFILE
105-853056		NE	1	ENG COWLING FWD LH MOD
105-853066		NE	1	ENG COWLING FWD RH MOD
105-853076		NE	1	CAB ROOF F PART SEPER MOD
105-85327		NE	1	COVER
105-853336		AR	3	SANDFILTER DETACH FIXTURE
105-853346		NE	1	INSTAL PART SEPARATOR FOR SANDFILTER
105-853521.01		NE	2	SHROUD
105-85354		NE	1	SEALS ROTOR MAST CONTROL RODS
105-85502		NE	1	ENG COWLING FWD RH REWOEK
105-85503		NE	1	ENG COWLING FWD RH REWOEK
105-860291		SV	4	CONTROL UNIT
105-86490		NE	1	KIT
105-86559		NE	1	SWITCH PANEL ASSY
105-880068		NE	1	Konsole GAS6
105-88921		SV	1	CONTROL UNIT
105-895666		NE	1	INSTAL HEADREST
105-899926		NE	1	SNOW SKID RH MOD
105-90986		NE	1	FRAME ASSY
105-90996		NE	1	GROUNDING CABLE
1059-1-1	AIRSHOW	Q	6	CKT MODULE
105-91106		NE	1	REL BOX
105-911151		NE	1	P/C BOARD GEN INTERLOCK
105-912021		NE	1	RELAISKASTEN 10VE
105-93975		NE	1	DRUCKSCHALTER VOLLST
105-93975		NE	1	PRESSURE SWITCH ASSY
105-94020		NE	2	WIRING HARNESS 2VB
105-94104		AR	1	IOVE PANEL
105-94107		AR	1	RELAY BOX
105-943101		NE	1	WIRE HARNESS
105-94563		SV	1	MAST MOVEMENT INSTALLATION
105-94563		SV	1	MM SYSTEM ASSY
105-94563		AR	1	SP. P MM INSTALATION
105-94563		NE	1	S.P.-MAST MOMENT INSTALLATION
105-94564		AR	1	MM INDICATOR
105-945657		NE	1	S P MAST MOMENT INSTALLAT
105-94575		NE	1	MM-DREHUEBERTRAGER
105-94641		NE	2	WIRING HARNESS 19VB
105-96273		OH	2	GH-14 WITH NVG MOD
105-98036		NE	1	CONTROL UNIT FERRANTI 29VE
105-98041		NE	1	CONTROL ROD LONGITUDINAL
105-98043		NE	1	SERVO ACTUATOR
105-980624		SV	1	CSAS CONTROL UNIT
105-98224		NE	1	FOLLOW UP TRIM
105-98301.01		AR	1	LANDING LIGHT
105-983121		NE	1	ELT SYSTEM STROBE LIGHTS
105-98328		NE	3	WIRING HARNESS
105-98328		NE	1	WIRING HARNESS 22VB
105-98334		NE	1	BLEED AIR HEATING
105-98341		AR	1	CONTROL UNIT
105-98341.06		AR	1	APPARATUS
105-98342		SV	1	CONTROL DEVICE
105-98359		NE	1	CONTROL UNIT, LONG RANGE FUEL
105-98359.1		NE	1	PANEL RANGE TANK
105-98359.9		NE	1	PANEL RANGE TANK
105-98380		NE	1	CONTROL UNIT
105-98383		NE	1	P/C BOARD SWITCHING AMPL
105-98385		NE	1	PIC BD PWR SLUP
105-984041		NE	1	LANDING LIGHT

105-98407.01		NE	1	SWITCH PANEL
105-98502		NE	3	WINDSHIELD WIPER SYSTEM
105-985386		NE	1	INSTL.ELT PARTS SANDFILTER
105-985396		NE	1	INSTL.EL. SYSTEM PART SEP. DET. (SANDFILTER
105-98706		AR	1	BOX
105-98751		NE	1	HG. WRING PLATE MOD.
105A103-1		NE	2	PETR CONTROL BOX ASSY
105-E0006-6		NE	1	BRACKET ASSY
105H213-1		NE	1	PETR VALVE. MOD
105H522-2		NE	1	COMPRESSOR
105H535-1		AR	1	COMPRESSOR
105-S810-35-3.1		NE	1	KIT
105-S830-105-3.1		NE	1	SB KIT
105-S860-40/3.1		NE	1	KIT
105-S880-69-3.1		NE	1	KIT
105V202-1		NE	1	HEAT PUMP FILTER DRIER
1060-1-1	AIRSHOW	SV	1	MODULE
1060-1-3	AIRSHOW	SV	2	DIGITAL POTENTIOMETER MODULE
10-60207-18	5985-01-633-1120	NS	1	WAVEGUIDE
106075-1		SV	1	AC POWER CONTROLLER
10-60897-69		SV	1	WAVEGUIDE
106090-3		NS	4	OUTLET ASSY
106096-1		NS	1	OUTLET ASSY
106096-2		NS	2	OUTLET ASSY
1061-1-1	AIRSHOW	SV	2	CALL MODULE
10-614950-1		AR	1	EXCITER ASSY
10-614950-1C		SV	1	EXCITER ASSY
1062-1-1	AIRSHOW	SV	1	MODULE
106272-1		SV	1	AV PORT
106354-1	106354-1MODB	SV	1	AC POWER CONTROLLER
106356-2		SV	1	OUTLET
1075L26CEW0BFC-QMT05	1075L26CEW0BFC	SV	1	HANDSET
107CDC20		SV	1	PUMP-VACUUM
1080-01	GPS-1200	SV	1	GPS
10811-12		NE	1	CABLE ASSY
109-0010-09-103		NE	5	BEARING
109-0011-03-105		NE	10	TORQUE TUBE ASSY
109-0011-05-1		NE	1	COLLAR
109-0011-76-109		SV	1	CONTROL STICK ASSY
109-0020-06-1		SV	1	TORQUE TUBE AND LEVER ASSY
109-0020-51-3		NE	1	BUSHING SLEEVE
109-0020-87-1		NE	1	ROD END ASSY
109-0020-88-1		NE	1	COUPLING
109-0020-89-1		NE	2	NUT
109-0021-17-1	L108BDM	SV	1	TRIM AND FORCE GRADIENT ACTUATOR
109-0030-05-1		SV	1	LEVER
109-0030-05-3		SV	1	LEVER
109-0030-17-103		SV	1	SUPPORT
109-0030-19-1		SV	1	BELLCRANK ASSY
109-0030-19-5		SV	2	BELLCRANK ASSY
109-0030-20-5		SV	1	BELLCRANK ASSY
109-0030-26-1		SV	1	SLIDING RACK ASSY
109-0030-28-1		SV	1	BELLCRANK ASSY
109-0032-01-13		SV	1	CONNECTING LINK RIGID
109-0032-01-29		SV	1	CONNECTING LINK RIGID
109-0032-01-61		SV	1	CONNECTING LINK RIGID
109-0032-01-69		NE	1	CONNECTING LINK RIGID
109-0032-02-25		SV	1	CONNECTING LINK RIGID
109-0032-02-41		NE	1	CONNECTING LINK RIGID
109-0032-02-57		SV	1	CONNECTING LINK RIGID
109-0032-07-1		SV	1	CONNECTING LINK RIGID
109-0033-02-103		SV	1	SUPPORT
109-0040-33-1		SV	1	LEVER BELLCRANK ASSY
109-0040-49-5		OH	1	SUPPORT ASSY
109-0040-49-5		SV	1	SUPPORT ASSY
109-0101-11-7		NE	2	SHW
109-0101-21-1		NE	1	CONICAL RING LOWER
109-0101-61-1		NE	1	RING
109-0101-62-107		NE	25	BOLT MAIN ROTOR LOCKING
109-0104-04-1		NE	2	WASHER
109-0110-53-1		SV	1	SUPPORT ASSY
109-0110-70-3		NE	5	BUSHING
109-0110-70-3		NE	5	BUSHING
109-0111-07-117		OH	1	DAMPER BRACKET
109-0111-09-103		NE	1	SLIDING RING ASSY
109-0111-25-101		NE	4	PITCH CONTROL LEVER BUSHING

109-0111-28-107		NE	1	PIN DROP STOP ASSY
109-0111-32-103		NE	16	SLEEVE BUSHING
109-0111-34-101		NE	1	UPPER FLAPPING LIMITER
109-0111-36-101		NE	1	FLAPPING LIMITER PIN
109-0111-42-109		NE	4	FIXED SUPPORT
109-0112-02-101		SV	2	MAIN ROTOR ASSY
109-0112-05-107		SV	8	MAIN ROTOR LAG DAMPER
109-0130-49-103		NE	1	WASHER
109-0130-91-105		SV	1	PITCH CHANGE SLIDER ASSY
109-0131-34-107		NE	8	SHIM TR TRUNNION
109-0135-03-101		SV	1	LEVER TR ASSY
109-0135-07-101		NE	10	BUSHING
109-0135-07-103		NE	14	BUSHING
109-0135-09-101		NE	7	BALANCING PLUG
109-0135-14-101		NE	5	BUSHING TAIL ROTOR
109-0135-16-101		NE	9	LINER ASSY BEARING
109-0135-17-101		NE	2	BOOT BELLOWAFT
109-0162-03-105		SV	1	TR HUB AND BLADES ASSY
109-0210-29-103		NE	12	WASHER LAMINATED
109-0210-31.208M01	109-0210-31.208	NE	1	RH AFT FAIRING
109-0301-26-149	109-0301-26-149M01	NE	1	PANEL ASSY LEFT
109-0301-26-150		NE	1	PANEL ASSY
109-0301-27-129		NE	2	BRACKET ANGLE
109-0310-02-102		NE	1	BRACKET
109-0310-02-124		NE	6	SHIM
109-0310-02-139		NE	20	FRAME OUTSIDE LH
109-0310-02-140		NE	14	FRAME OUTSIDE RH
109-0310-02-206		NE	1	DOUBLER OUTSIDE RH
109-0310-02-207		NE	6	DOUBLER LH
109-0310-02-212		NE	5	BRACKET RH
109-0310-02-319		NE	4	DOUBLER
109-0310-03-2		NE	2	LATCH HOUSING RH
109-0310-27-13		NE	1	RETAINER
109-0310-27-15		NE	1	RETAINER
109-0310-27-16		NE	1	RETAINER
109-0310-27-195		NE	2	DOUBLER LH
109-0310-27-196		NE	1	RETAINER
109-0310-27-197		NE	2	RETAINER LH
109-0310-27-198		NE	1	STRIP RETAINER
109-0310-27-31		NE	1	RETAINER
109-0310-47-101		NE	1	HINGE ASSY REAR
109-0310-94-104M01	109-0310-94-104	NE	1	WINDSHIELD RETAINER RH
109-0310-94-105	109-0310-94-105M01	NE	2	CENTRAL RETAINER
109-0310-94-108		NE	1	RETAINER SUP RIGHT
109-0310-94-108		NE	1	RETAINER
109-0310-97-105A1		NS	1	RETAINER LWR RH
109-0310-97-109M01		NE	1	RETAINER LOWER LH
109-0310-97-113A1	109-0310-97-113	NE	1	RETAINER ASSY
109-0310-97-115M01		NE	1	LATERAL RETAINER PORT
109-0310-97-116M01		NE	1	LATERAL RETAINER RH
109-0310-97-121M01		NE	1	WINDOW RETAINER
109-0310-97-123		NE	1	DOUBLER
109-0313-03-141		NE	4	SUPPORT
109-0313-58-113		NE	1	LH LWR NOSE COVER
109-0313-61-113		NE	3	GASKET
109-0313-88-107		NE	1	PEELING SHIM
109-0313-88-111		NE	1	PEELING SHIM
109-0313-89-125A1		NE	1	DOOR ASSY
109-0313-90-105		NE	1	FWD HINGE ASSY
109-0313-91-101		NE	1	HINGE ASSY AFT
109-0315-22-101		NS	2	MACHINED DOUBLER
109-0320-05-127M01	109-0320-05-127	NE	1	FIREWALL ASSY
109-0320-26-15		NE	1	UPPER FRAME RIB
109-0320-48-311		NE	1	ANGLE
109-0322-10-507		NE	1	BRACKET ANGLE INTERNAL LH
109-0322-76-111		SV	1	DOOR ASSY
109-0322-76-111		SV	1	PANEL ASSY
109-0322-76-203		NE	1	PANEL ASSY
109-0322-32-3		NE	14	PIN STRAIGHT HEADED
109-0324-35-101		NE	1	SLIDING DOOR HOUSING ASSY
109-0324-35-102		NE	1	ASSY HOUSING PIN
109-0324-35-103		NE	1	HOUSING PIN
109-0324-35-104		NE	1	PIN HOUSING ASSY
109-0324-73-119		NE	1	TRAILING
109-0325-08-1		NE	1	BRACKET
109-0325-08-1		SV	1	BRACKET ASSY

109-0325-08-111		NE	1	LOWER FITTING
109-0325-19-205		NE	1	ASSY LOCK
109-0325-34-109		SV	2	CATCH SAFETY
109-0326-47-107M01		NE	1	CHANNEL SEAL LH
109-0326-47-108		NE	4	CHANNEL SEAL RH
109-0330-12-7	109-0326-47-108M01	NE	1	ANGLE
109-0342-43-203M01	109-0342-43-203	NE	1	PANEL COVER UP
109-0360-05-1		NE	1	FORK
109-0360-06-101		NE	1	BRACE DRAG
109-0360-07-103		NE	1	BELLCRANK LH
109-0360-07-104		NE	1	BELLCRANK RH
109-0360-28-101		NE	1	THREADED BUSHING
109-0360-28-102		NE	1	LOWER CARRIAGE ASSY RH
109-0360-46-125		NE	1	EDGE LH
109-0360-49-217		NE	2	STRAP
109-0360-49-402		SV	1	DOOR ASSEMBLY COCKPIT RH
109-0360-49-402		AR	1	COCKPIT DOOR ASSY RH
109-0360-60-103		NE	1	DOOR ROD
109-0360-74-123		NE	2	WINDOW ASSY
109-0360-74-124		NE	2	WINDOW ASSY
109-0361-09-101		NE	3	LATCH DOOR HOOK LH
109-0361-09-102		NE	6	HOOK RH OPP
109-0361-29-103		NE	1	SHIM PEELING
109-0361-41-104		NE	2	LEVER ASSY
109-0361-45-101		NE	4	PIN ASSY
109-0361-66-101		NE	12	LATCH SEAT
109-0361-66-101		NE	8	SEAT LATCH
109-0361-78-117		NE	10	SEAL BASKET
109-0361-78-117		NE	7	SEAL BASKET
109-0361-82-103		NE	1	HANDLE PIVOT
109-0361-86-101		NE	1	HANDLE
109-0361-93-103		NE	21	WELDED MOUNTING ASSY
109-0361-93-103		NE	15	WELDED MOUNTING ASSY
109-0361-93-109		NE	2	PEELABLE SHIM
109-0361-93-111		NE	9	PLATE
109-0361-93-111		NE	6	EXTERNAL PLATE
109-0361-93-117		NE	2	PEELABLE SHIM
109-0362-05-105		NE	2	CONNECTING LINK DOOR
109-0362-11-104		NE	1	SHAFT
109-0362-20-103		NE	1	SHAFT
109-0362-20-103		SV	1	SHAFT
109-0362-20-103		NE	1	SHAFT
109-0362-23-207		NE	1	DOOR LATCH CONTROL ROD RH
109-0362-23-208		NE	1	DOOR LATCH CONTROL ROD RH
109-0362-24-103		NE	3	SHAFT ASSY
109-0362-24-103		NE	3	SHAFT
109-0362-24-105		NE	1	SHAFT
109-0362-25-107		NE	1	HOUSING
109-0370-50-103		NE	1	SUPPORT TR SHAFT
109-0370-59-107		NE	1	ANGLE AFT LH
109-0370-59-203M01		NE	1	RIGHT ANGLE
109-0370-59-219		NE	1	ANGLE DETAIL
109-0371-28-1		NE	1	SUPPORT
109-0371-32-3		NE	1	SHIM
109-0371-32-4		NE	1	SHIM
109-0371-33-13		NE	2	COVER ACCESS
109-0372-24-101		NE	1	PANEL ASSY
109-0372-34-101M01		NE	1	ANGLE LH PROFILE
109-0372-34-103		NE	1	ANGLE LH
109-0372-53-205		NE	1	BRACKET
109-0372-57-105		NE	1	SKID ASSY TAIL
109-0372-94-107		NE	1	STRIP RETAINER
109-0373-21-107		NE	2	SHIM
109-0373-21-109		NE	1	SHIM
109-0400-03-109		AR	1	A109 TRANSMISSION ASSY
109-0400-03-109		OH	1	A109 TRANSMISSION ASSY
109-0405-13-1		NE	1	NUT RING STOP
109-0405-64-103		NE	1	WASHER
109-0406-52-1		NE	1	SPRING
109-0406-52-103		NE	1	SPRING
109-0406-53-1		NE	1	SCREW REGULATOR
109-0407-41-101		NE	3	RING
109-0407-43-103		NE	3	RING LOCK
109-0407-43-105		NE	1	RING LOCK
109-0407-72-103		NE	1	SHIM UPPER
109-0407-80-101		NE	1	THERMOSWITCH

109-0424L02-101		NE	1	BEARING BALL
109-0425-06-5		NE	2	PTR DRIVESHAFT PIN
109-0425-38-1		NE	1	BUSHING SLEEVE
109-0425-45-105		NE	1	PIN
109-0425-45-107		NE	1	PIN CHECKING
109-0425-49-101		NE	1	ADAPTER SLIDING
109-0425-70-103		SV	1	RING NUT
109-0425-72-101		NE	5	RETAINING RING
109-0435-15-1		NE	2	SPACER
109-0435-15-103		NE	1	SEAL SPACER
109-0435-17-3		NE	1	PIN
109-0435-24-3		SV	2	OIL INDICATOR
109-0435-24-3		NE	3	OIL INDICATOR
109-0435-24-3		NE	3	INDICATOR OIL
109-0440-06-105		SV	3	TAIL GEARBOX ASSY 90 DEG
109-0445-15-103		NE	1	SEAL
109-0445-50-101		NE	1	SEAL TR GB INPUT
109-0445-52-101		NE	3	SEAL
109-0501-11-1		NE	2	PIN BEARING
109-0501-20-1		NE	3	BUSH
109-0501-21-3		NE	2	BOLT MACHINE
109-0504-24-1		NE	4	WASHER NONMETALLIC
109-0506-11-1		NE	1	SPRING BRACKET
109-0506-99-101		NE	1	ROTOR BRAKE CONT CABLE
109-0512-14-105		NE	1	PIVOT
109-0518-45-103		NE	1	TUBE ASSY METAL
109-0570-03-110		NE	1	ASSEMBLY SKID RH
109-0570-06-104		SV	1	LANDING GEAR SADDLE RH
109-0570-09-103		NE	1	LOWER SUPPORT AFT CROSS BEAM ASSY
109-0570-10-103		NE	1	BULLONE SPECIALE
109-0570-23-106		NE	1	SHOE ANTIABRASION PROOF REAR
109-0570-32-107		SV	3	LANDING SKID DAMPER
109-0600-37-105		NE	2	SPACER
109-0600-71-1		NE	3	TACH GENERATOR
109-0601-47-107		SV	1	OIL BREATHER TUBE ASSY
109-0601-47-141		NE	1	OIL BREATHER PIPE ASSY
109-0601-66-111		NE	24	GASKET
109-0601-66-111		NE	24	GASKET
109-0601-81-119		AR	1	EXHAUST TUBE
109-0601-81-143		SV	1	EXHAUST DUCT ASSY LH
109-0601-83-109		NE	1	AIR INTAKE DUCT ASSY
109-0602-17-105		SV	1	ASSY LH SUPPORT
109-0602-17-106		SV	1	ASSY RH SUPPORT
109-0605-50-105		NE	1	LINK SUPPORT ASSY
109-0605-53-101		SV	2	BRACKET AFT
109-0605-63-109	NSCM A-126	SV	1	ENGINE MOUNT TRIP-OD ASSY AFT RIGHT
109-0605-69-103		SV	1	BIPOD ASSY ENGINE MOUNTS
109-0605-74-103		NE	2	ENGINE BRACKET
109-0610-19-5		NE	1	RUBBER TUBE
109-0610-20-1		NE	2	PLATE
109-0610-20-3		NE	2	PLATE
109-0610-48-1		SV	2	DRAIN DISH
109-0612-23-1		SV	2	GUARD ASSY DRAIN
109-0613-93-101		NE	1	FLEX HOSE
109-0614-18-101		NE	2	FILLER
109-0619-06-1		NE	6	SEAL
109-0620-88-101		NE	1	LINK STRAP ASSY
109-0621-30-101		NE	1	METALLIC TUBE ASSY
109-0621-31-101		NE	1	METALLIC TUBE ASSY
109-0630-70-103		NE	1	CABLE ASSY
109-0630-70-103		NE	1	CABLE ASSY
109-0630-70-105	65761-1	SV	2	GEARBOX ASSY W/RVDT OPTION
109-0641-43-167		NE	1	DOOR ASSY
109-0641-46-134		NE	1	SEAL
109-0641-71-301		NE	1	LEFT DOOR ASSY
109-0641-90-303		NE	1	LEFT DOOR COWLING
109-0641-90-304		NE	1	RIGHT DOOR COWLING
109-0680-11-101		NE	1	DUCT
109-0702-97-103		NE	1	FERMO
109-0702-97-105		NE	1	STOP
109-0710-31-111		NE	1	AIR DUCT ASSY
109-0711-08-1	109-0711-08-3	NE	1	CONTROL AIR TEMP SYSTEMS
109-0712-10-109		NE	1	CUSHION SEAT BACK ASSY
109-0712-10-111		NE	1	HEAD CUSHION
109-0714-82-102		NE	2	DUCT ASSY AIR CONDITIONING RH
109-0714-82-201		NE	1	DISTRIBUTION BOX ASSY



109-0716-79-119		SV	1	SUPPORT ASSY
109-0718-77-101		NE	2	HANDLE SLIDING DOOR
109-0722-10-101		NE	2	BUSHING
109-0729-08-111	15DA01U	OH	1	INDICATOR, TACH
109-0729-08-5	15DA01-TYP1201	OH	1	INDICATOR, TACH
109-0729-13-3	5021-3048	OH	1	INDICATOR, TURB OUT TEMP
109-0729-19-1	AG-06-1	SV	1	COMMUNICATION CONTROL UNIT
109-0729-19-3	AG-06-1-A	SV	1	PANEL, POWER DISTRIBUTION
109-0729-20-107	PAL-12-7	OH	1	CONTROL SIGNAL
109-0729-21-105	PGI-12-3	OH	1	PANEL ALARM
109-0729-22-113	RBE25-11	OH	1	DETECTOR, RPM LIMIT
109-0729-22-5	RBE15-5	OH	1	DETECTOR, RPM LIMIT
109-0729-23-103	04D904A-TYP1857	OH	1	INDICATOR LIQUID LEVEL
109-0729-26-3	14D801G-TYP1360	OH	1	INDICATOR, OIL TEMP AND PRESS
109-0729-27-109	14D801F	OH	1	INDICATOR, OIL TEMP
109-0729-27-113	14D824	OH	1	INDICATOR, OIL TEMP
109-0729-27-3	14D801F-TYP1359	OH	1	INDICATOR, OIL TEMP
109-0729-28-1	4344-3022	OH	1	INDICATOR, FUEL PRESSURE
109-0729-28-3	124-003	OH	1	INDICATOR, FUEL PRESSURE
109-0729-29-1	4344-3021	OH	1	INDICATOR, HYD PRESS
109-0729-29-109	14D801F	OH	1	INDICATOR, OIL TEMP
109-0729-29-3	124-419-1	OH	1	INDICATOR, HYDRAULIC PRESS
109-0729-30-109	13DC028-TYP1350	OH	1	INDICATOR, DUAL TORQUE
109-0729-31-21	PAL19-21	OH	1	PANEL ALARM
109-0729-31-5	PAL19-5	OH	1	PANEL ALARM
109-0729-32-1	124-486	OH	1	TOT INDICATOR
109-0729-32-115	08DC06G	OH	1	INDICATOR
109-0729-32-117	08DC06N	OH	1	INDICATOR, ITT
109-0729-33-1		SV	2	VSI
109-0729-34-1	16034	OH	1	ALTMETER
109-0729-38-1	124-487	OH	1	INDICATOR, DUAL VOLTMETER
109-0729-38-3	124-488	OH	1	INDICATOR, DUAL VOLTMETER
109-0729-46-1		SV	1	BOX, AMPLIFIER
109-0729-50-1	PMB20-1	SV	1	PANEL, CONTROL
109-0729-51-1	PMA10-1	SV	1	PANEL ASSY
109-0729-87-101	06D843	OH	1	INDICATOR, DUAL PRESSURE
109-0729-96-103		SV	1	AUDIO GENERATOR
109-0729-99-105	DCEB37V-1	SV	4	ELECTRICAL BOX
109-0730-16-113	15DA03B-TYP1487	OH	1	INDICATOR TACH
109-0749-93-101		NE	1	VNL PANEL
109-0760-03-34		SV	1	TANK ASSY WELDED
109-0760-42-107	4212403	SV	1	PUMP HYDRAULIC AP1.SV.01-03
109-0760-53-101		AR	1	PUMP ROTOR BRAKE
109-0763-86-101		NE	1	TUBE ASSY METAL
109-0784-82-209		NE	1	EXTENSION TNC/TPS
109-0810-79-123		NE	2	BRACKET AIR COND
109-0811-76-153		NE	4	DECAL PLACARD
109-0821-47-101		NE	37	ROLLER
109-0822-68-113		SV	1	SLIDING WINDOW
109-0822-68-113		NE	1	SLIDING WINDOW
109-0822-68-113		NE	1	WINDOW ASSY
109-0822-75-132		SV	1	ROD TUNING
109-0822-75-137		NE	4	WASHER
109-0822-75-139		NE	4	WASHER
109-0823-29-113		NE	2	BOLT
109-0823-29-117		NE	5	WASHER
109-0823-31-105		NE	1	SUPPORT
109-0823V36-101		NE	1	HOSE INSULATED ASSY
109-0859-90-103M01	109-0859-90-103	NE	1	DOUBLER
109-0881-33-210		NE	1	SUPPORT ASSY RH OPP
109-0881-33-316		NE	1	FITTING RH SLIDING DOOR
109-0881-34-103		NE	1	RIB
109-0881-34-109		NE	1	ANGLE LH
109-0881-34-111		NE	1	COVERING
109-0881-34-113		NE	1	SHIM SPACER
109-0881-34-121		NE	1	ANGLE
109-0881-34-123		NE	1	COVER
109-0881-34-129		NE	1	ANGLE LH
109-0882-29-121		NE	1	ANGLE PLATE
109-0900-08-109	EAP12-15	SV	1	WARNING LIGHT PANEL
109-0900-21-107		NE	2	CUP
109-0900-38-101		SV	1	CONTROL PANEL COMPASS
109-0900-49-107		SV	1	PANEL ASSY FUEL CONTROL
109-0900-54-211		NE	1	FUEL PROBE TRANSMITTER
109-0900-54-211		SV	2	FUEL PROBE TRANSMITTER
109-0900-54-211		SV	1	FUEL PROBE TRANSMITTER

109-0900-66-3A01	193860-13	SV	2	INTEGRATED DISPLAY SYSTEM
109-0900-66-3A01	193860-11	SV	1	INTEGRATED DISPLAY SYSTEM
109-0952-84-107		NE	1	DOUBLER
1092100M8B	105-93921	OH	1	ANTI ICE ACTUATOR
10933001-1		NE	1	LITE ASSY KIT LEFT
109-3900-30-1		NE	1	PIN STRAIGHT HEADED
109-3900-37-1		NE	7	PIN TOW
109-3900-51-1		NE	1	CLEVIS FOR TOW BAR
109-4160-16-101		SV	1	LEVER ASSY UPPER
109-4160-19-101		OH	1	MIDDLE LEVER ASSY
109-4160-21-101		NE	2	BUSSOLA
109-8131-22-111		NE	12	WEIGHT, STATIC BALANCE T/R
109-8131-22-115		NE	24	MASS BALANCING
109-8131-22-117		NE	8	MASS BALANCING
109-8131-22-117		NE	16	WEIGHT COUNTER BALANCE
109-8131-30-109		NE	2	BUSHING
109-8131-38-117		NE	8	SHM
109-8131-38-119		NE	4	SHM
109-8131-38-121		NE	10	SHM 2.685-2.695
109-8131-38-123		NE	10	SHM 2.705-2.715
109-8131-38-125		NE	8	SHM 2.725 - 2.735
109-8131-38-127		NE	12	SHM 2.745-2.755
109-8131-38-129		NE	14	SHM 2.765 - 2.775
109-8131-38-131		NE	10	SHM 2.785-2.795
109-910106-33		NE	14	WASHER
109-A816-03-126-1		NE	1	BRACKET ASSY
109-A816-04-119		AR	1	AFT LITER BOARD MOUNT
109-A816-05-117-1		NE	1	LITER SUPPORT GUARD
109-A816-09-111-1		NE	2	AFT SEAT BOTTOM
109A816-20-113-1		NE	5	LITTER LATCH DISC ASSY
109-A816-50-116-2		NE	1	POUCH RM
1100-A-2500	DBA-1100MR	SV	1	ASSY SATELLITE ANT RCVG FLT.D
1-10-175301BCR		NE	1	3 POINT AUTOM HARNESS
110-323		NE	1	ANTENNA KIT
110-328-0		SV	1	406 BLADE ANTENNA
110-337		SV	1	ANTENNA
110-338		SV	1	ANTENNA ARTEX
110-338		AR	1	ANTENNA
1-1041-144		NS	2	COMPONENT
11097-1		SV	1	SWITCH IMPACT
1-10-E50301	1-10-E50301/AGU080	SV	1	SEAT BELT AND HARNESS ASSY
110PNO1V01	704447621035	OH	1	TACHOMETER IND
1110-A-0501-10	CNX-100	SV	1	CABIN NETWORK XCELERATOR
1110-A-0501-20	CNX-200	OH	2	ACCELERATOR, NETWORK
111-11111-0000	TS10B	NS	1	HARNESS
1-11182G		SV	2	PRESSURE XMTR
111302-5		OH	2	H-S-I
1114-039480		NE	1	HARNESS
1120-81024		SV	1	VIB ABSORBER
1121-10151W1		NE	E	GUIDE SLEEVE
1121-21451		NE	1	HOLDER
1121-31508		AR	1	ROTOR WAVE
1121-31566		NE	1	SHAFT
11213AL		SV	1	PRESSURE SWITCH
1121-41903.24		NE	2	BELLOWS
1121-41903.24		NE	1	BELLOWS
1121-51002		NE	1	SKID SHOE
1121-62671		NE	1	HOUSING ASSY
1121-70561		NE	3	HEADREST
1121-70651.71		AR	1	TUBE
1121-70651.75		AR	1	TUBE
1121-70651.89		AR	1	TUBE
1121-71124		NE	1	COVER PLATE ASSY
113300-03A1		AR	5	FUEL PUMP
11336AA		OH	1	VACUUM GAUGE
1138PGCP1-15		SV	1	SWITCH LOW PRESS OIL
114-049		OH	1	IND. FAN SPEED
115-01771-01	GTx345	SV	1	RACK
1151324-1M218		SV	2	ELT - GERMANY CODED
115-201-3		SV	1	PRESSURE INDICATOR
115-201-4		SV	1	DUAL PRESS IND
115-201-4		NE	1	SIGNALCONDITIONER
115-230NVG	AC410047-NVG	OH	1	AIR TEMP IND
1152394-1		SV	1	ELT BRACKET
1152394-2		SV	1	ELT BRACKET
1152572-2	PC-251-12312	SV	1	STATIC INVERTER

1159AV50723-1	W50723	NS	2	HARNES
1159C20080-23		NE	1	CABLE
1159H47440-1		AR	2	PULSATION DAMPER
1159SB40396-11		NE	1	BRACKET
1159SB40588-3		SV	1	NOSE WHEEL PANEL
1159SB47807-13		NS	1	BRACKET
1159SB49016-1		FN	1	APU WIRING HARNESS
1159SCAV402-2	4585-2-000	SV	1	IMPACT SWITCH
1159SCAV462-5	700-D36409A-008	SV	1	NAV CONTROL
1159SCAV462-7	700-D36411A-008	SV	1	ADF CONTROL
1159SCAV462-9	700-D36415A-004	SV	2	HRK CONTROL
1159SCAV472-101		SV	1	TRANSDUCER CABIN DIF
1159SCF208-1	DRA45C-26	SV	1	OVERSPEED WARNING SWITCH
1159SCF412-11	523273	OH	1	ENGINE MONITOR
1159SCF426-2	128-413	SV	3	EL INDICATOR
1159SCF427-3	128-406	SV	2	ELPU
1159SCF452-5	3A1320A	AR	1	FDR POSITION SENSOR
1159SCF578-5		SV	1	LIGHTPLATE REV D
1159SEAV40123		SV	1	APU TEST BOX
115-MA1-132		NE	4	FAN ASSEMBLY
116012-0000	5935011959995CW	NS	3	CONNECTOR
1161-21-140		FN	2	NAVIGATION COMPUTER UNIT
117-0550-2		AR	1	KLIMA
117-0550-3	117-0550-3-2	NE	1	AIR CONDITIONING UNIT
117-10521		NE	1	BRAKE HAND LEVER
117-1111-01.00		NE	1	TANK COMPL INSTALL
117-11123.06		NE	1	HEX BOLT
117-11137		NE	1	TORQUE STRAP
117-11203-01		NE	1	ROD ASSY
117-11203-01		SV	1	ROD ASSY
117-12001W3		NE	1	OIL DRAIN HOSE
117-12010W11		NE	1	WRENCH SET
117-12010W15		NE	2	PULLER
117-12010W19		NE	2	HOLDER
117-12010W2		NE	1	PUSHER
117-12010W28		SV	1	MOUNT
117-12010W29		NE	1	PULLER
117-12010W3		NE	1	PUSHER
117-12010W40		NE	1	GUDE SET
117-12010W43		NE	1	PULLER
117-12010W44		NE	1	PULLER
117-12010W45		NE	1	PULLER
117-12010W56		NE	1	GUARD
117-12010W63		SV	1	PUSHER
117-12010W63		NE	1	PUSHER
117-12010W68		NE	1	PUSHER
117-12010W70		NE	1	MOUNT
117-12010W70		NE	1	MOUNT
117-12010W72		NE	1	WORKING STAND
117-12010W75		NE	1	REACTION ARM
117-12020W2		NE	1	PUSHER
117-12020W4		NE	1	Montagwerkzeug
117-12020W7		NE	2	PUSHER
117-12060W5		NE	1	PUSHER
117-12110W6		NE	1	PUSHER SET
117-12140-01		NE	1	ACC. GEARBOX ASSY LH
117-12140W2		NE	1	PUSHER
117-12140W7		NE	1	PULLER
117-12150W1		NE	1	PUSHER
117-12150W2		NE	1	PUSHER
117-12170W1		NE	1	PUSHER SET
117-12250W16		SV	1	PUSHER
117-12250W19		NE	1	IMPRESSIVE TOOL
117-12250W6		NE	1	PUSHER
117-12256-01		NE	1	SEAL RING
117-12300W5		NE	2	PUSHER
117-12300W7		NE	1	PUSHER
117-12303-01		FN	1	SEAL SPACER
117-12303-01		NE	1	SPACER
117-12415-01		SV	1	MOUNT ASSY
117-12601-01		NE	2	BALL BEARING
117-12602-01		NE	8	BALL BEARING
117-12603-01		NE	10	ROLLER BEARING
117-12605-01		NE	5	ROLLER BEARING
117-12606-01		NE	6	ROLLER BEARING
117-12607-01		NE	10	ROLLER BEARING

117-12609-01		NE	10	BALL BEARING
117-12610-01		NE	4	ROLLER BEARING
117-12610-01		NE	2	ROLLER BEARING
117-12612-01		NE	6	ROLLER BEARING
117-12614-01		NE	8	ROLLER BEARING
117-12615-01		NE	6	ROLLER BEARING
117-12616-03		NE	8	BALL BEARING
117-12617-01		NE	6	ROLLER BEARING
117-12619-01		NE	4	BALL BEARING
117-12621-01		NE	8	ROLLER BEARING
117-12622-01		NE	12	BALL BEARING
117-12623-01		NE	7	BALL BEARING
117-12645-05		SV	5	LUBE PUMP ASSY LH
117-12645-05		SV	1	SCHMIEROLPUMPE
117-12645-07		SV	2	LUBE PUMP ASSY RH
117-13901.01		NE	1	HUB CAP
117-141081		NE	2	MAIN ROTOR HEAD
117-141081		AR	1	HEAD OF PROPELLER
117-141831		SV	7	INNER SLEEVE ASSY
117-141831		AR	4	INNER SLEEVE ASSY
117-151421V001	117-151421	SV	1	BLADE ARM 1
117-151441V001	117-151441	SV	1	BLADE ARM 3
117-152111		NE	1	TPY CAP ASSY
117-15856 C		NE	1	ELASTIC BUSHING
117-15860		SV	10	CONNECTION FITTING
117-16010-01		SV	2	MAIN DRIVE SHAFT
117-21181-01		NE	3	WINDOW ASSY LH
117-21197-04		NE	1	GUSS SET
117-21199-52		SV	1	WINDSHIELD ASSY RH
117-21199-52		NE	1	WINDSHIELD ASSY RH
117-22581.01		SV	4	SIDE WINDOW ASSY LH
117-22953-21		SV	2	COVER ASSY
117-23392-08		NE	1	BLANKET ASSY RH
117-24101-18		NE	2	COCKPIT DOOR ASSY RH
117-24202-13		NE	1	CABIN DOOR ASSY LH
117-24261-03		NS	2	SEAL
117-24261-07		FN	1	SEAL
117-24261-09		FN	1	SEAL
117-24261-09		NE	1	SEAL
117-24261-11		NE	1	SEAL
117-24283-08		NE	1	RAIL RH
117-24285-01		NE	2	SPACER
117-24292-13		NE	1	EMERG. RELEASE MECH. ASSY L
117-24292-13		NE	1	EMERG. RELEASE MECH. ASSY LH
117-24302-02 "H17"		NE	2	CARGO DOOR
117-24612-01		NE	1	HINGE ASSY
117-24627-01		FN	1	SHRM
117-24627-01		NE	1	SHRM
117-24646-05		SV	1	DOOR LOCKING CYLINDER
117-30640		AR	1	RETROF. HORIZ. STAB FN ASSY
117-31547		NE	1	SHAFT
117-315671		NE	1	SHAFT
117-31714		NE	1	TAIL ROTOR HEAD
117-31714		NE	1	TAIL ROTOR HEAD
117-317391		SV	1	TAIL ROTOR HEAD
117-317411		SV	2	TAIL ROTOR BLADE ASSY
117-31742		AR	8	TAIL ROTOR BLADE
117-31748		SV	1	TAIL ROTOR BLADE BONDED
117-384031-1	20B380-5	OH	1	TURN AND BANK INDICATOR
117-410271		NE	1	LATERAL TRIMMER
117-41110-02		NE	1	COVER ASSY
117-41111-01		NE	1	BOOT ASSY
117-41201-01		NE	4	TORQUE TUBE ASSY
117-41201-01		NE	4	TORQUE TUBE ASSY
117-412581		NE	1	GRP ASSY
117-41308-05		NS	1	BUSHING
117-41314-01		NE	1	BOOT ASSY
117-41340.01		NE	1	HOUSING ASSY
117-41634		NE	1	PEDAL ASSY RH
117-41904-07		SV	1	CARDANRING, TWO PART
117-42185-25		NE	1	CONTROL ROD
117-42185-25		NE	1	CONTROL ROD ASSY
117-44001WS.06		NE	1	WEDGE
117-44001WS.07		NE	1	WEDGE
117440-1		SV	1	BASE, RADIO BEACON
117-44115WQ		NE	1	PUSHING OUT TOOL

117459-2		SV	1	ADELT BEACON
117-467531		NE	1	TRANSFER VALVE
117-5000211		NE	1	SKID PROTECTIVE PLATE
117-601131		SV	1	FIRE WALL AFT LOWER LH
117-601141		SV	1	FIRE WALL AFT LOWER RH
117-61268-01		NE	1	FITTING
117-61311-01		NE	3	PRESS SWITCH
117-62616-01		NS	1	BOLT
117-63518-01		NS	1	BUSHING
117-64134-01		NE	1	SEAL
117-64141-21		NE	1	FILLER ASSY
117-64141-21		NE	1	FILLER ASSY
117-64151-03		NE	12	BOOSTER PUMP
117-64151-03		SV	4	BOOSTER PUMP
117-64152-01		SV	1	FUEL QUANTITY TRANSMITTER
117-64155-01		NE	2	SEAL
117-64159-01		NE	1	METAL O SEAL
117-64159-01		NE	1	SEAL
117-64172-03		SV	6	SUPPLY FUEL CELL ASSY
117-64173-01		SV	1	REAR FUEL CELL ASSY
117-64173-01		NE	3	REAR FUEL CELL ASSY
117-64174-01		SV	1	FWD FUEL CELL ASSY
117-64174-01		SV	3	FWD FUEL CELL ASSY
117-64174-01		SV	2	FWD FUEL CELL ASSY
117-64569-03		NE	1	PRESS SWITCH FUEL
117-66260-01		NE	1	FIRE WALL ASSY AFT LH
117-67122-01		NE	1	STRAINER ASSY
117-67172-01		NE	1	OIL TANK LH
117-67172-02		NE	1	OIL TANK RH
117-68101-01		SV	1	SCROLL ASSY
117-68121-01		NE	1	HOULTING
117-68122-01		NE	6	SHM
117-69005-03		OH	1	INDICATOR, TORQUEMETER
117-712261		NE	1	COVER SEAT PAN
117-712271		NE	1	COVER BACK REST
117-71305-01		NE	3	WIPER CONVERTOR
117-72150-01		NE	2	NOZZLE ASSY LH
117-72150-02		NE	2	NOZZLE ASSY RH
117-72461-01		SV	1	SENSOR
117-725021		NE	1	REWORK BLEED AIR HEATING
117-725041.08		NE	1	COUPLING SLEEVE
117-72582-03		SV	1	MIXING VALVE
117-72582-05		NE	2	MIXING VALVE
117-72582-05		NE	1	MIXING VALVE
117-72623-01		NE	1	COVER
117-770051		NE	1	COVER ENGINE INLET
117-770071		NE	1	COVER ENGINE OUTLET
117-80023		NE	1	SUPPORT ASSY
117-80036		NE	1	INST. RAILS
117-80044		NE	2	FUEL VENT AND DRAIN LINES
117-80047		NE	1	PROV FLOOR
117-80064		NE	1	ASSEMBLY
117-80070		AR	1	DECKEL
117-80078		NE	1	MOD OF INTERIOR PANEL UP RH
117-80094		NE	1	SCOOP
117-80127		SV	1	LOAD HOOK DETACH. PART
117-80156		NE	1	STRUT
117-80168		SV	1	VIBRATION ABSORBER
117-80170		SV	1	VIBRATION ABSORBER
117-80170V001		SV	2	VIB ABSORBER REPAIR
117-80175	117-80175B2	NE	3	TANK
117-80180		SV	1	VIBRATION ABSORBER
117-80180		NE	1	VIBRATION ABSORBER
117-80284.09		NE	1	FITTING
117-80355		AR	1	VIP FIXED PROVISION
117-80356		NE	1	MOD SET VIP-LIFT
117-804181		NE	1	ANTI STATIC CABLE
117-804251.10		NE	1	CONSOLE
117-81104-01		NE	1	COVER ASSY
117-81253-01		NE	1	WIRING HARNESS
117-83617-01		NE	2	PROTECTOR ASSY
117-83617-01		AR	2	PROTECTOR ASSY
117-83617-03		AR	1	PROTECTOR ASSY
117-84045		NE	1	SKID PROTECTIVE PLATE
117-841014		NE	1	SCAVENGE OIL FILTER SYSTEM
117-84109		NE	2	SETTLING PROTECTOR

117-84113		NE	1	SETTLING PROTECTOR ASSY
117-84271		NE	12	WEIGHT ASSY LH
117-84271		NE	1	WEIGHT ASSY LH
117-84272		NE	2	WEIGHT ASSY RH
117-84272		NE	7	WEIGHT ASSY RH
117-84338		NE	1	CARDS BAG
117-84442		NE	1	STOP
117-84624		NE	1	WATER CONDUCTORS
117-847054		SV	1	SETTLING PROTECTOR
117-85111-01		AR	1	SEAT BANK
117-85171-03		NE	3	CO-PILOTEN SEAT
117-85171-03		AR	1	SEAT
117-85194-23		NE	1	INT. PANEL CARGO WHITE ASSY - KIT
117-860024		NE	1	PEDAL COVER ASSEMBLY
117-86061		NE	1	COVER F PASS SEATS
117-86111		NE	1	HIGH DEFIT. SEAT
117-86119		NE	1	HOSE ASSY
117-86138		NE	1	FLAP ABOVE
117-86146		NE	1	FITTING BELOW
117-86214		NE	1	INST JUCTION BOX
117-86249		NE	2	SEARCHLIGHT SX16
117-86307		NE	1	OUTB. L. SP. PERM. FKT. VA
117-879111		NE	1	INSTALLATION KIT
117-88024		NE	1	PLATE ASSY
117-883541		SV	1	MOTHER BOARD
117-884311		SV	1	SIGNAL PROCESSING SPAS
117-88659		SV	1	BELLCRANK ASSY
117-88814		NE	5	TRANSDUCER
117-897321		NE	1	LAMP
117-89783-01		NE	2	FUEL PUMP FAIL DETECTOR
117-89783-01		NE	1	FUEL PUMP FAIL DETECTOR
117-902011		OH	1	TRIPLE INDICATOR RPM
117-902011		SV	1	TRIPLE TACH INDICATOR
117-902031	124T499-7	SV	2	TOT INDICATOR
117-902041		OH	2	ENG. OIL T/P INDICATOR
117-902061	124L507-6	SV	1	DUAL AMMETER 200A
117-902061		NE	1	DUAL AMMETER INDICATOR
117-902141		AR	1	CSAS
117-902141		SV	1	CONTROL UNIT CSAS
117-91034-03		SV	1	DETECTOR
117-92031-03		NE	1	CONTROL UNIT
117-92031-03		OH	2	CONTROL UNIT
117-92031-07		SV	2	CONTROL UNIT
117-92031-07		NE	1	CONTROL UNIT
117-92040-03		SV	1	LIGHT EMERGENCY EXIT SIGN
117-92042-01		SV	1	IMPACT SWITCH
117-92049-01		NE	3	POWER SUPPLY
117-94035-05	124-500-3	NE	1	IND. XMSN OIL PRESS. DUAL
117-94036-05		OH	2	DUAL OIL PRESS INDICATOR
117-940471		NE	1	INDICATOR AIRSPEED
117-940481		SV	1	AIRSPEED INDICATOR
117-94051-05	124-499-4	SV	1	TOT INDICATOR
117-94051-05		SV	1	INDICATOR-TOT
117-94051-05		OH	1	T4 INDICATOR
117-94051-07	124-499-5	SV	1	TOT INDICATOR
117-94051-07		OH	1	TOT-INDICATOR
117-94052-07	82000-05605	SV	1	ANNUNCIATOR PANEL
117-940521		NE	4	AIRSPEED INDICATOR
117-94052-11		NE	1	ANN PANEL
117-94052-17		SV	1	ANNUNCIATOR PANEL
117-94052-17		NE	4	ANNUNCIATOR PANEL
117-94053-03	6505A-3053	OH	2	TRIPLE INDICATOR RPM
117-94053-03		NE	1	TRIPLE INDICATOR
117-94053-03		OH	2	TRIPLE RPM INDICATOR
117-94054-01	PF240-N3	OH	2	INDICATOR FUEL QTY KG
117-94054-03	PF240-N4	SV	1	INDICATOR FUEL QUANTITY (GA)
117-94056-03	6503A-3101	OH	1	N1 INDICATOR
117-94056-03	6503A-3101	OH	2	INDICATOR N1
117-94057-01		SV	2	TEMPRETURE
117-94058-07	124.498-6	OH	1	INDICATOR TEMPRATURE OIL
117-94058-07	124.498-6	NE	2	INDICATOR TEMPRATURE OIL
117-94061-01		SV	1	RPM WARNING CONTROL UNIT
117-943231		OH	1	STBY HORIZON IFR
117-945641		NE	1	MM-ANZEIGEGERAET
117-94564W2		NE	2	MM-BALANCER
117-945661		SV	1	SP MAST MOMENT INSTALLATION

117-945661		AR	1	SP, P MM INSTALATION
117-94680-03		NE	1	HOSE ASSY
117-95769-01		NE	1	WIRE HARNESS
117-95879-01		NE	1	WIRING HARNESS
117-958811		NE	1	WIRING HARNESS
117-98043		NE	1	FILTER
117-980601		NE	1	VENTILATION EQUIP DESK
117-98130		SV	1	P/C BOARD LR FUEL TK
117-98130.01		AR	1	BOARD ASSY
117-98133		NE	1	LR FUEL TANK
117-98135		NE	1	MOD PART RETROFIT VIP TANK
117-98192		NE	1	WIRING HARNESS 302VB
117-982021		NE	1	WIRE HARNESS
117-982041		NE	1	WIRE HARNESS
117-98228		NE	3	PANEL-LTG PLASTIC
117-98230		NE	1	WIRING HARNESS 80VB
117-98248		NE	1	WIRING HARNESS 48VB
117-98295		NE	2	WIRING HARNESS 67VB
117-98331		NE	2	BATTERY INST AFT SECT
117-98336		SV	1	CONTROL UNIT YAW CSAS
117-98336		NE	1	CONTROL UNIT YAW CSAS
117-98439		SV	2	CONTROL UNIT
117-98538		NE	1	WIRING HARNESS 538VB
117-98609		SV	1	RELAY VOLLST
117-98682		NE	1	PRINTED CIRCUIT BOARD ASSY
117-9970119600		NE	1	CSAS P/R TEST SET
117-AS820-104-3.1		NE	1	KIT
117-AS880-127-3.1		NE	2	KIT
117-AS890-105-3.1		NE	1	KIT
117C2-5871-001-2.C	B711M4143101	NE	1	POWER PLANT, BLANKET ENG.
117-E0018.2		NE	1	COVER PLATE ASSY
117-S820-1-3.1		NE	1	KIT
117-S840-103-3.1		NE	1	SB KIT
117-S840-104-3.1		NE	1	SB KIT
117-S860-102-3.1		NE	4	KIT
117-S880-105-3.1	KIT:117-SB80-105-3.1	NE	1	KIT CONV. A-3 TO A-4
1180-1-12	UNS1	SV	1	UNS1 NCU
11-8150-1		AR	1	TIMING KIT
11-9110-1		AR	1	TIMING LIGHT TESTER
119300-101		NE	2	AW119 FILTER ASSEMBLY UPPER
119350-101		NE	4	AFS AW119 FILTER ASSEMBLY SIDE
120-03048-0002		NE	6	IC LM139J
12042-0061		NE	5	DIODE
121-0011-000		NE	1	ANTENNA
121-016796-01	AT-51	SV	1	ANTENNA
121-049675-02		NE	1	ANTENNA
12192-00		NE	3	SMOKE DETECTOR
1-2233-28		NE	1	SEAL
1229-1		OH	1	INDICATOR, BATT TEMP
1234T100-7TZ		AR	1	TURN COORDINATOR
124-1128-1		OH	1	INDICATOR DUAL DC AMMETER
124-244-2	209-070-263-009	OH	1	IND VOLT METER
124-444-2		OH	1	TOT INDICATOR
124-507-04		NE	1	AMMETER DC DUAL
124-545	222-375-024-101	OH	1	INDICATOR
124-546	222-375-016-101	OH	2	INDICATOR
124-549	222-375-017-101	OH	2	INDICATOR, XMSN OIL TEMP
124-550		OH	2	INDICATOR, ENGINE OIL TEMP
124-550-3		OH	1	INDICATOR, ENGINE OIL TEMP
124-679-1		SV	1	CGB-PRESS/TEMP-IND
124-933A	209-070-264-1	SV	1	INDICATOR, DUAL AMPS
124L507-6		NE	1	INDICATOR
124L507-6		NE	1	DUAL AMMETER INDICATOR
12507G-44		SV	1	HEADSET MIC
1259T100-3		SV	5	ACTUATOR
126-182-10	AC410004	SV	1	ENGINE TORQUE IND
126-306-5	222-375-064-105	OH	1	INDICATOR, TOT DUAL FUEL QTY
126PN01Y07	704447-621-086	OH	1	INDICATOR, ENGINE TORQUE
128-413	1159SCF426-2	SV	2	EL INDICATOR
1286-1-1	212-077-200-3	SV	1	COMMUNICATION CONTROL UNIT
129-0160-43-101		NE	13	SPACER INTERNAL
129-0160-44-101		NE	10	SPACER EXTERNAL
12903-4	P80134004	NS	1	SWITCH PRESSURE
129415-024		NS	1	SOLENOID
1297C-4-04		OH	1	AIRSPEED INDICATOR
129920-3		OH	1	ATTITUDE INDICATOR

129920-3		OH	1	ATTITUDE INDICATOR
1300160-3	3G2150V10651	SV	1	COCKPIT CONTROL PANEL, ECS
1-300-363-03	2925-00-950-2516	NE	6	IGN-UNIT
1301S		NS	1	FAIL SAFE
130-380041-7	41-402-1	OH	1	TEMP TURBINE INTERSTAGE
130-380045-7	83-183-1	OH	1	OIL TEMP & PRESS IND
1305-1-5	1305-58-2	SV	2	SMART SWITCH ADAPTER
1308-85		NE	1	ANTENNA
13-1-0110		SV	1	SERVO MOTOR
13-11014P		NE	1	PART
1312-1-1		SV	1	RCVR/TRANS MODULE
1312-1-2		SV	1	MODULE
1317S		NS	2	FAIL SECURE
132NE		NE	1	OAT-SENSOR
1330-16		SV	1	SCAT COMPUTER
1333-200-200	071-50014-0400	SV	2	HGA-48 HIGH GAIN ANTENNA
1333-300-200	071-50014-0203	SV	1	BSU-48A BEAM STEERING UNIT
1333-500-100		SV	1	DIPLEXER
134338-02-01		OH	1	Vertical gyro
1343-85		NE	1	VHF ANTENNE
13477-11281		OH	1	DIR GYRO
134E0505-054		SV	1	MOUNTING TRAY
135-0350-4		NE	1	AIR SWITCH ASSY
135-0550-3		SV	2	COMPRESOR CONDENSATOR PALLET ASSY
135-0550-3		NE	2	COMPRESOR CONDENSATOR PALLET ASSY
135-0553-1		SV	1	COMP.COND PALLET EL-SSTART
135-0553-1		NE	1	COMP.COND PALLET EL-SSTART
135-1401-1		NE	3	AUX BLOWER ASSY
133ME1339.		SV	1	Pulse Generator IF66000
136286-1		SV	1	CONTROL UNIT CCU32A
13636-60921-1		SV	1	MOUNTING TRAY
137685-01	5990-00-073-1810	NE	1	SYNCHRO
13824-12-0211	TNL2000A	SV	1	GPS
13824-12-0234	TNL2000A	SV	2	GPS
138740-19	704A47330088	SV	1	HORIZONTAL SITUATION INDICATOR
1394T100-7A		OH	1	TURN COORDINATOR
1394T100-7B		AR	1	TURN COORDINATOR
1397-1		SV	1	AMP SLEW SWITCH
13F141		NS	5	RESISTOR
140100-03-01		SV	1	ATTITUDE IND
1401-020		SV	1	MONITOR
1401-1T-83		OH	1	INDICATOR AIRSPEED
1402-1T-C1		OH	1	AIRSPEED INDICATOR
1403-01-11		SV	1	DATA TRANSFER UNIT
141063-2	BAU-35A	SV	1	BEACON, AIRFOIL UNIT
14141-0203-	GNSX	SV	2	GNSX
141987-0001		SV	1	A-C-U-
1426-1AE-A1		OH	1	AIRSPEED IND
1426-37A-A6		OH	1	AIRSPEED IND (MPH)
1426-6M-817		OH	1	AIRSPEED INDICATOR
143236-0420	BAU-35A	SV	1	BEACON, AIRFOIL UNIT
14347-0101-06	GNSX	SV	2	GNSX CDU
1445-1-1	20001-004	SV	2	TCC AUDIOFILE
145-0174-1		SV	2	COCKPIT BLOWER ASSY
145-0250-1		NE	1	COCKPIT BLOWER ASSY
1453PGCCP		OH	1	FUEL PRESSURE SWITCH
1461-BU-8-03	E-32	SV	1	INDICATOR, TACHOMETER
147830A	MS28008-1	OH	1	INDICATOR TEMP
147831A	MS28009-1	OH	1	INDICATOR TEMP
147832A	MS28004-1	OH	1	INDICATOR TEMP
1-480710-0		NS	3	CONNECTOR
1486-1-16		SV	1	SWITCH PANEL
1486-1-20		SV	1	SWITCH PANEL
1486-1-6		SV	1	SWITCH PANEL
1486-1-7		SV	2	SWITCH PANEL
1486-1-8		SV	2	SWITCH PANEL
149-0020 003		SV	1	MOUNTING TRAY
149-015932-0001		SV	1	INSTALL KIT
1500-01-13	C5000	SV	1	AIR DATA COMPUTER
15-0007-127		SV	4	LIGHT ASSY
15-0105-1		NE	1	PANEL LIGHT
152HL2W	206-070-267-007	OH	1	TOT INDICATOR
152HL2W3		OH	2	TOT INDICATOR
153-017713-01		SV	2	FF-HANDSET
153-168		NE	2	FF PROTECTION
1534-1-8		SV	1	AIRSHOW PANEL



1534-1-9		SV	1	AIRSHOW PANEL
153510-000017	STRATUS ESG	SV	1	ADS-B OUT TRANSPONDER
1550184-503		SV	1	ANNC COUPLER UNIT
155-02578-0001	TS10B	NS	1	HARNES
155-02581-0000	TS10B	NS	1	APPLE BOARD CABLE
156-01	EDO AIRE	SV	1	ADF CONTROL HEAD
1564T100-5		SV	1	SERVOMOTOR
156F115B0084S180		NS	3	TUBE
156M1		SV	1	ADF CTL
1575-1-1	1305-58-2	SV	1	32 I/O ADAPTER MODULE
1575-4		SV	1	GPS AMP
1589-4		SV	1	VOLTAGE REGULATOR
15989-005		NS	1	ANN- DCPL- FD- "OFF"
15989-006		NS	1	ANN- CYCLIC POSITION CTR
159AV10001EQ5		SV	1	TURBINE GAS TEMP
159AV10001TEQ5		SV	1	TURBINE GAS TEMP
15E02-1	222-325-013-102	SV	1	VALVE
15PX308		AR	1	GUARD RCVR
1601B-DC28		SV	1	COFFEE MAKER
1602-01-03	CVR30A	SV	1	COCKPIT VOICE RECORDER
1602-02-03		OH	1	CVR-30A Cockpit voice recorder
160305	160305	OH	1	ALTIMETER
1612-02		SV	1	CVR CONTROL
1616-050-02A		SV	1	SKY CONNECT
1616-050-03A		SV	1	SKY CONNECT
1616-055-00		SV	2	SKY CONNECT CONTROL HEAD
1616-055-10		SV	2	SKY CONNECT CONTROL HEAD
1616-450-01A		SV	1	SKY CONNECT TRANSEWER
162-1		NS	1	VIDEO ISO TRANS 75 OHM
16248-11		SV	5	GPS ANTENNA
162LC601A		SV	1	INDICATOR, TEMP ELEC
164BT-2		OH	1	ROTARY ACTUATOR
164ZS01Y		SV	1	AUDIO WARNING
1656A1100-01		SV	1	TRAILING ARM LH
1656A2100-02		SV	1	TRAILING ARM, RH
16650-1142		OH	1	ALTIMETER
16650-1172		OH	1	ALTIMETER
16722-007	13986-001	NS	30	ANNUNCIATOR
168SR101		SV	3	SWITCHING RELAY
16HM1-1		NE	8	MICROSWTICH ROTOR BRAKE
170-431-02-100		SV	1	COMM CONTROL
17-100		SV	1	COMPASS
1713121-501		SV	1	RADAR PHASED ARRAY
1713122-501		SV	1	BASE
171-431-02-000		SV	1	COMM CONTROL
171-431-45-100		SV	1	COMM CONTROL
1716803-502		SV	1	ANTENNA ARRAY
171BS101-1		SV	2	AMPSS00
172837-001		SV	10	RELAY
17343-62-340		NE	1	FIRE DETECTOR
173819-001		SV	1	RELAY
174213-02-01		SV	5	FLIGHT DATA RECORDER
1742500-09		NE	9	FILTER ASSY
1742500-09		NE	2	OIL FILTER
1742510-05		NE	1	FILTER ELEMENT
17479-549		NS	1	ANNUNCIATOR
175096-101		SV	1	RELAY
1762A020000		OH	1	DRAIN KIT
17680-01		NE	1	CONFRG MODULE
1778686-655		SV	1	C6 INDICATOR
1783180-122		SV	1	INTEGRATED INST RACK
18013B-011		OH	1	VSI
18013B-012		OH	1	VSI
1801-CH		OH	10	INDICATOR SIMPLE
180806-007		SV	1	AMP ASSY
1810-010		SV	1	ROSEN MONITOR
18-1830-2		SV	1	INVERTER
1811D605		NE	1	PILOT STATIC TEST SET
18152-1		SV	1	MODULE
18152-309		SV	1	IND
18152-907	422-18152-907	SV	1	MODULE
18152-983		SV	1	MODULE
18-1814	96774-18-1814	OH	1	TORQUE PRESSURE IND
18-1842-7	412-075-205-101	OH	1	TORQUE PRESSURE TRANSMITTER
18-2021	MS28010-1	OH	1	IND, PRESS, MULTIPURPOSE
18253G-19		NE	1	ADAPTER HEADSET

183-0251-000	183-0251-00	NE	5	CAPACITOR
18-380011	198428	OH	1	FUEL QTY GAGE
18422-0		AR	1	THERMOSWITCH HEATER CONTROL
184-7668-000		NE	45	CAPACITOR
18650-000-04	704444242008	SV	1	DAMPER TAIL SKID
1865-40		SV	3	FILTER DIFF- PRESSURE SWITCH
18790-500		NE	1	FLIR HARNESS
188-3305-901		SV	2	EMERGENCY LIGHTS BOX
18-947-1		SV	3	INVERTER
189-740-2		SV	1	INVERTER
189-740-2		NE	3	INVERTER
18-994		SV	3	ALC INVERTER
18-996		SV	4	ALC INVERTER
19095-100-00	19095-100-00B	SV	1	DRAG STRUT JACK, NLG
19100-0101		SV	1	GPU
1916400-7		NE	2	SHUT OFF VALVE
1918312-1		NE	1	TEMPERATURE SENSOR
19210-00-04		SV	1	CRASHWORTHY SEAT
192743-0001		AR	1	PSU SPEAKER
1936AA		SV	1	TRANSMITTER
1-936-BA		SV	1	TRANSMITTER
1945F200	1945F200W01	SV	1	ACTUATOR, MLG
1945G200A01		SV	1	MAIN LANDING GEAR L/H
1957EG		OH	1	INDICATOR DOUBLE
1957EH	3160.S.73.47.940	OH	6	INDICATOR DOUBLE
195-83072-1		NE	1	DEFLECTOR, FWD, WINDSHIELD
1962-26-1		SV	1	SWITCH PANEL
1-99302		NS	2	LINING
19A2593	206-073-913-1	SV	2	BLOWER
19A2696	222-325-009-101	SV	1	BLOWER
19E143-1A		NE	2	BENDIX SHAFT
1C27-10		AR	1	PUMP FUEL CARTRIDGE
1C27-11		SV	1	FUEL BOOST PUMP
1C64-7		SV	4	PUMP
1D1917		OH	1	INDICATOR
1G-1272		SV	1	AUDIO GENERATOR
1S14980-1		SV	1	FCU PUMP & MOTOR
1U262-001-10		AR	1	DIRECTIONAL GYRO
1U262-001-39	4000B39	OH	1	GYRO
1U262-001-7		OH	1	DIRECTIONAL GYRO
1X25166857	EUROCOPTER	SV	1	DRIFT
1X25170023	EUROCOPTER	SV	1	DRIFT
1X31711W5	EUROCOPTER	SV	2	MOUNTING TOOL
1X36166806	EUROCOPTER	SV	1	SOCKET WRENCH
1X53166817	EUROCOPTER	SV	1	PULLER EXTRACTOR
1X53170049	EUROCOPTER	SV	1	PULLER EXTRACTOR
1X53174739	EUROCOPTER	SV	1	DRIFT
1X54176702	EUROCOPTER	SV	1	DRIFT
200000-1		OH	1	TANK RH LONGI CRASHWORTHY
2000029-61		SV	2	SECURITY BELT
2000-106	SRC-2000	SV	1	SPECIFIC RANGE COMPUTER
200-0452-00	200-0452-00-R12	NS	1	MODULE
200-05330-0002		SV	1	EFIS AP FD PANEL
200-071-003	76450-01078-102	OH	1	FUEL PRESSURE INDICATOR
200-08777-0010		FN	1	SONY REPLACEMENT
2000-902	SRC-2000	SV	1	SPECIFIC RANGE COMPUTER
2000-902-2G	SRC-2000	SV	1	SPECIFIC RANGE COMPUTER
2001-053-01-0	A0089-100N	SV	1	DISPLAY UNIT
20-0158-1R		NE	1	EYE BROW LIGHT
20018-11308	20020-11365	OH	1	AIR SPEED INDICATOR
20020-11190		OH	1	AIR SPEED INDICATOR
20020-11212	222-375-027-107	OH	1	AIR SPEED INDICATOR
20020-11293		OH	5	AIR SPEED INDICATOR
20020-11293E034-438		OH	1	AIR SPEED INDICATOR
20020-11327		OH	1	AIR SPEED INDICATOR
20020-11388	222-375-027-113	OH	1	INDICATOR, AIRSPEED, PITOT, STATIC
200-2752-03	200-02752-0003	NS	1	VCO
200-2752-04	200-02752-0004	NS	1	VCO
200-4273-00		AR	1	RADAR ADAPTER
200-92704-101	MT-851	AR	1	MOUNT ASSY
2005GL115Q-2		OH	1	STARTER GENERATOR
2005GL129Q		OH	1	STARTER GENERATOR
20110-1-03	21105-2-03	SV	1	NDB-2 NAV DATA BANK
20230M1		SV	3	CONTROL UNIT
203-021-003	76450-01078-103	OH	1	FUEL QTY IND
203-022-005	76450-01078-101	OH	1	ENGINE OIL TEMP AND PRESS IND

203-022-008	76450-01078-112	OH	1	TRANS OIL TEMP IND
203-022-009	76450-01078-126	OH	2	OIL TEMP AND PRESS IND
203-022-012		OH	1	INDICATOR OIL PRESS & TEMP
203-022-013	76450-00906-102	OH	5	INDICATOR OIL PRESS & TEMP
203-022-016	76450-00907-103	OH	2	INDICATOR, OIL TEMP & PRESSURE
203-023-003	76450-01078-104	OH	1	DUAL HYD- PRESS-IND
20322-501		SV	2	CO-PILOT ANNUN CPLR
2035482-0701	5985-01-109-8878	NS	10	ISOLATOR,RADIO FREQUENCY
2037923-0503	5975-01-307-3609	OH	1	FRONT PANEL
2038070-0501	5998-01-107-4863	SV	1	ROLL AMP ASSY
2038992-0501	5841-01-089-2745	OH	1	RADAR SET SUBASSEMBLY
2039016-0501	5996-01-088-6358	OH	1	AMPLIFIER, RADIO FREQ
2039272-0502	5841-01-340-3771	OH	1	RADAR SET SUBASSEMBLY
2039273-0501	5841-01-088-3812	OH	3	POWER SUPPLY
204-001-264-1	204-001-264-001	NS	1	BOX ASSY
204-010-937-007	SGT520-6	SV	2	DAMPER ASSY
204-011-164-001		NS	2	STOP
204-011-174-1		NS	1	SPACER
204-011-179-1	5340-00-157-7846	NE	1	CLEVIS, ROD END
204-030-846-001		NS	1	SWWEL ASSY
204-030-893-91		NS	4	BRACKET
204-032-743-1		NS	1	PLASTIC
204-032-743-1		NS	1	PLASTIC
204-040-219-001		NS	1	PACKING
204-040-760-3	204-040-760-003	OH	1	OIL FILTER
204-040-801-1	204-040-801-001	OH	1	GEARBOX
204-040-929-2	204-040-929-002	SV	1	COVER AND LIFT PLATE
204-060-005	76450-00904-105	OH	2	TURBINE INLET TEMP IND
204-060-006	76450-00904-106	OH	2	TURBINE INLET TEMP IND
204-060-663-003	204-060-663-3	NE	18	SWTCH ASSY, FUEL FL
2040918-0501	7021-01-269-3244	OH	1	COMPUTER,DIGITAL
2041441-0101	5975-01-192-0723	OH	1	MOUNTING BASE
2041441-0102	5975-01-091-1877	SV	2	MOUNTING BASE
2041442-0101	5975-010911876	AR	1	MOUNTING BASE
2041442-0102		NS	1	MOUNTING BASE
204A-1A1A	MS28008-1	OH	1	INDICATOR TEMP
204A2F1A	MS28004-1	OH	1	INDICATOR TEMP CYL HEAD
205-001-916-1	205-001-916-001	NS	2	BELLCRANK ASSY
205-032-161-006		NS	1	BRACKET
205-032-616-006		NS	1	BRACKET
205-040-229-001		SV	4	GEAR
205-050-125-1	205-050-125-001	OH	3	FIXED FLOAT DAMPER
205-070-283-003	8D181CDG	OH	1	TACH N1
205-070-710-1	205-070-710-001	NS	1	LEG ASSY
205-070-729-5	205-070-729-005	NS	1	CUPPORT BRACKET
205-072-708-001		NS	1	TUBE ASSY
205-075-158-001	205-075-158-1	OH	1	OIL PRESSURE INDICATOR
205-961-383-21		NE	1	CABLE ASSY
205RQUFA1		SV	1	RATE SENSOR
206-001-400-9		AR	3	LEVER ASSY
206-032-445-007		NS	1	SUPPORT ASSY
206-040-407-7	206-040-407-007	OH	1	TAIL ROTOR OUTPUT SHAFT
206-050-141-024		NS	8	AXLE ASSY
206-062-627-003	22A649	SV	1	TACH GENERATOR
206-062-831-1		NS	1	LINE ASSY
206-070-266-9	6501-3008	OH	1	N1 INDICATOR
206-073-913-1	19A2593	SV	1	BLOWER
206-075-190-001		OH	1	TOT INDICATOR
206-075-676-103	124-1014	OH	1	INDICATOR, FUEL PRESS & LOAD
206-075-681-117	DL401-15	OH	1	DUAL TACH IND
206-075-681-123	DL401-18	OH	1	DUAL TACH IND
206-075-711-001	6620-01-034-0883	OH	1	INDICATOR, TORQUEMETER
206-075-711-1	6620-01-034-0883	OH	1	INDICATOR, TORQUEMETER
206-076-037-001	206-076-037-1	OH	1	VALVE
206-360-501-101	10687D	AR	1	OIL COOLER
206-706-201-021		NS	1	NULL
2068609-0701		NE	1	DUMMY LOAD
2068623-0701		NE	1	WAVEGUIDE
206-951-383-011K		NS	2	CABLE ASSY
206-961-383-21		NS	1	CABLE ASSY
2070499-0101		SV	1	MOUNTING TRAY
2070499-0102		SV	1	MOUNTING TRAY
2070499-0104	MBA-1L	SV	1	MOUNTING TRAY
2070965-0101	5841-01-089-1022	SV	1	RADAR CONTROL
2087772-7304	CV473-190	SV	1	ANTENNA COUPLER
209-062-005-001	209-062-005-001WTD2	SV	1	INSPECTION TOOL

209-062-104-001		SV	1	TUBE ASSY
209-063-010-1		NE	5	GASKET HEATING SYSTEM
209-076-021-013	209-076-021-13	OH	1	CYLINDER ASSY HYD
2090JFA		OH	1	PUMP FUEL BOOSTER
209-175-301-001		SV	1	VOLTAGE
20919-031		NS	1	INDICATOR
20919-033		NS	1	INDICATOR
20919-034		NS	1	INDICATOR
20919-035		NS	1	INDICATOR
20919-036		NS	1	INDICATOR
20919-037		NS	1	INDICATOR
20919-039		NS	1	INDICATOR
20919-042		NS	1	INDICATOR
20VR4D		SV	1	BATTERY PACK
2100284-4		SV	1	NAV COMPUTER UNIT
2100-8006-00		NS	1	MOUNTING TRAY
2103401-2		SV	1	SOURCE
2107-B-6		OH	1	RMI
2107D-B-6		SV	1	RMI
2116-40-1116	UNS-1L	SV	1	FMS
2117404-5	SERIES 4	OH	1	ELECTRONIC CONTROL UNIT
2118478-1		SV	2	CONTROLLER, ELECTRONIC UNIT
212-030-044-001	212-030-044-1	NS	1	COVER
212-030-044-001		NS	1	COVER
212-070-108-001	8D131AAJ	OH	1	INDICATOR TACHOMETER
212-070-116-003	124-972A	OH	1	OIL TEMP & PRESS IND
212-070-116-009	124-045	OH	1	OIL TEMP AND PRESS IND
212-070-116-3	124-972A	OH	1	OIL TEMP & PRESS IND
212-070-116-9	124-045	OH	1	OIL TEMP AND PRESS IND
212-070-160-021	18-1838-21	OH	1	INDICATOR, DUAL TORQUE
212-073-912-1	30756-1	SV	1	SQUIB VALVE
212-075-523-101		SV	1	COMM PANEL
212-6000-09-1		NE	8	GASKET
212CW		SV	1	DRY AIR PUMP
21311MI		SV	1	INTERFACE UNIT
2133VENT		NE	2	VENT ASSY
2135228	213723	SV	1	ENGINE SYNC UNIT
213545A	213723	SV	1	ENGINE SYNC UNIT
213798C		SV	1	GOVERNOR COM
2138-50000-106	76900-01880-106	SV	2	AMPLIFIER
214-001-347-005	67A370	SV	1	ACTUATOR
214-001-347-007		SV	1	ROTARY ACTUATOR
214-001-347-101		OH	1	ACTUATOR
214-040-013-115	214-040-020-103	OH	1	GEAR BOX ASSY, COMB
214C50-60		SV	1	SWITCH, PRESSURE
215371-0		NE	1	DIGITAL PRESSURE GAUGE
217596-0		SV	1	FWD LEFT E.F.S. ASSY
217597-0		SV	1	FWD RIGHT E.F.S. ASSY
217598-0		OH	1	AFT LEFT E.F.S. ASSY
217599-0		OH	1	AFT RIGHT E.F.S. ASSY
217-601933-215	CMA-1100	NE	1	I/O CABLE ASSY
21867-1		OH	1	GENERATOR
2193-10C		NS	2	SERRATED DISC
21867-1A	21867-1	SV	1	CONTROL UNIT, GEN, AC
220-352864-000		NE	1	LAMP
221258C050042L		NS	4	SCREW
221-3992-803		NS	1	AIR ASSY
22-1863-048		SV	1	FAILURE WARNING PANEL
22-1863-089	704447723068	SV	1	FAILURE WARNING PANEL
22-1863-089-REP	704447723068	SV	1	FAILURE WARNING PANEL
222-001-072-105		OH	1	SPR CART ASSY
222-001-072-109		OH	2	SPR CART ASSY
222-005-001-101		OH	1	ACTUATOR
222-005-030-101		OH	1	RPM LIMIT DETECTOR
222-005-030-111		OH	2	RPM LIMIT DETECTOR
222-025-182-001		NS	2	SEAL NOSE SKIN
222-031-308-033		NS	1	PANEL
222-036-017-001		NS	2	SHM
222-065-562-133		NS	1	SEAL
222-075-132-101		SV	1	PANEL
222-366-684-103		SV	1	LOWER PROBE
222-366-684-103		AR	1	LOWER PROBE
222-375-010-107	80-0500-1	SV	1	ANNUNCIATOR PANEL
222-375-010-131	80-0500-17	SV	1	ANNUNCIATOR PANEL
222-375-020-103	HA122070110	OH	1	TRIPLE TORQUE IND
222-375-021-101	78200000-01	OH	1	TRIPLE TORQUE IND

222-375-027-111	20020-11365	OH	2	AIRSPD IND
222-375-033-101	4300-8170-1L	OH	3	ALTITUDE IND
222-375-071-105	78300000-05	OH	1	INDICATOR, TRIPLE TORQUE
222-375-077-113		SV	1	PRESSURE TRANSDUCER
222-382-002-103	143000-104	SV	1	DIRECTIONAL SERVO
22251BC050060L		NE	20	SCREW
22252BC050011L		NS	10	BOLT
22-260-014		OH	1	MANIFOLD PRESS IND
22-260-042-1A		OH	2	MANIFOLD PRESS IND
22-280	22-280-015A	OH	1	TACHOMETER INDICATOR
222-899-604-101		OH	1	PA CONTROL
222-899-604-113		SV	1	PA CONTROLLER
2231321-4		SV	1	UNIT-INTEGRAT FRD/HUMS
2231896-2		SV	1	PANEL-CONTROL PANEL
2241500-4A		SV	2	MDAU
225398-6		NS	1	CONNECTOR
225973-4		NS	1	CONNECTOR
2260-1001-1	209-075-326-1	OH	1	DETECTOR, RPM LIMIT
22-697-06-1		OH	1	AIRSPD INDICATOR
22885-21-4174		SV	2	WING LIGHT
22885-22-4174		SV	2	WING LIGHT
229-0324-010		SV	1	VERTICAL ACCELEROMETER
229-0324-010-M		SV	1	VERTICAL ACCELEROMETER
229-0324-020		SV	1	ACCELEROMETER
229-0324-020-M	SA111128-020	SV	1	ACCELEROMETER
229-1001-000	229-1001-00	NE	1	MOTOR CONTROL
229-3044-040		NS	1	SYNCHO
229-6026-030		NE	1	SYNCHO
22A703		SV	1	GENERATOR
230-0257-00	6105-00-578-7304	NE	1	MOTOR DC
2302KA/CP/1		SV	1	TACH GENERATOR
23032-022		SV	1	STARTER GENERATOR
23032-048		NE	2	STARTER GENERATOR
23032-048		SV	5	STARTER GENERATOR
23032-049		NE	2	STARTER GENERATOR
23032-049		SV	2	STARTER GENERATOR
23032-062		NE	1	STARTER GENERATOR
23032-062		SV	4	STARTER GENERATOR
23032-2711		NS	4	BACK PLATE
2306-557-00-10	704A37-650-100	OH	2	FUEL QTY IND
23081-001		NE	2	STARTER GENERATOR
23081-043		NE	1	STARTER GENERATOR
23081-043		OH	3	STARTER GENERATOR
23081-043		AR	3	STARTER GENERATOR
23081-303		NE	1	SUPPORT ASSY BEARING AND BRUSH
2309-355-00-11		SV	1	AMMETER, DC
2311M-205-2		NE	1	MOTOR ASSY ELECTRIC
23120-25		SV	1	TESTER
2312M41-12		NE	1	CONVERTER
2312M41-12		NE	2	CONVERTER
2312M-41-13		SV	1	CONVERTER
2312M-41-20		NE	1	CONVERTER
2313M-427-1	02313M-427-1	AR	1	WIPER MOTOR ASSY
2313M-427-1	222-625-001-101	SV	1	WIPER MOTOR ASSY
2315M116-1		NE	1	WIPER BLADE ASSY
2315M116-1		NE	2	WIPER BLADE ASSY
2315M6-1		NE	1	BLADE
2315M-75-2		NE	1	BLADE
233-1-2		SV	1	CURRENT SENSOR
233209-03		SV	1	FILTER
2338-50		AR	1	ANTENNA DME/TRANS
2381-05-L-18-IG-C		NS	1	EYEBROW
2383-05-L-18-IG-C		SV	2	EYEBROW
2393-05-L-18-IG-C		NS	1	EYEBROW
23932-005	570-23932-005	OH	1	ALTMETER
23932-101	570-23932-101	OH	1	ALTMETER
23932-901	570-23932-901	OH	2	ALTMETER
2400-25-4-4-2		AR	1	PULSE/LITE CONTROL UNIT
24043GR79		NE	10	LINING ROTOR BRAKE ASSY
241-0570-010		NE	3	FILTER,LP
2420C1		NE	2	CONTROL UNIT
24293-1		SV	1	ENGINE FIRE SHUT OFF HANDLE
24353-0001		NE	1	CONNECTOR
244-602183-000		SV	1	POWER INTERFACE UNIT
245-604128-000	CMA-1100	SV	2	PILOT VIEW
245-604129-000	CMA-1100	SV	2	PILOT VIEW

245-604170-008	CMA-1100	SV	2	EMU
245-604244-215	CMA-1100	SV	2	EFB MOUNT
24640QAE0101		NE	1	FUEL JETTISON ASSY
24640QAE0101		SV	5	FUEL JETTISON ASSY
249-1398-000		NE	2	CONNECTOR ASSY
24HP883-101		NS	2	SHROUD PAD BASE
250003-1		SV	2	DC POWER SUPPLY
2500979-1		NS	6	CONTACT
25011-00312		SV	2	CVR CONTROL UNIT
25011-192H101A		SV	1	LAV SWITCH PANEL
25012-029H402A	2501-2-029	SV	1	SWITCH PANEL
25012-030H402A		SV	1	PANEL
25012-252/H101A	2501-2-252	SV	1	AIRSHOW MODULE
25020-1157	704A47-113-102	SV	1	AIRSPEED INDICATOR
25020-9601		OH	1	AIRSPEED IND
2504094-5		NE	2	COIL
2504-3002A-040M	6610-01-214-5884	OH	1	COMPUTER UNIT
2504-3002A-04ET		OH	1	COMPUTER UNIT
2504-600-004A		NS	1	TEMP PROB MOUNT
2504-900ET		OH	1	TRANSDUCER ASSY
25100-004	540-25100-004	SV	1	ALTITUDE ALERTER
25174A-25A		SV	1	ANGLE OF ATTACK TRANSDUCER
2524644-3		SV	1	FUEL CONTROL
2524667-12		SV	1	POWER TRUB GOVERNOR
2524667-4		SV	1	GOVERNOR
2524738-30		AR	1	RR250 FUEL CONTROL
2524738-30		OH	1	RR250 FUEL CONTROL
2524843-1		SV	1	GOVERNOR CONTROL
2524843-1A		SV	1	GOVERNOR CONTROL
2524843-3		SV	1	N2 REGLER
253-E0873-00		SV	1	S ROTOR SPEED ENCODER
25486-00426		NE	2	RELAY ARMATURE
256-1		SV	3	AIRSHOW CURRENT SENSOR
257.011-001		NE	1	RN6 EURONAV IV DIGITAL MAP
257.01-15G		NE	1	RN5-2.9 MAP-COMPUTER 2 RS422
257.012-002		NE	1	RN6-CM EURONAV DIG MAP
25850-219		OH	1	MAX ALLOW A/S IND
2586257-1		SV	6	COMPENSATOR
2586689-902	SP-50A	SV	1	AP CONTROLLER
2587193-42		OH	1	GYRO
2587193-43		OH	1	GYRO
2587400-844		SV	1	AIR DATA COMPUTER
2587516-8		SV	1	ELEC ASSY
2588302-4		OH	1	GYRO DIRECTIONAL
2588767-901		SV	1	RADIO DIR IND
2590004-904	SP50G	SV	1	ALT PRESELECT COUPLER
2591201-922	CL-201	SV	2	COMPASS COUPLER
2591202-902		SV	1	COMPASS CONTROLLER
2591411-444	HZ444	OH	2	HORIZON FLIGHT DIRECTOR
2591714-14		SV	1	ALT COMPUTER
2591715-4		SV	1	AIRSPEED COMPUTER
2593342-932		SV	1	COMPUTER
2593342-932		AR	1	COMPUTER
2593342-976		SV	1	COMPUTER
2593342-976		AR	1	COMPUTER
2594775-200		SV	1	ALTITUDE CONTROL
25ARM300-20E20		NE	1	INSULATOR
25ET1-S		NE	1	SWITCH
2-5X15-2186		NS	1	ORING
26000-30-07		AR	1	Secondary Flight Display
2600-600-0000		SV	1	TAS/PLUS COMPUTER UNIT
2600-700-0000		SV	2	TAS/PLUS COMPUTER UNIT
260-2351-01		OH	1	IND, DUAL FUEL PRESSURE
262-2348-010	KW204S	NE	2	DIGITAL DISPLAY IND
26400-102		SV	1	CONVERTER
2641011-5		AR	1	AXLE ASSY
2641011-5		NS	1	AXLE ASSY
265-100A		NE	5	RELAY
266-7566-010		NE	4	SWITCH
267-937-005		OH	1	IND, FUEL FLOW
269A1278		NS	5	SEAL
269A2063		NS	4	OIL SEALS
269A2335		NS	1	DAMPER PLATE
269A4714		AR	1	PANEL
269A5050-44P		NS	4	BEARING
269A5463		NS	4	CLAMP

269A5492-3		NS	6	SHM
269A6053-3		NS	1	BUMPER
26ET32-T		NS	1	SWITCH
27000-01-20	9030-3046	NS	1	AIR DATA UNIT
2700-004A22		SV	1	COCKPIT DISPLAY
27005-00-08		SV	2	AIR DATA DISPLAY UNIT
2700-500-A2A00BJDGF		NS	1	DIGITAL CABIN DISPLAY
270-2196-010	590B2	OH	1	AIRSPEED SENSOR
270-2878-070	G7632-108	OH	2	CTL32G NAV CONTROL
270-839	839	SV	2	MICRO TOUCH PANELS
2718-00		NE	1	AEROTHERM AIR TEMP GAGE
273AA-205	311601	NS	1	COAX CABLE ASSY
273AA-206	311601	NS	1	COAX CABLE ASSY
273AA-207	311601	NS	1	COAX CABLE ASSY
273AA-208	311601	NS	2	COAX CABLE ASSY
273AA-220	311601	NS	1	COAX CABLE ASSY
273AA-221	311601	NS	1	COAX CABLE ASSY
273AA-222	311601	NS	1	COAX CABLE ASSY
273AA-223	311601	NS	1	COAX CABLE ASSY
277200-002		AR	1	COURSE DEVIATION INDICATOR
277200-214		SV	1	COURSE DEVIATION IND
2797-4		SV	4	AQUAFIX 406 GPS
28-1750-18	A141938	NS	2	RING
28260-004	930-28260-004	SV	1	DISPLAY CONTROLLER
282K2770-051		NE	1	CHCHECK VALVE JET PUMP
2850-1		NS	1	SWITCH
28711-902	930-28260-004	SV	1	DISPLAY CONTROLLER
2891ESR		OH	2	DIRECTIONAL GYRO
29007-007	521-29007-007	SV	1	ALTIMETER
29007-204	521-29007-204	SV	1	ALTIMETER
29-1000		OH	2	OIL TEMP IND
2915-12-341-8028	300991124	SV	1	GOVERNOR
29264-001	CA-154-3A	SV	1	EMERGENCY BATTERY SUPPLY
29400-212		SV	2	RAD ALT CONVERTER
29400-4117		SV	1	RAD BAR CONVERTER
29400-4217		SV	1	RAD BAR CONVERTER
29400-8101		SV	2	RAD BAR CONVERTER
29400-8112		SV	1	RAD BAR CONVERTER
2-95X23-47-61D6		NS	1	ORING
2A350-1D1		SV	1	STATIC INVERTER
2C12-1	4320-01-483-9169	OH	1	FUEL PUMP
2LA001625-04WS		NE	2	TAIL LIGHT
2LA455359-00		NE	1	LED NAVIGATION LIGHT GREEN
2N3637		NE	3	TRANSISTOR
2N4925	5961-00-479-1735	NE	5	TRANSISTOR
2N6764		NE	5	TRANSISTOR
2N6782		NE	4	TRANSISTOR
2N6788		NE	4	TRANSISTOR
252C21		NS	1	RELAY
3001-01-100		NE	1	Accelerometer single axis
3001-01-101-4		SV	1	SINGLE AXIS ACCEL
300-2184-0000	300-2184-000	SV	1	RT30 GUARD RECEIVER
300-2202-000		SV	1	MOUNTING TRAY
300-2241-000		SV	1	GUARD RECEIVER WITH CRYSTAL
300-2265-000	H4	SV	4	RET CORD
30050-0707-1121	GNSX	AR	1	GNSX RPU
30050-0909-1121	GNSX	SV	1	GNSX RPU
30-0504-23		NE	1	ANTI COLL STR LIGHT
30-120-16		NS	185	PIN
3014C		SV	2	POWER UNIT
30-1994-1		SV	1	LIGHT, NAV, STROBE
30230-1165	222-375-030-001	OH	2	INDICATOR, VERTICAL VELOCITY
30-231-31		SV	1	SMOKE DETECTOR
30-2478-1		SV	2	FWD POSITION LIGHT
30-2478-2		SV	2	FWD POSITION LIGHT
303-006-005	76450-01078-123	OH	2	DUAL TORQUE INDICATOR
303-006-006	76450-01078-125	OH	2	DUAL TORQUE INDICATOR
30-303A		OH	1	CONTROL AMP FIRE DETECT
30-303AT		SV	1	AMPLIFIER
303990-02	TC-M	NS	1	ALTIMETER
3043574-01		NE	2	FUEL FILTER KIT
3044180-01		NE	1	FUEL AIR BLAST
3045819-01		NE	1	KIT FUEL FILTER CHANGED
3050562-01		SV	4	ACCUMULATOR, ECOLOGY SYSTEM
30510-133	422-30510-133	SV	1	AIR DATA COMPUTER
305154-00		AR	1	SAE5-35

3054015-3		OH	1	AUX SERVO PRESS REDUCER
30542-102		SV	1	CABIN DISPLAY PANEL
3057-147		OH	1	TORQUE IND
3057-148	704A47621092	OH	1	TORQUE INDICATOR
3057-148-1	704A47621094	OH	1	TORQUE INDICATOR
3057-148-2		OH	1	TORQUE IND
3057-149-6	704A47621120	OH	1	TORQUE IND
3057-165-2		OH	1	TORQUE INDICATOR
3057-169-2		OH	1	TORQUE INDICATOR
3057-182-1	105-957411	OH	1	DOUBLE TORQUE INDICATOR
3057-3-10-143		SV	1	TORQUEMETER
3057-3-134		OH	1	PRESSURE INDICATOR
3057-3-136-6	704A47621128	SV	1	TORQUEMETER INDICATOR
3059026-01		SV	1	CARBON SEAL-CLUTCH DRIVE
306211P02		SV	1	INLET PRESSURE SENSOR
306-4-1200		NS	5	10FT HOSE
306908		SV	1	WINSLOW AEROFILTER
3070-00-01		SV	1	UNIVISION COMPUTER
30702-2		SV	1	MOUSE KEYBOARD INT EXT
3076214-01		OH	1	HEATER, OIL TO FUEL
3080-201-1		SV	1	INDICATOR
3080-201-2	117-94069-1	OH	2	DUAL TORQUE INDICATOR
3080-201-3	117-940711	OH	1	TORQUE INDICATOR
3080-201-4	117-902121	OH	1	TORQUE INDICATOR
30-97		SV	1	BRAKE ASSY
30E01-1B		OH	1	GENERATOR
30Y1000		OH	1	TACHOMETER INDICATOR
310-007-003	76450-00902-103	OH	1	DUAL TORQUE IND
310155-2		SV	3	AUDIO JACK
310155-2		NS	1	AUDIO JACK
3121-748		FN	8	INNER SLEEVE
3121-748		NE	8	SLEEVE
31230-1120		OH	2	VSI
31300-0101-0111	C5000	SV	1	CONTROL UNIT
31300-0101-1200	C5000	SV	1	CONTROL UNIT
3130S35-60-010		NS	1	SUPPORT LH
3130S-68-00-907		NS	2	BEARING
3130S-88-10-020-1		NS	2	CABLE
31480-7123	575-31480-7123	OH	1	COMBINED SPEED IND
315A-88-00-0101		NS	3	CABLE
3160S12-20-960		NS	2	SEAL
3160S33-20-017		NS	1	THREADED PIN
3160S68-10-000-4		SV	2	HOUSING
3160S68-10-001		SV	2	HOUSING
3160S86-02-000-1		OH	1	PEDAL ASSY
318-00140		SV	1	TRANSMITTER
3192936-7		NE	60	STUD
32005-023		OH	1	TACH GENERATOR
320-1060-000	030-24478-0001	NE	7	COAX CONNECTOR
3202312-AB077		NE	2	FLUR HARNESS
3202312KAB240		NE	2	FLUR HARNESS
3202313KAD		NE	2	FLUR KIT
3203487-1	3203487-1K240	NE	1	FLUR KIT
3203487-1K240		NE	3	FLUR KIT
32-1012		SV	1	RATE OF CLIMB INDICATOR
32120-001		SV	1	COFFEE MAKER G280
3230008-3	3000U	SV	1	ALTITUDE SERIALIZER
324700M00		SV	1	DAMPER, ROLL
324900M03		SV	1	DAMPER, YAW
324AG64		SV	1	AFT FLOAT PACK ASSY PORT
3252013-0601		OH	1	ALTIMETER, ENCODER
326A25-30		SV	1	ELECTRO VALVE
32979-001		SV	1	ALT COMPUTER
33075-541	575-33075-541	OH	1	MACH AIRSPEED IND
330A98-3532-00		SV	1	WRENCH
331-0015-292		NS	1	COIN KIT
331-0025-292		NS	1	COIN KIT
3310071-01		NE	1	SEAL FACE
3311724-1	6220-00-576-3922	NE	4	PANEL INDICATING
3311A		SV	1	FUNCTION GENERATOR
331A		SV	1	FUNCTION GEN
332A67-4260-0051		SV	1	UNIT CONTROL 426VU
332A67-4270-0051		SV	1	AUX- ENGINE CONTROL PANEL
332A67-4270-01		SV	1	AUX- ENGINE CONTROL PANEL
332A67-4271-00AA		SV	1	AUXILIARY CONTROL PANEL
332C-1		OH	1	DUAL RMI



332P61-6512-09		SV	1	AVIONICS SHELF
3357-9209		NS	1	JUNCTION SHELL
33776-0002-044		SV	1	ACTUATOR FITTING
33776-44788-041		SV	1	UNIT, RADAR ALTIMETER
33776-57574-042	76286-33776-57574-042	SV	4	S76 HEADLINERS
33776-66142		NE	4	RAD ALT KIT
33776-66143-041		NE	12	PLATE ASSY
33984-002	585-33984-002	SV	1	FUEL TANK TEMP C
34-0428020-65		NS	1	LAMP
34100-001	635-34100-001	SV	1	AIR DATA CONVERTER
34170-1X		SV	1	BAGGAGE LIGHT
341-93-3308-00		SV	1	TOOLING
341A31-4900-00		SV	1	BEARING BALL
341A41525400		SV	1	FILLET LEG LH FWD
34401-30A22-1	6620-00-067-4946	OH	1	TRANSMITTER,PRESSURE
35020-11111		OH	1	YSI
350-321		OH	1	CYL TEMP IND
350-370		OH	1	TACHOMETER
350-93-3011-01	350A93-3011-01	SV	1	TOOLING
350-93-3302-01		SV	1	TOOL
350-93-3309-01	350A93-3309-01	SV	1	TOOLING
350-93-3711-00		SV	1	TOOL
350A00-0122-25		NS	2	LABEL
350A00-0138-31		SV	5	WEIGHT
350A00-0138-32		SV	1	WEIGHT
350A07-1156-71		SV	1	CONTROL PANEL
350A07-6544-75		NE	1	AFT COMMAND IMPROVEN
350A08-6011-14		SV	1	FOOTSTEP, RIGHT
350A08-6042-0151		SV	1	DOOR, RIGHT EQUIPED
350A21106905		SV	1	BEAM ASSY, FRONT
350A21-1318-02		FN	2	FASTNER
350A21-1318-02		NE	1	FASTENER
350A2114382151		NS	1	DALOT
350A25-1082-20		NE	1	SHM
350A31-1858-00		NS	1	SPACER
350A31-1872-21		FN	1	BUSHING
350A32-3152-20		NS	1	BOLT
350A32-3152-20		NS	1	BOLT
350A-34-1015-21		NS	3	SPACER
350A37000305M		SV	1	MAIN ROTOR SHAFT
350A-37-1096-20		NE	5	LOCK WASHER
350A37-1178-20		NS	1	SHM
350A55-1004-20		NS	6	SEAL
350A55-1031-04		NS	1	STRAP
350A58-1031-20		NE	4	DOG
350A73-0367-04		OH	2	ALTIMETER
350A73-1633-01		SV	1	ASSY ISO MOUNT
350A75-4005-02		SV	1	TANK,LOWER HYDRAULIC
350A76010701		SV	1	INDICATEUR EQUIPE
350A76-1013-20		NS	1	HALF-FLANGE
350A76-1070-1		OH	1	INDICATOR EQUIPE
350A93-3201-00		SV	1	TOOLING
350A93-3204-00		SV	1	EXTRACTOR
350A93-3303-01		SV	2	EXTRACTOR
350A93-3405-10		SV	1	TOOLING
350A93-3405-11		SV	1	BUSH ASSY, LOCKING
350A93-3705-20		SV	2	EXTRACTOR
351-1112-010		NE	7	IC LINEAR
351-1530-010		NE	50	MICROCIRCUIT
352-001		SV	3	AUDIO SELECTOR PANEL
352-1006-030		NE	2	TRANSISTOR
353-3740-200		NE	42	DIODE
355A32-0022-00		SV	1	BOX PRIN TRAN
355A32020002M		SV	1	PUMP OIL MGB
355A86-2008-20		FN	8	SHM
3567401-3001		SV	1	TRANSMITTER
3571251-9110	222-375-022-101	OH	2	GAD PRODUCER TACHOMETER
3571251-9119	222-375-023-103	OH	2	INDICATOR
3571442-1004		SV	1	HORIZON IND
3571442-1004		AR	1	HORIZON IND
357-7204-010		NE	2	CONNECTOR
3600338-0001		NS	1	RDR1500B PHASED ARRAY
360-27-1210		SV	1	YSI
3603247-0001		SV	1	ELECTRON TUBE
3604618-0501		SV	1	MEMORY TIMER
3604989-0501	5841-01-331-9898	NE	3	REG BOARD ASSY

3605588-0501		SV	1	MOUNTING TRAY
360A32-1152-21		SV	1	VALVE
360A32-1163-01		SV	1	SUPPORT, EQUIPPED
360A32-3526-23		SV	3	BEVEL RING
360A57-2083-222		NS	1	SPACER
3614001-4001	064-1047-00	SV	2	VC-401B VHF COMM
3614002-4003		SV	1	COMM CONTROL
3614165-5512	AA5512B	SV	1	PHASE ARRAY ANTENNA
3614258-0802		SV	2	MT-150B MOUNT
3614276-1004	CP-103A	SV	1	CONTROL
3614276-1019		FN	1	CNTR PNL 28V W/D DUAL POTS
3614330-1001	071-1335-00	SV	1	CP-103D ERS CTL PANEL
3614331-1001	066-4017-00	SV	2	NC-104B NAV CONCENTRATOR
3614331-1005	NC104B	SV	1	UNIT INTERFACE RADAR 1400
3614335-1002	SG101B	SV	1	SYMBOL GENERATOR
3614477-8601	IN861A	OH	1	RADAR INDICATOR
3614522-1019	CP-103E	SV	1	CONTROL PANEL
3614549-1008	3614549-1008-K	SV	1	RDR1500 INDICATOR MOUNT
36200-101	222-366-615-101	SV	1	VALVE
362-00135-100		SV	1	FLIGHT STATUS CONTROL
365A00-0337-DT		NS	1	DECAL
365A00-0337-DX		NS	1	DECAL
365A27326601		SV	1	ROD
365A2733050401		SV	1	COLLECTIVE PITCH STICK COPILOT
365A3117904		SV	1	MAIN ROTOR SHAFT
365A31-4706-00		SV	9	UPPER FLANGE,W SLEEVE & MASK
365A33-2167-20		NS	1	WEIGHT
365A33-2168-20		NS	5	WEIGHT
365A33614520		SV	2	CONTROL ROD
365A52-1266-20		NS	1	JOINT SEAL
365A57-3178-21		NE	1	DECAL
365A61-3416-21		NS	1	LOWER CUP
365A84-3061-20		NE	2	HOOK
365A91-2141-01		AR	1	JACK ADAPTER
365S67-8413-20		NS	1	PRESSURE TRANSMITTER
365W84-3061-20		NS	2	HOOK
366.684-921		NE	1	SERVICE SATION BOX
366-D-455-01		SV	1	ASSY-MGB FIRE DETECTOR
369A1140		NS	2	PAD
369A7951-47		NS	4	BEARING
369D21333		NS	1	STRIKER PLATE
369D27517NC		NS	8	COUPLER
37.014.20.000		NE	1	COLLER OIL AIR
37.016.20.000/3		NE	1	OIL COOLER
37.036.24.000		NE	5	VENTILATION
371-007-002		OH	2	PRESS TRANS
371-007-004		OH	1	PRESS TRANS
371-1-4		SV	5	CONTROLLER, 6 CIRCUIT
3718009-30		NS	2	SCREWLOCK
3718547-5		NS	1	BACKSHELL
375-1-3		SV	1	CONTROLLER, 5 CIRCUIT, 2 DELAY
37695-422629-811	422629-811	NS	1	HARNES
380-004		SV	1	AUDIO PANEL
380-020		SV	2	AUDIO SELECTOR PANEL
3809-066-015		NS	2	BUSHINGS
38100-0128	PA520A	SV	1	ACTUATOR
38210-3941		OH	1	VSI
38210-490		OH	1	VSI
383392-1-1		OH	1	ENGINE AIR STATER
38399-330		OH	1	AIRSPEED INDICATOR
38399-330-02	704A47113066	SV	1	INDICATOR,AIRSPEED,MPH
38399-480		OH	1	AIRSPEED INDICATOR
386500-4		OH	1	PUMP, GEAR TYPE
386500-5		SV	2	FUEL PUMP
39.1-1100-02		NE	2	SPAS-ACTUATOR
390-389001-0001	MGB4A-1	OH	2	STARTER GENERATOR
3911213-9012	222-DK117	OH	1	HGT INDICATOR
3911213-9016	222-375-023-111	OH	2	HGT INDICATOR
3-91250613-60		NE	52	ORING
393026-03236		SV	1	INDICATOR,LIQUID QUANTITY
393086-01236		SV	1	FUEL QTY IND (US GALS)
393086-01236		SV	1	FUEL QTY IND
3932241-9002	222-375-064-101	OH	1	IND, TOT DUAL FUEL QUAN
3932241-9008	222-375-064-103	OH	1	TOTALIZING DUAL FUEL IND
3941213-9003	222-375-022-105	OH	1	IND, GAS PRODUCER TACH
3941213-9014	222-375-022-111	OH	2	IND, GAS PRODUCER TACH

394400-1		AR	1	FUEL PUMP
395-6798		NE	1	BEARING
39647951-5L		NS	2	BEARING
397578-4-1		SV	1	TEMPERATURE SENSOR
3A63.32.20F.28.1AB		SV	1	ALTIMETER
3A250-1A1		SV	1	STATIC INVERTER
3A43.32.50F.05.1.EG		OH	1	COUNTER DRUM ALTIMETER
3A43-42-50F-05-1-FT		OH	1	ALTIMETER
3A55.32.35F.00.0E		SV	2	Encoding Altimeter
3A61-22-20F-28-1-DS		OH	3	ALTIMETER
3A63.32.20F.28.1AB		OH	1	ALTIMETER
3A632235F281HS		SV	1	Altimeter Drum Scale
3A67-22-20F-58-1-AZ		OH	1	ALTIMETER
3CR15		NS	1	SPEEDAIRE ENGRAVING PEN
3D2314-06		SV	1	ADJUSTER FLOW VALVE
3G20F		NS	4	PUSH BUTTON
3H55.32.35F.00.0.AE		SV	1	Encoding Altimeter
3H65.32.20F.28.4.BP		NE	5	ALTIMETER
3L0-453/4-5		AR	1	G SWITCH
4000020-002		NE	3	LIGHT ASSY COCKPIT UTILITY
400-0073-010	C-962A	SV	1	CONTROL UNIT 28V
4000096-001		NE	1	FILTERCAP NVG
4000-10		SV	1	ELT
4000-1002	206-070-275-5	OH	1	CLOCK
400-0106-000	C-1000	SV	1	CONTROL UNIT 28V
400-0106-010	C-1000	SV	1	CONTROL UNIT 28V
400-0125-101	RT18D	SV	1	FF RT
400-0130-002	C118	SV	1	CTL UNIT
400-0130-003	C118	SV	1	CTL UNIT
400-0130-005	C118	SV	1	COCKPIT CONTROL
400-0130-005	C118R	NS	1	CONTROL PANEL
400-0131-005	C118BR	SV	1	COCKPIT CONTROL
400-0132-013	WHSHFR	SV	1	FF CABIN CTL
400-0138-002		SV	1	FF COCKPIT CONTROL
400-0140-025		SV	1	VHF FM TX/RX
400-014135-01		SV	1	GPS DOWNCONVERTER
400-014635-0101	IC-18	SV	1	FLTEPHONE INTERCOM
400-018100-12	1014744-001	SV	2	FF HANDSET
4000369-8501	DH861A	SV	1	HORIZON IND
400-041181-0001	CDM-451	SV	1	DME TRANSCIEVER
400-045500-0005		SV	1	AFIS DMU
400-045500-2011		SV	2	AFIS DMU
4000460-0501	AD3405A	SV	1	SYS INTER ADAPTER
400-047152-9005	CVC-152	SV	10	COMM CONTROL NVG
400-048100-0001	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0002	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0003	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0004	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0005	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0006	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0007	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0008	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0009	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0010	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0011	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0012	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0013	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0014	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0015	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0016	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0017	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0018	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0019	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0020	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0021	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0022	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0023	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0024	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0047	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0101	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0103	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0106	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0107	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0108	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0109	CVC-151	SV	10	VHF COMM TRANSCIEVER
400-048100-0110	CVC-151	SV	10	VHF COMM TRANSCIEVER

400-048100-0111	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0112	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0113	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0114	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0115	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0116	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0117	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0118	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0119	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0120	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0121	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0122	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0123	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0124	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0201	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0202	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0203	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0204	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0205	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0206	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0207	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0208	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0209	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0210	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0211	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0212	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0213	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0214	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0215	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0216	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0217	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0218	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0219	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0220	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0221	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0222	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0223	CVC-151	SV	10	VHF COMM TRANSCIVER
400-048100-0224	CVC-151	SV	10	VHF COMM TRANSCIVER
4000503-0203	IN1202A	SV	1	INDICATOR
4000504-0301	DA1203A	OH	2	ANTENNA DRIVE
4000525-1212		SV	3	RDR1400 PHASED ARRAY ANT
4000525-1218		SV	1	PHASED ARRAY ANTENNA
40007-1A64		NS	6	ADAPTER
4000833-0207	IN1401A	SV	2	RADAR IND
4000833-0208	IN1402A	SV	1	RADAR IND
4000965-0210	IN1302B	OH	2	RADAR INDICATOR
4000985-3101	DM-2031A	SV	1	DME RT
4000985-3101	IN-2032A	SV	1	INDICATOR
400100-128		NE	1	COMPASS STANDBY 28 VOLT
40-0103-31		OH	1	LIGHT BEACON
40-0117-1		SV	1	LIGHT ASSEMBLY
4001291-2104	IN2021A	OH	1	RADAR INDICATOR
4001597-2304	IU-2023B	SV	2	REMOTE COMPUTER UNIT
4001598-2303	IU-2023C	SV	1	REMOTE COMPUTER UNIT
4001639-2405	CC-2024C	SV	1	MULTI-FUNCTION CHECKLIST UNIT
4001670-2511	IN-2025B	OH	2	RADAR IND
4001670-2513	IN-2025A	OH	5	RADAR IND
4001922-5201	IN-1152A	SV	1	COLOR RADAR INDICATOR
4001943-0401	AA1504A	SV	1	RDR1500 ANTENNA ARRAY
4001974-0207	IN1502A	SV	1	RADAR INDICATOR
4001977-0654	CN1506A	SV	1	RDR1500 CONTROLLER NVG 28V
40020-01		SV	8	HYDRAULIC PUMP
40020-01		OH	10	HYDRAULIC PUMP
4002963-404	RH404	OH	2	RMI
4002963-444	RH444	OH	2	RMI
4002963-904	RH404	OH	1	RMI
4004444-901	RA-210	OH	2	RADIO ALT IND
4004763004		OH	2	STATOR VANE ACTUATOR
4005088-0502		SV	1	MOUNTING TRAY
400-6		NE	25	AIRSPD POINTER
4007261-0502		SV	1	RACK
4007543-0502		SV	1	MOUNTING TRAY
4007550-0507		NE	1	CONNECTOR KIT
4007561-0502		SV	1	MOUNTING TRAY
4007637-2	AT222	SV	1	ALTIMETER ANTENNA
4007701-9		NS	1	CONNECTOR

4008-103		NS	1	ECS RACK
400GL		SV	1	VOLTMETER
400R-1		SV	1	EMERGENCY LIGHT
400R-1		SV	1	EMERGENCY LIGHT
401/262		SV	1	ANTENNA CTL UNIT
4012373-903	SM710	OH	3	ACTUATOR
4012373-904	SM710	OH	3	ACTUATOR
4012373-905	SM710	OH	3	ACTUATOR
4012373-905	SM710	NE	10	LINEAR ACTUATOR
4012373-906	SM710	OH	3	ACTUATOR
4012373-907	SM710	OH	3	ACTUATOR
4012373-908	SM710	OH	3	ACTUATOR
4012373-909	SM710	OH	3	ACTUATOR
4012373-910	SM710	OH	3	ACTUATOR
4012373-911	SM710	OH	3	ACTUATOR
4012373-912	SM710	OH	3	ACTUATOR
4012373-913	SM710	OH	3	ACTUATOR
4012373-914	SM710	OH	3	ACTUATOR
4012373-915	SM710	OH	3	ACTUATOR
4012373-916	SM710	OH	3	ACTUATOR
4012373-917	SM710	OH	3	ACTUATOR
4012373-918	SM710	OH	3	ACTUATOR
4012373-919	SM710	OH	3	ACTUATOR
4012373-920	SM710	OH	3	ACTUATOR
4012455-2		FN	1	DC MOTOR BRUSH RING
4012565-1		FN	2	COND ASSY
4013013-907	VS200	SV	3	VER AIRSPEED
4013241-903		OH	1	AIR DATA COMPUTER
4013241-907	AZ-241	SV	1	AIRDATA COMPUTER
4013242-708	AZ-242	SV	1	AIRDATA COMPUTER
4013242-726	AZ-242	SV	1	AIRDATA COMPUTER
401-40-2		SV	1	AIRSPEED SWITCH
4018285-901	AL-205	SV	1	ALTITUDE ALERT CONTROLLER
4018368-901	MS500	SV	1	MODE SELECTOR
4018368-902	MS500	OH	1	MODE SELECTOR
4018368-913	MS500	SV	1	MODE SELECTOR
4020501-594	GH14	OH	1	GYRO HORIZON
4020550-904	AD300H	OH	1	ATTITUDE DIRECTOR INDICATOR
4021541-191	GH14B	OH	1	GYRO HORIZON
4021541-331	GH14	OH	1	GYRO
4021541-391	GH14	OH	2	GYRO HORIZON IND
4021541-560	GH14	OH	1	GYRO HORIZON IND
4021541-590	GH14	OH	1	GYRO HORIZON IND
4021541-671	GH14	OH	2	GYRO HORIZON IND
4021541-671		NE	1	GYRO HORIZON
4021541-671INVG	GH14	OH	2	GYRO HORIZON IND
4021541-791	GH14	OH	1	GYRO HORIZON IND
402-2301		NS	1	SPDT 1GHZ COAX RELAY
4023400-0503	RT-859AJAPX-72	SV	1	TRANSPONDER
4023400-0506	RT-859AJAPX-72	SV	1	TRANSPONDER
4025008-910	SP711	SV	2	HELIPLOT COMPUTER
4025008-911	SP711	SV	2	HELIPLOT COMPUTER
4025008-915	SP711	SV	2	HELIPLOT COMPUTER
4026206-902	Ri-206	SV	1	INST REMOTE CONTROLLER
4026206-972	Ri-206	OH	1	INST REMOTE CONTROLLER
4027395-023		NS	1	PANEL
402-90-1		OH	1	PRESSURE SWITCH
4029377-907		FN	1	SP600 Autopilot Computer
4029377-912	SP600	AR	1	AUTOPILOT COMPUTER
4029516-520		SV	1	FLIGHT DIR COMPUTER CONTROL
403001-005	153-017310-01	SV	1	HPA/LNA
403001-006		SV	3	HPA LNA GPS PRE AMP
4030182-901	AC702	OH	1	ALTITUDE SENSOR
40-41320-1010		NE	3	DIAPHRAGM ASSY/ALTI
404-38-X018		SV	1	MOUNTING TRAY
404-810-1	5841-041-0540	SV	1	RT-833AV1/APN-175V
404-810-1	RT-833AV1/APN-175V	SV	1	RECEIVER TRANSMITTER
404A-25-S-D/DPXB-0		SV	2	TRAY
404A-38-S-1/DPXB/C-0		SV	2	TRAY
404A-50-X003		SV	1	MOUNTING TRAY
405001A-PMA		FN	1	Satcom IGA Antenna
405006A-PMA		FN	1	Satcom IGA Antenna
405010A	AERO-I	SV	2	SATCOM HPA
405012A	AERO-I	SV	1	SATCOM DLNA
405016A		FN	2	TT-5016A High Power Amplifier
405033A-01	AERO-I	SV	1	SATCOM SDU CONFG MOD

405033A-UAT-NRS	AERO-I	SV	1	SATCOM SDU
405622A-UAB		SV	1	SATCOM CRADLE
405624B-THR		FN	6	AVIATOR Wireless Handset Black
405AD		SV	1	AC ADAPTER
4-063-020-17		OH	1	INLET HOUSE
4-063-020-17		AR	1	INLET HOUSE
4-063-140-02		NE	2	PANEL ASSY
4066010-910		SV	1	TCAS II COMPUTER
407-240-018-101		SV	1	DRIVESHAFT TOOL SPAN
407-375-001-105	90090001-02	OH	1	MGT INDICATOR
407-375-008-101	DL439	OH	1	DUAL TACHOMETER INDICATOR
4-081-080-11		SV	1	FUEL PUMP DRIVE
4088468-902	DBA-1160MR	SV	1	ASSY SATELLITE ANT RCVG FLT.D
4088622-2		NS	3	CONNECTOR
4088622-3		NS	7	INSULATR
4088622-4		NS	2	CONNECTOR
4092745-901	XMDPRT-02	SV	2	XMWX DATA PORT
40T15K		NE	1	PUSH BUTTON ASSY
4-101-060-13		SV	1	SHROUD ASSY
41102010-01		SV	1	ACTUATOR
41-104082-01		SV	1	RELAY UNIT
412-075-008-111	9813-25-21	OH	2	DUAL TORQUE IND
412-075-008-113	DT410-2	OH	2	DUAL TORQUE IND
412-075-205-101	18-1842-7	OH	2	PRESSURE TORQUE TRANSDUCER
412-075-706-107	292-412-706-107	NS	2	PANEL
412-075-710-101	67564-101	NS	2	PANEL
412-075-711-101	97499/412-075-711-101	NS	2	PANEL
41222-100-009-001	100-009-001	SV	1	CVR
412-375-702-101	292-412-702-101	NS	2	PANEL
412-375-703-101	292-412-703-101	NS	2	PANEL
412-375-704-101	292-412-704-101	NS	2	PANEL
412-375-711-103	292-412-711-103	NS	1	PANEL
412-375-712-103	292-412-712-103	NS	2	PANEL
412-375-713-101	292-412-713-101	NS	2	PANEL
412-375-714-101	292-412-714-101	NS	2	PANEL
412-832-151		NS	2	SEARCHLIGHT CONTROL PANEL
4-141-010-24		SV	1	HOUSING
4-141-026-05		NS	1	SPACER
414-180615-3		NS	1	LENS RH WING
4-143-020-07		SV	1	HOUSING
4-143-020-07		NE	2	COMBUSTOR HOUSING
416-00293-010		SV	1	P/R SAS COMPUTER
416-00293-100		SV	1	P/R SAS RECHNER
416-00293-120		SV	1	SAS2000 COMPUTER
416-00297-302		SV	2	PA 4-AXES DUPLEX SAR
416-00297-310		SV	1	AUTO PILOT MODULE
416-00298-010		NE	2	APMS2010 NVG
416-00298-010		SV	2	FLIGHT CONTROLLER
416-00298-100		SV	2	APMS2100 ERS
4-161-417-02		NS	2	REDUCER
418-00275-003	1560SA0572907	SV	3	BAROMODULE, AP AIR DATA CONTRO
418-00302-000	704A47-1350-08	SV	1	ELECTRIC ACTUATOR
418-00625-114	704A47135033	SV	1	ACTUATOR,ROLL
418-00847-100		SV	1	SEMA 8399
418-00874-001	704A47-1320-58	SV	3	ACTUATOR,PITCH TRIM
418-00876-250		SV	1	SMART ACTUATOR
418-00876-800		SV	2	ACTUATOR
418-00876-800		AR	5	ACTUATOR
418-00881-000		SV	1	DUPLEX TRIM PARALLEL ACTUATOR
418-01141	212-061-010-001	SV	1	TRANSMITTER, OIL PRESS
418-02461-001		SV	1	ACTUATOR
418-09084	45AS86825-005	OH	1	OIL PRESSURE TRANSMITTER
4184NX		NE	1	FAN
41850A14-4580		SV	2	LANDING LIGHT
41850A17-4580		SV	1	LANDING LIGHT
419-00320-561	704A47-1332-05	SV	1	COUPLER, CDV 85
419-00320-660		SV	1	CDV AUTOPILOT COUPLE
419-00320-660		AR	1	CDV AUTOPILOT COUPLE
419-18		NS	1	SWITCH
41950-0000		SV	1	RECEIVER ACCESSORY
4200-005-2		NE	1	CIRCUIT BREAKER
420-00332-411		SV	2	AHRU APIRS F201
420-00332-460	261500123-0460	SV	2	AHRU
420-00339-000		NE	2	MAGNETOMETER
422-18152-933	18152-933	SV	1	STATIC CORR
422-23080-027	23080-027	AR	1	LEAR 35A/36A STATIC DIFF COR

422559-2WH	336695-802WH	AR	2	MAGNASTAR PHONE
422650-801	1HGD9REV8	SV	1	CABLE
42325-371		NE	3	MOTOR FAN ASSY
42325-389		NE	2	FAN MOTOR
4254A010-100		NE	8	SWITCH DIFFERENTIAL PR
426-1-13		SV	1	GALLEY SWITCH PANEL
42701-1	42701-01	SV	4	MOUNT
4271-606		NS	1	CONNECTOR
4271-613		NS	3	SWITCH MATRIX
427-375-001-103	160M020	SV	1	IDS DISPLAY
42960-00	704A47612052	SV	1	INDICATOR,TACHOMETER
42HP601-19		NS	6	PANEL
42HP605-1		NS	1	PANEL
42HP911-1		NS	5	PANEL
42HP920-7		NS	4	PLATE
42HP926-1		NS	4	RING
42HP928-1		NS	1	PANEL
4300-20000-00		FN	1	DCU
4300-8170-1L	222-375-033-101	SV	2	ATTITUDE GYRO
4-301-044-02	1373-00-1	OH	1	VALVE, BLEED AIR
4-301-099-10		OH	1	T1 SENSOR 650B1
4-301-099-10		AR	1	T1 SENSOR 650B1
4-301-128-04 C	4-301-128-04	NE	1	FUEL PUMP
4-301-483-01		OH	1	CONTROLLER
4-301-483-01		AR	1	CONTROLLER
430-215-100-101		SV	1	GAUGE, TRIM TAB BEND
43025-0400		NS	20	RECEPTACLE
4305-7150L		SV	1	DIRECTIONAL GYRO
4305-8175-1L	222-375-034-101	SV	2	ATTITUDE GYRO
430-6090-600	GSL71	SV	1	LIAT CONTROL PANEL
4308-05000-20-101		NE	1	FAERITO AVIONICS RECORDER
4308-15003-23-101		NE	1	RIGHT HAND CAMERA
4344-2020	206-075-706-3	OH	1	OIL PRESSURE IND
4351-1203		SV	1	TORQUE METER
43622-02-03-01		SV	1	ROLL ROD ASSY
437-1-4		SV	1	CONTROLLER- GALLEY CALL
438-00100-021		NE	2	PITCH YAW GYRO METER
438-00100-021		SV	1	PITCH YAW GYRO METER
4-381-128-10		SV	1	FUEL PUMP
442042-1		SV	1	FUEL CONTROL APU
44301-406		NE	1	FLOAT ASSEMBLY
44301-700		SV	1	FUNCTION BOX
44311-721		SV	1	PENDANT CONTROLLER, HOIST
44410-2-245		SV	1	ROTATING
444-DMC57-1	CD-571	SV	1	ANTENNA, UHF, BLADE
4484-100-020		SV	1	MASTER CAUTION PANEL
449-2	212-075-962-1	SV	1	POWER SUPPLY
45-0019-7		OH	1	LANDING LIGHT
450-1000-200		SV	1	CAMERA POD FLIR 4000, ULTRA
450120-H		NS	18	SEAL PLAIN ENCASED
45-0182-1	76550-02005-101	OH	1	SEARCHLIGHT
45-0182-3	76550-02005-102	OH	1	SEARCHLIGHT
45-0182-5	76550-02005-103	OH	1	SEARCHLIGHT
45-0182-7	76550-02005-104	OH	1	SEARCHLIGHT
45-0182-7M		OH	1	SEARCHLIGHT
45-0253-11		OH	1	LAND LIGHT RETRACT
45-0300-1		SV	1	NVG SEARCHLIGHT, CONTROL, F3]
45-0300-1		SV	3	SEARCH LIGHT
45-0339-11		SV	1	SEARCH LIGHT
452-0111		SV	1	ANTENNA
452100-02		SV	3	MODE SELECTOR UNIT
453-0150-01	ELT100HM	SV	2	ELT
453-6603		SV	1	ELT
4545-00-5	209-072-433-101	SV	1	VALVE
454640-01	LTN72	SV	1	CONTROL DISPLAY UNIT
454C-01		NE	6	DRAIN VALVE
455-0407		SV	1	ELT
455-5001(999)	455-5001	NE	1	EMERGENCY TRANSM C406-2H
455-6196		NE	18	INSTALL KIT WINAV REMOTE SWITCH
455-6500		NE	4	ELT/NAV INTERFACE
45900-1		SV	1	ANTI-COLL-BEACON
45AS88856-3		SV	1	CONTROL BOX
46060-10	706-10	OH	2	GYRO DISPLACEMENT
46060-11	706-11	OH	2	GYRO DISPLACEMENT
4632AA	704A49430049	SV	1	BOX,DETECTOR VIBRATION ANALYSIS
46700-1	704A47111037	SV	1	IND-WSETTER,VERT- SPEED FT/MN

46D36		NE	1	VENTIL
47-00000-9		SV	1	CHADWICK CONTROL
47-120-142-1		NS	4	SEAL
47360-1100		SV	1	TRANSCEMER
47-620-200-12T210		SV	1	PLUG TOOL
47-620-617-007	2802-070-8060-80080	NS	80	PLATE
47-644-213-003		NS	3	BEARING HOUSING
481-301-104	76450-00706-104	OH	2	T5 INDICATOR
481-401-103	76450-00706-103	OH	1	DUAL TORQUE IND
481-501-104	76450-00706-102	OH	1	TRIPLE TACH INDICATOR
482-5088-010	6695-00-438-3977	NE	10	METER MOVEMENT
483GCO1Y032	704A46570104	SV	1	MASTER ELECTRICAL RT
48707-002	527-48707-002	OH	1	SERVO ALTIMETER
48770017-01		SV	1	NAV SENSOR UNIT
488-3305-001		SV	1	CONTROL
492-1-50		SV	1	UNIVERSAL SPC
492GCO1Y021	704A46570068	SV	1	ELECTRICAL MASTER BOX_LH
494-116-001-694		SV	3	HEADSET, MIC
4A16.32.60F.28.4.CE		NE	8	VERTICAL SPEED INDICATOR
4A2000-1B		SV	1	FREQ CONVERTER
50-0002-01	50-000X-XX	SV	1	CDI-500 COURSE DEV IND
500185-5		SV	1	AEROROUTER 700
500-21	C668520-0101	OH	1	OAT INDICATOR
500-23164-101		NE	1	KIT, HSD-400 RF COAX
500-280		SV	1	3 PHASE AC
500-30577-17		NE	1	HPA TO ANT COAX
500-30577-18		NE	1	HPA TO ANT COAX
500-5000		SV	1	CONVERTER
5006-1036		OH	1	TOT INDICATOR
5006-1039		NE	1	EXHAUST TEMP. INDICATOR
500-83007-01	311501	NS	1	COAX CABLE ASSY
500-83007-02	311501	NS	1	COAX CABLE ASSY
500-83007-03	311501	NS	1	COAX CABLE ASSY
500-83007-04	311501	NS	1	COAX CABLE ASSY
5008512-002		SV	1	DATA BUS COUPLER
500N5433		NS	1	SEAL
50-1-053		SV	3	NO SMOKING PANEL
501-1038-01	AC111D	SV	1	FLT CONTROL
501-1121-01		SV	1	VG208A Vertical Gyro
501-1121-01		OH	1	VG208A Vertical Gyro
501-1121-01		AR	2	VG208A Vertical Gyro
501-1142-03	AD102A	SV	1	AIR DATA SENSOR
501-1142-04	AD102B	SV	1	AIR DATA SENSOR
501-1170-21		OH	1	ATTITUDE GYRO
501-1170-23	AI-904U/HA/B	OH	1	ATTITUDE GYRO
501-1170-27		OH	1	ATTITUDE GYRO
501-1170-40		OH	1	ATTITUDE GYRO
501-1185-01	FN106A	SV	1	RR FILTER NETWORK
501-1197-29	AI-804CE	OH	1	ATTITUDE INDICATOR
501-1207-08	DC-2001H	SV	1	DIGITAL NAV COMPUTER
501-1224-02	76600-02113-102	OH	1	VERT GYRO
501-1240-01	SI-100A	SV	2	STATIC INVERTER
501-1453-01	76600-02113-103	OH	4	VERTICAL GYRO
501-1475-01		FN	1	PS-855A S.I. 115V
501-1568-17	AI330	OH	2	ATTITUDE INDICATOR
501-1845-01	AI-803CY	NE	3	HORIZON INDICATOR
501-1845-01	AI-803CY	OH	2	HORIZON INDICATOR
501580-401		AR	1	SEAT BELT
5018-753-00-00		SV	1	AUDIO AMP
502-1-50		SV	1	VIDEO SPC WITH ALAN I
502A15		SV	1	POWER ADAPTER UNIT
502-DP1-STS	2102-070-1060-10010	NS	10	SPRING CLAMPS
503067-405-2255		NS	1	SEAT BELT
503067-407-4185		NS	3	SEAT BELT
503068-409-2862		SV	2	BELT ASSY
503-19-3		SV	1	C-SWITCH
503-23		NE	1	COCKPIT CONTROL PANEL
50-380034-3	515-3	SV	1	TACHOMETER IND
50-384081-21	8326-1	OH	1	ENGINE GAGE
50-389091	22-280-026-1A	SV	1	TACH SYNCHRO INDICATOR
504-0017-901	510-1A	AR	1	ATTITUDE GYRO
504-0017-901	510-1A15	OH	1	ARTIFICIAL HORIZON
504-0017-908	510-1B	OH	1	ATTITUDE GYRO
504-0017-917	5108C	OH	1	ATTITUDE GYRO
504-0017-933		OH	2	ATTIT.GYRO (510-1P-15)
504-0035-905	520-2A	OH	1	GYRO



504-0045-902	510-358	OH	1	ATT GYRO
504-0110-905	1100-145(11)	OH	1	HORIZON GYRO
504-0111-902	1100-28(11)	OH	2	HORIZON GYRO
504-0111-903	1100-28L(20B)	OH	2	HORIZON GYRO
504-0111-904	1100-28(0)	OH	2	HORIZON GYRO
504-0111-905	1100-28L(0F)	OH	2	HORIZON GYRO
504-0111-906	1100-28(0)CES	OH	1	HORIZON GYRO
504-0111-907	1100-28LS(8F)	OH	2	HORIZON GYRO
504-0111-908	1100-28(5)	OH	2	HORIZON GYRO
504-0111-909	1100-28(8)	OH	2	HORIZON GYRO
504-0111-910	1100-28(12)	OH	2	HORIZON GYRO
504-0111-911	1100-28(14)	OH	2	HORIZON GYRO
504-0111-912	1100-28L(5F)	OH	2	HORIZON GYRO
504-0111-913	1100-28L(7F)	OH	2	HORIZON GYRO
504-0111-914	1100-28L(8F)	OH	2	HORIZON GYRO
504-0111-915	1100-28L(12F)	OH	2	HORIZON GYRO
504-0111-916	1100-28L(14F)	OH	2	HORIZON GYRO
504-0111-917	1100-28LS(0F)	OH	2	HORIZON GYRO
504-0111-918	1100-28LS(5F)	OH	2	HORIZON GYRO
504-0111-919	1100-28LS(12F)	OH	2	HORIZON GYRO
504-0111-920	1100-28LS(14F)	OH	2	HORIZON GYRO
504-0111-928	1100-28LS(7F)	OH	1	HORIZON GYRO
504-0111-929	1100-28L(15F)	OH	2	HORIZON GYRO
504-0111-930	1100-28LS(15F)	OH	1	HORIZON GYRO
504-0111-931	1100-28L(11F)	OH	2	HORIZON GYRO
504-0111-932	1100-28LS(11F)	OH	1	HORIZON GYRO
504-0111-933	1100-28L(15B)	OH	1	HORIZON GYRO
504-0111-934	1100-28L(10F)	OH	1	HORIZON GYRO
504-0111-935	1100-28LS(16F)	OH	1	HORIZON GYRO
504-0111-937	1100-28L(6F)	OH	1	HORIZON GYRO
504-0111-940	1100-28L(4F)	OH	1	HORIZON GYRO
504-0111-942	1100-28LS(14E)	OH	1	HORIZON GYRO
504-0111-943	1100-28LS(11B)	OH	1	HORIZON GYRO
504-0111-944	1100-28K(10)	OH	1	HORIZON GYRO
504-0122-902	1200-2RS(15D)	OH	2	AH3 HELI 28V FRONT W
504339-211-1028		NE	1	LAP BELT ASSY
505-0002-904	200DC(28)	OH	1	DIRECTIONAL GYRO
505-0002-917		OH	1	DIRECTIONAL GYRO
505-0010-902	200DCL	OH	1	DIRECTIONAL GYRO
505-0031-904		NE	1	DIRECTIONAL GYRO
50691-7	222-375-062-107	SV	2	MAST TORQUE SIGNAL CONDITIONER
50691-9	222-375-062-109	SV	1	MAST TORQUE SIGNAL CONDITIONER
507-220-101	2102-070-1060-10010	NS	10	CIRCUIT BREAKER SWITCH
5083-100		NE	1	RADOME ASSY
50C-0024-10		OH	1	INDICATOR
50C-0024-10		AR	2	INDICATOR
50C-0024-12		OH	2	INDICATOR
50C-0024-12		AR	2	INDICATOR
51008-0065		NE	4	IC
5110-1050-00		SV	1	BEVERAGE MAKER
513-18352-10	18352-10	SV	1	SDC MODULE
51522-000	222-375-060-103	SV	1	REGULATOR/CONTROLLER
51522-002	222-375-060-109	SV	1	REGULATOR/CONTROLLER
51530-006A	76550-09006-105	SV	1	D-C- GENERATOR CONTROL UNIT
51538-005A		NE	1	DC GENERATOR CONTROL UNIT
51538-005A		SV	2	DC GENERATOR CONTROL UNIT
51565-000R		SV	4	VOLTAGE REGULATOR
518-16007-161	16007-161	OH	1	ALTIMETER
518-16007-334	16007-334	SV	1	ENCODING ALTIMETER
51824-1	2602-070-6060-60060	NS	60	GREEN THERMASHIELD
5201-1		SV	1	ATC CONTROL PANEL
520-3150-003	HSI-315A	SV	1	STANDBY H.S.I.
520-3337-207	3337LB21C	SV	1	RADIO MAGNETIC INDICATOR
520-4150-007	HSI-415A	SV	1	STANDBY H-S-I
520-7137-014		OH	1	RMI
520-8014-001	RVG-801E	NE	2	VERTICAL GYRO
520-8100-101		OH	1	DIRECTIONAL GYRO REMOTE
522-0240-003	350X-1	SV	6	RACK
522-0700-023	37P-5	SV	1	GLIDE SLOPE ANTENNA
522-1658-000		SV	1	MOUNTING TRAY
522-1660-000	618T3	SV	1	HF TRANSCENER
522-2357-019	614L8	SV	1	ADF CTL
522-2447-560		SV	1	NAV CONTROLLER
522-2449-000		SV	1	VHF CONTROLLER
522-2644-00		OH	1	SLAVING ACCESSORY UNIT
522-2644-011		OH	1	SLAVING ACCESSORY UNIT

522-2788-015		SV	1	MONITOR, COMPARATOR WARN
522-3443-000	490T1	SV	1	ANTENNA COUPLER
522-3616-204	313N4D	SV	1	CONTROL UNIT ,NAV
522-3617-003		SV	1	CONTROL UNIT ,VHF
522-3761-001	137A6A	SV	1	ADF ANTENNA
522-3918-001		SV	1	CONTROL IND
522-3918-004		SV	1	COMPARATOR MONITOR IND
522-3948-001	54W1C	SV	1	MONITOR COMPARATOR WARN
522-4114-003		OH	1	RAD ALT INDICATOR
522-4140-007	437X1	SV	1	ANTENNA
522-4853-001	5985-00-617-7123	OH	2	ANTENNA
522-4945-001	323A2G	SV	1	FLUX VALVE
5232C		SV	1	INTERFACE ADAPTOR
52347-100BCL	262-070-660-606	NS	10	NUT
52347-100BCL		NE	20	NUT
52355FBD050N	2112-070-1160-11011	NS	11	FASTENER
528401-5		SV	1	EATON RUDDER TRIM CTL
52D67M	700-3CF	OH	1	ATTITUDE GYRO
5306-155-00-10	704A37-641-008	OH	2	OIL PRESSURE IND
5306-155-00-10		OH	1	ENGINE OIL PRESSURE IND
5306-160-00-11		OH	1	MGB OIL PRESSURE IND
5306-168-00-10		OH	1	OIL PRESSURE IND
5306-255-00-11	704A37-633-008	OH	1	OIL TEMP IND
5309-155-00-11		OH	2	FUEL PRESSURE IND
53114-24ADL		NS	1	WASHER
53114-24ADL		NE	1	WASHER
53114-24ADL		NE	1	WASHER
53-1784-503-00		SV	1	PANEL
540-011-118-001	540-011-118-1	NE	1	BARREL
540-011-123-001	540-011-123-1	OH	5	PINS
540-012-125-005	3120-01-026-6942	FN	16	SLEEVE
540-012-125-007	3120-01-026-6943	FN	9	SLEEVE
540-012-125-5	3120-01-026-6942	FN	16	SPACER
540-012-125-7	3120-01-026-6943	FN	9	SPACER
540-23989-011	23989-011	OH	2	ALTITUDE SELECT
542-1037-08		NE	1	DUAL SWITCH MODULE
5448-706-91-10		OH	2	N1 INDICATOR
5448-709-91-11	117-902101	SV	1	N1 INDICATOR
5448-709-91-11	117-902101-A	SV	1	N1 INDICATOR
5448-712-91-10		OH	2	N1 INDICATOR
5485-054-K		SV	1	ACTUATOR
549-4800-000		NS	1	SWITCH
5500-01		SV	1	LED READ LIGHT
5501-04		NS	14	READING LIGHT
5501-05		NS	9	READING LIGHT
550-18013B-012	18013B-012	OH	1	VSI
550-18013B-954	18013B-954	OH	1	VSI
5506L-S		OH	2	ALTITUDE ALTERTER
5506L-S114		OH	1	ALTITUDE ALTERTER
5506-S		OH	1	SERVOED ENCODING ALTIMETER
5506-S5		OH	1	SERVOED ENCODING ALTIMETER
5506-S5-Y		OH	1	SERVOED ENCODING ALTIMETER
5506-SG		OH	1	SERVOED ENCODING ALTIMETER
5506-SG5		OH	1	SERVOED ENCODING ALTIMETER
5506-SG5Y		OH	1	SERVOED ENCODING ALTIMETER
5506S-S-39		OH	1	SERVOED ENCODING ALTIMETER
55100-010		NE	1	YOKE FOR PULLER
55132-102	2142-070-1460-14014	NS	14	PIN
55134-202		NS	5	RECEPTACLE
55216-092-112		NS	1	CLAMP
5550-101-07	FLIGHT VISIONS	SV	2	HEADS UP DISPLAY PDU
5550-8340N5L		OH	2	2 INCH TURN AND SLIP
5550-9235N1L	222-375-072-101	SV	2	TURN & BANK IND-
5560-8165N1L	222-375-028-101	SV	2	TURN & BANK IND-
5600-S938	209-075-372-1	SV	2	RELAY, TIME DELAY
5601-036		SV	2	ROSEN MONITOR
5601-130		SV	1	ROSEN MONITOR
5601-160		SV	2	ROSEN MONITOR
56056-0101A	56056-0101	SV	1	SATCOM FAX APAPTER
5617-355-91-11	704A47-660-012	OH	1	INDICATOR, OIL TEMP & PRESS
5622103A		NE	2	IFF MOUNT MTR401
5626-555-00-11	704A47-632-038	OH	1	TEMP IND
5633-619-00-12	704A47612123	OH	1	INDICATOR DELTA NG
566-1814-04		NS	1	CLAMP MOUNTING IND
5677-752-00-12	704A47621125	OH	1	INDICATOR TORQUEMETER
5678-553-80-12		OH	2	ITT IND

5678-710-80-12		OH	1	PROPELLER SPEED IND
568A0000-01		SV	2	SOLENOID VALVE
570-24929-053		OH	1	ENCODING ALTIMETER
571-2	222-375-009-103	OH	1	DETECTOR, RPM LIMIT
5713-20-10-C2C		NE	24	STUD, TURNLOCK FASTENER
5718-A3-ACNC		NE	6	TURNLOCK FASTENER
574-1220-01		NS	1	HARNES
574-3		SV	1	WINDSHIELD TEMP CONTROL
575-31500-436		SV	1	AIRSPPEED IND-
5800-465-80-14	704A47270025	OH	1	INDICATOR 14 INFOS
5800-473-80-10	704A47270129	OH	1	INDICATOR 14 INFOS
5800-483-80-10	704A47270136	OH	2	INDICATOR HFD
5802-1006		OH	1	AIRSPPEED INDICATOR
58057-12	461-00272-101	OH	3	GYRO
58057-42	461-00272-101	OH	1	DIR GYRO
5813-700-00-11	704A47610064	OH	1	INDICATOR,TACHOMETER NR/NRTL
5821-01-135-6056	RT-1168C/ARC164V	SV	1	RCVR/TRANS
5821-01-137-6300	RT-1168B/ARC164V	SV	1	RCVR/TRANS
582-507-11		SV	1	TCAS IND
5868K-0142		OH	1	AIRSPPEED IND
58960-4088630-901	4088630-901	NS	12	CONNECTOR ASSY
5909244-4		SV	1	INDICATOR
59140-010		NS	1	PROXIMITY SENSOR
5916-46A-1-B		OH	1	INDICATOR AUTOSYN
5934A-1		OH	1	ALTIMETER
5934PAD-3		AR	1	ALTIMETER
59-52.02-41-70		NS	2	CLAW RING WASHER SET
5952-CW-6	5952-CW-6 REV C	NE	1	LUMINATOR
597-1987-003	51RV-40F	SV	1	NAV RCVR
5A16-32-18K-28.4.DT		NE	8	AIRSPPEED INDICATOR
5A16-32-30K-00.0.BK		SV	1	Airspeed Indicator
5A16-13-27K-00-0A		OH	1	AIRSPPEED INDICATOR
5A58-42-45K-05-1-DH		OH	1	AIRSPPEED IND
5-AS350-19		OH	1	COMPRESSOR ASSY
6004061-10		SV	1	BRAKE CONTROL SYSTEM
600-52262-1		NE	1	PLACARD
600-52262-2		NS	1	PLACARD
600-52267-6		NE	1	PLACARD
600-52267-6		NE	1	PLACARD
6007-61B-7B		OH	1	INDICATOR OIL QUANTITY
60-1431-3		SV	1	GRMES STROBE LIGHT PWR SUPPLY
60-1592-5		SV	1	STROBE LIGHT POWER SUPPLY
60-1755-1		SV	1	STROBE LIGHT POWER SUPPLY
601A50922-11		NE	4	BEZEL
601A50923-7		SV	1	LIGHT PANEL
6022550CN8044286		SV	1	CURSOR CONTROL DEVICE
602667-1		SV	1	POWER SUPPLY
602-7684		SV	1	HAND MIC
60-2885-1	60-2885-1REV D	SV	1	STOBE LIGHT PWR SUPPLY
60-2915-1		SV	1	FILTER ASSY
603-32-0		NS	3	TIMER
60344-103		NE	1	PUMP
6038T62P13	763700-13	SV	1	H-M-U-
6041H190		SV	1	RELAY 200 AMP SPST
6041H255	389A4658	NS	2	DC AIRPLANE CONTACTOR
6073-102		SV	1	MOUNTING TRAY
608-9419-003	5821-01-023-9318	OH	1	GUARD RCVR
608-9420-003	5996-01-248-0614	SV	2	AMPLIFIER,INTERMEDIATE FREQ
609-4009-001		NE	2	KNOB
6097768-200		SV	1	AIR TRANSPONDER
6103-1004		OH	1	ALTIMETER
610C-001		SV	1	ENGINE MONITOR
611-016		NE	2	AURAL WARNING GENERATOR
61148-110		OH	1	CONTROL BOX
61148-110		NE	4	CONTROL BOX
61-21-3		NE	1	BALLAST FLUORESCENT LAMP
612-1-52885-001		SV	1	BLADE TRACKER
61474-130-1		OH	1	INDICATOR,NR-NTL1-NTL2
61474-120-2	704A-47-616-023	OH	1	INDICATOR,NR-NTL1-NTL2
61475-102-1		OH	1	INDICATOR, NG1-NG2
61476-402-1	704A47610065	OH	1	INDICATOR NR-NTL
61533-107-1		OH	2	TEMP IND
61595-0101		NE	2	KIT
616-ECU-01		SV	2	AMPLIFIER
616-ECU-01		AR	2	AMPLIFIER
617-6195-103		NS	1	RACK ASSY

617-8759-002		SV	5	RECEIVER BOARD
617-9618-001	5821-00-180-8250	SV	1	SYNTHESIZER, FREQUENCY
618-5054-002		NE	1	PLATE
618-5057-002		NE	1	PLATE
618-5078-005		NE	1	PLATE
618-5079-002		NE	1	PLATE
618-5080-001		NE	1	PLATE
620317-2REVE	620317-2	SV	3	DUPLEXER
621-0450-001		OH	3	618M3 SUBASSY
621-0451-001		OH	1	618M3 SUBASSY
621-0451-002		OH	2	618M3 SUBASSY
621-0452-001		OH	1	618M3 SUBASSY
621-0452-005		OH	2	618M3 SUBASSY
621-0453-003		OH	2	618M3 SUBASSY
622-0142-003		SV	1	SELECTOR, REMOTE
622-0171-002	339H3	OH	1	RAD ALT IND
622-0193-001	641D1	SV	2	CAPACITOR
6220-300-01	FLIGHT VISIONS	SV	1	HEADS UP DISPLAY GRID AMP
622-2040	9900BX	FN	2	XPRD COUPLER KIT
622-0629-002	913F2	SV	1	CONTROL, RADIO SET
622-0876-001	VR30A	AR	2	NAV RCVR
622-0876-011	VR30A	SV	5	NAV RCVR
622-0876-012	VR30A	AR	2	NAV RCVR
622-0876-201	VR30A	AR	1	NAV RCVR
622-0876-211	VR30A	SV	5	NAV RCVR
622-0876-212	VR30A	SV	1	NAV RCVR
622-0950-001		SV	1	MODE SELECTOR
622-1032-001	699Z1	SV	10	RMI ADAPTER
622-1036-001	1E1H1	SV	1	PROGRAMMER
622-1204-002	339H4	OH	2	RAD ALT IND
622-1204-003	339H4	OH	2	RAD ALT IND
622-1204-004	339H4	OH	2	RAD ALT IND
622-1205-001	339H4A	OH	1	RAD ALT IND
622-1205-002	339H4A	OH	1	RAD ALT IND
622-1205-003	339H4A	OH	1	RAD ALT IND
622-1205-004	339H4A	OH	1	RAD ALT IND
622-1239-201	VR31A	SV	2	RCVR, VOR/LOC/GS/MB
622-1270-001	TDR90	AR	5	TRANSPONDER RT
622-1334-002	VHF20B	AR	2	VHF COMM TRANSCIVER
622-1391-003	5895-00-567-4548	SV	2	CONTROL RCVR TRANS
622-1391-004	5895-01-513-5529	OH	1	CONTROL RCVR TRANS
622-1678-001	5826-01-012-4864	SV	2	ADAPTER, RECEIVER-TRANS
622-1738-002	913Y1	SV	1	MODE SELECT UNIT
622-1742-003	990C3D	SV	1	MOUNTING TRAY
622-1783-001	MT4682A	OH	2	MOUNTING BASE
622-1879-001	VHF20A	AR	8	COMM TRANSCIVER
622-1879-002	VHF20A	AR	8	COMM TRANSCIVER
622-1879-002	VHF20A	OH	8	COMM TRANSCIVER
622-1945-011	339R7	SV	4	REMOTE READOUT UNIT
622-1947-011		SV	1	REMOTE READOUT UNIT
622-2041-001	MT-4915A	OH	3	MOUNTING BASE
622-2080-011	VR351	AR	2	NAV
622-2091-000		SV	1	RCVR
622-2091-001		SV	1	RCVR
622-2093-001		SV	1	POWER CONVERTER PWC-150
622-2313-058		SV	1	FLIGHT GUIDANCE PANEL
622-2362-001	ADF60A	SV	4	ADF RCVR
622-2506-002	RMI-36	SV	1	RMI
622-2506-004	RMI36	SV	2	RMI
622-2883-001	PWR200	OH	1	HF POWER AMPLIFIER
622-2884-004	AAC200	SV	1	HF COUPLER
622-2913-001		SV	1	RELAY UNIT
622-2921-001		OH	1	860E5 DME TRANSCIVER
622-2921-001	860E5	OH	1	DME TRANSCIVER
622-2923-004	PRE80A	AR	1	ALTITUDE ALERTER
622-2937-004	ALISS	OH	1	RAD ALT INDICATOR
622-2937-009	ALISS	OH	1	RAD ALT INDICATOR
622-2938-001	ALISSA	OH	1	RADIO ALT INDICATOR
622-2938-002	ALISSA	OH	1	RADIO ALT INDICATOR
622M87		SV	2	ACCELEROMETER
622-3015-001	SV080A	AR	1	PRIMARY SERVO
622-3374-002	ADISSV	OH	3	ATTITUDE DIRECTION INDICATOR
622-3670-001	TCR451	SV	1	DME
622-3915-001	IND40	SV	1	DME IND
622-3920-001	IND41B	OH	1	DME IND
622-3922-002	990C12	OH	1	HF COUPLER RACK

622-4038-001	RT-1300/ARC-186V	NE	1	RECEIVER TRANSMITTER
622-4038-001	RT-1300/ARC-186V	SV	1	RECEIVER TRANSMITTER
622-4160-015	DRIS5	OH	1	RAD ALT INDICATOR
622-4298-001	HSI45	OH	3	HORIZONTAL SITUATION IND
622-4523-015	CTL20	AR	3	COMM CTL
622-4524-087	CTL30	AR	1	NAV CONTROL
622-4526-015	CTL60	SV	2	ADF CONTROL
622-4527-015	CTL90	SV	1	TRANSPONDER CONTROL
622-4730-002	FPA80	SV	3	FLIGHT PROFILE ADV
622-4782-001	VSI-80A	OH	1	INDICATOR, VERTICAL SPEED
622-4782-004	VSIB8A	SV	1	INDICATOR, VERTICAL SPEED
622-4938-007	RM130	AR	2	INDICATOR, RADIO MAG
622-5369-002	99351	SV	2	MOUNTING BASE, ELEC EQUIPMENT
622-5462-004	728U-2	SV	1	HF R/T
622-5612-036	RTU-90	SV	1	RADIO TUNE UNIT
622-5656-001	PAC200	SV	1	HF COUPLER
622-6019-001	SSS-65	SV	1	SLIP SKID SENSOR
622-6137-001	VR32	OH	4	RCVR, VOR/LOC/GS/MB
622-6152-001	VHF22A	AR	6	TRANSCHEWER, VHF COMM
622-6152-011	VHF22A	OH	2	TRANSCHEWER, VHF COMM
622-6152-031	VHF22A	OH	2	TRANSCHEWER, VHF COMM
622-6174-001	RCP-65	SV	2	REMOTE COMPENSATION UNIT
622-6199-001	HPU74A	AR	1	H-S-+ PROCESSOR UNIT
622-6200-002	HCP-74	SV	1	H-S-+ CONTROL PANEL
622-6212-003	UMT12	NE	1	RACK
622-6321-001	RT-1250A	SV	4	ARC-182 COMM UNIT
622-6520-007	CTL22	OH	1	VHF CONTROL
622-6520-007	CTL22	AR	2	VHF CONTROL
622-6520-008	CTL22	AR	2	VHF CONTROL
622-6521-013	CTL32	SV	1	CONTROL
622-6521-014	CTL32	SV	2	NAV CTL
622-6521-015	CTL32	SV	3	NAV CTL
622-6523-005	CTL92	AR	2	TRANSPONDER CONTROL
622-6523-008	CTL92	AR	2	TRANSPONDER CONTROL
622-6523-203	CTL92	OH	2	TRANSPONDER CONTROL
622-6557-001	TCR230	AR	2	HF TRANSCHEWER
622-6590-001	CAD62	AR	5	CONTROL ADAPTER
622-6590-002	CAD62	AR	2	ADF/TRANS ADAPTER
622-6590-002	CAD62	NE	1	ADF/TRANS ADAPTER
622-6590-002	CAD62	SV	2	CONTROL ADAPTER
622-6614-022	CTL230	AR	1	HF CONTROL
622-7139-002	PAC230	SV	1	HF PROBE COUPLER
622-7154-002		AR	2	FAN MONITOR MODULE
622-7292-101	VHF-422A	AR	1	VHF COMM TRANSCHEWER
622-7382-101	ADF462	AR	1	ADF RECEIVER
622-7667-001	DDA-42	SV	3	ADAPTER, DME DIGITAL DISTANCE
622-7695-001	CAD-870G	AR	4	TRANSPONDER CTL ADAPTER
622-7695-002	CAD-870G	AR	4	TRANSPONDER CTL ADAPTER
622-7824-001	790511	SV	1	MOUNTING BASE, ELEC EQUIPMENT
622-8332-002	CAD31	SV	2	CONTROL ADAPTER
622-8365-003	PWR851A	SV	4	IAPS POWER SUPPLY
622-9116-014		AR	1	DISPLAY SELECT PANEL
622-9210-108	TDR94D	SV	3	TRANSPONDER
622-9301-003	RTA-852	SV	2	RECEIVER TRANSMITTER ANTENNA
622-9313-004	C-12019A	SV	4	ARC-182 CONTROL UNIT
622-9353-415		NS	1	TVI-920D ACAS Display
622-9405-001		SV	2	HF-9042 HF Coupler
622-9462-004	PRE-80C	OH	1	PRESELECTOR/ALERTER
622-9462-025	PRE-80C	SV	1	PRESELECTOR/ALERTER
622-9728-415		FN	1	TVI-920D TCAS VSI
625614-1-1		SV	1	CONTROL SENSOR TEMP
628-6492-001		SV	1	HF 230 RACK
628-6492-003		SV	1	RACK
628-8657-001		SV	1	RACK ASSY
629-7941-026		SV	1	BEECH 200 MOD FOR PN 622-6137-099
62980-2		NS	1	STRIKER
629-8503-001		SV	1	FLAT PLATE 12IN
6302-101	S0085-109	SV	1	MOUNTING TRAY
63-211378-003	890119-940	SV	2	INCLINOMETER PANEL
634-0333-001		SV	1	MOUNTING TRAY
634-1081-003		NE	1	PIGGYBACK BRACKET
634-1103-003		NE	4	ADAPTOR KIT, DUAL (UMT-12)
634-1104-003		NS	1	PIGGYBACK KIT
634-1112-001		NE	1	CONNECTOR KIT
634-1130-012		NE	1	CONNECTOR PLATE
634-1898-003		NE	4	CONNECTOR KIT

63700-025		NE	5	HEADSET
637-1981-001	637-1472-001	SV	1	HF CTL SELECTOR
637-6500-001	5821-01-077-3397	OH	1	PANEL ASSY
637R		SV	1	WHEATSTONE BRIDGE
638-6378-002	5998-01-251-6833	SV	2	CIRCUIT CARD ASSEMBLY
638-6378-003	5998-01-318-0299	OH	1	CIRCUIT CARD ASSEMBLY
638-6270-002	5998-01-100-6095	OH	2	CIRCUIT CARD ASSEMBLY
638-6273-002	5998-01-100-6089	OH	2	CIRCUIT CARD ASSEMBLY
64/55980		SV	4	SERVO ACTUATOR
6400-100-02	FV-3000	SV	2	MODULAR MISSION DISPLAY PROC
6402-11001-01		AR	1	MFD-640, No DSP or AUX, Gray
6402-11001-01		SV	1	MFD-640, No DSP or AUX, Gray
6402-11011-01	MFD-640	OH	1	FLAT PANEL INTEGRATED DISPLAY
64050-228-1		SV	1	AIRPEED INDICATOR
64142-720-1		SV	1	ALTIMETER
64210-002-1		SV	1	FUEL PRESSURE TRANSMITTER
64251-203-1		SV	1	MGB PRESSURE SWITCH
64279-508-2		SV	1	TRANSMITTER, OIL PRESSURE
6430-91015-102	2995-00-992-9399	SV	4	BLOWER/AIR INLET SE
644358-103		SV	1	MOUNTING TRAY
64514-203-1	704A-37-616-003	OH	2	TACHOMETER IND
64514-208-1	704A47616009	OH	2	TACHOMETER IND
64530-068-4	704A47612044	OH	1	TACHOMETER IND
64536-500-1	704A37612012	OH	1	TACHOMETER IND, ROTOR
64536-501-1	704A47612071	OH	1	IND, TACH ROTOR CO-PILOT
64538-305-1	704A47612092	OH	1	NG INDICATOR
64538-308-1		OH	1	TACHOMETER IND
64-55980		SV	1	SERVO ACTUATOR
64-55990		NE	1	SERVO ACTUATOR FAS/20/MB/11C/P
6461-1		SV	1	ADF CONTROL
646-5410-001	5998-01-251-4580	SV	1	CIRCUIT CARD ASSEMBLY
64807-605-1		OH	1	INDICATOR, OIL TEMP MGB
64809-417-1		OH	1	INDICATOR, OIL MGB
64809-421-1	704A47-641-028	OH	1	INDICATOR, HYD PRESS MAIN
64809-617-1	704A47641085	OH	1	OIL PRESS INDICATOR MGB
64838-006-1		OH	1	PRESS IND
64905-005-1	704A47-730-007	OH	1	INDICATOR, PITCH
64905-006-1	704A47-730-008	OH	1	INDICATOR, PITCH
6490-60220-012		SV	1	FIRE WARN TEST
64975-020-1	704A47-612-070	OH	1	INDICATOR, NR
6500-037		SV	4	DISPLAY
65008-D02		NE	2	CONNECTOR RAIL
65008-D04		NE	3	CONNECTOR RAIL
65009-004-513		NS	1	CONN KIT
6501-1051	105-90845	NE	2	RPM INDICATOR
6501-1056		OH	1	TACHOMETER
6502-3030	206-070-265-7	OH	1	INDICATOR, DUAL TACHOMETER
6502-3031	206-070-265-11	OH	1	INDICATOR, DUAL TACHOMETER
6503A-1058	704A-47-612-042	SV	1	TACHOMETER
65053-208		NS	5	CONN KIT
6505A-3061	117-902011-1	OH	1	TRIPLE TACH-
6505A-3068		SV	1	TRIPLE TACHOMETER
65-0648-1	209-075-325-011	SV	1	INDICATOR, RPM
65-0911-5		SV	1	LIGHT ANNUNCIATOR PANEL
65-0911-7		SV	1	LIGHT ANNUNCIATOR PANEL
65-10051		NS	1	LIGHT
65-1005-1		SV	1	AOA INDEXER
65-1-50		SV	1	AAU SPC
65550-04023-103	30-326E-7	SV	1	AMP, SMOKE DETECTOR
660-0001-001		SV	1	MONITOR
6600156-032	19710/2R62058	NS	4	RUDDER TRIM ROTARY ACTUATOR
6600156-032	2R62058	NS	1	RUDDER TRIM ROTARY ACTUATOR
6601-1004		SV	1	RATE OF CLIMB IND
6601-1004		SV	1	VERTICAL SPEED INDICATOR
6607-1-90A		NE	6	OIL PRESSURE WARNING SWITCH
66084416-7		SV	1	WARNING LIGHT CONTROL UNIT
6620-01-594-9063	9813-25-21	OH	2	DUAL TORQUE IND
66503ASSY213778		SV	1	ENGINE SYNC
66969-04		SV	1	TCAS
6700-1225-900		NE	1	REGULATOR VACUUM LIFEPORT
6700-1225-900		NE	1	REGULATOR VACUUM LIFEPORT
673529-02		NE	1	INU PLENUM
674-0004-000		NE	1	TRANSFORMER, PWR
682-112-45-000		SV	1	NAV CONTROL
6895173-B		SV	1	FILTER
6895D1-6-5-5		SV	1	IMPACT SWITCH

6900020-000		SV	1	POWER SUPPLY
6900053-001		OH	1	POWER SUPPLY
6CL6		NS	10	TUBE
6M-40U		SV	4	DISPLAY
700-00159-001		SV	1	SATELLITE RADIO RECEIVER
7000299-901	PC702	OH	1	HELIPLOTT CONTROLLER
7000299-903	PC702	OH	1	HELIPLOTT CONTROLLER
7000299-907	PC702	OH	1	HELIPLOTT CONTROLLER
7000300-901	AS-702	OH	1	AIRSPEED SENSOR
7000466-914	AD650H	OH	3	ADI
7000466-915	AD650H	OH	2	ADI
7000466-925	AD650H	OH	1	ADI
7000466-935	AD650H	OH	1	ADI
7000469-902	RD650A	AR	1	H-S-I
7000469-903	RD650B	OH	1	H-S-I
7000469-909	RD650A	OH	1	HORIZON SITUATION IND
7000605-902	MS702	OH	2	MODE SELECTOR
7000789-901	ZC301	AR	4	FLT COMP
7000836-911	AD500C	OH	1	ADI
7000836-912	AD500C	OH	1	ADI
7000836-922	AD500C	OH	1	ADI
7000839-901	RA315	OH	2	RADIO ALTIMETER INDICATOR
7000850-571	GH222	OH	2	INDICATOR, ATT DIRECTOR
7000850-771		OH	1	INDICATOR, ATT DIRECTOR
70-009H000A265A		NS	1	HOSE ASSY
7001179-966	RD550	SV	1	H.S.I.
7001182-902	AD-550A	OH	1	ATTITUDE DIRECTION IND
7001182-904	AD-550B	OH	1	ATTITUDE DIRECTION IND
7001237-6		SV	1	ANNUNCIATOR PANEL
7001305-901	AN700	OH	1	ACTUATOR POSITION IND
7001410-901	SM410	OH	2	ROD END, ACTUATOR ASSY
7001410-902	SM410	OH	2	ROD END, ACTUATOR ASSY
7001410-903	SM410	OH	2	ROD END, ACTUATOR ASSY
7001410-904	SM410	OH	2	ROD END, ACTUATOR ASSY
70-0158-1	76550-01008-101	SV	1	DIMMER CONTROL
70-0158-5		SV	1	DIMMER CONTROL
700-1710-001		SV	1	CONFRG MODULE
7001840-901		SV	1	RT-300 RAD ALT R/T
7002-060		SV	6	7IN LCD MONITOR
7002-061		SV	6	7IN LCD MONITOR
7002353-901	AZ649	OH	1	AIR DATA SENSOR
7002353-902	AZ649	OH	2	AIR DATA SENSOR
7002353-913	AZ649	OH	8	AIR DATA SENSOR
7002353-913	AZ649	NE	5	AIR DATA SENSOR
7002412-902		SV	2	AL-200 AIR DATA PRESELECT CONTROLLER
7002412-904	AL300	SV	2	ALTITUDE PRESELECT CONTROLLER
7002800-801	SM725	OH	2	ACTUATOR
7002800-804	SM725	OH	2	ACTUATOR
7002800-901	SM725	OH	2	ACTUATOR
7002800-912	SM725	OH	2	ACTUATOR
7002800-914	SM725	OH	2	ACTUATOR
7002860-903	SI-225A	OH	1	MACH AIRSPEED INDICATOR
7002860-908	SI-285	OH	1	AIRSPEED IND
7003180-901		SV	1	SZ-400 STABILITY AUG COMPUTER
7003183-904		SV	2	FLIGHT COMPUTER
7003183-932	FZ-700	SV	1	FLIGHT COMPUTER
7003897-923	PC-400	SV	1	AUTOPILOT CONTROL
7004110-901	SM510	OH	2	CONTROL ROD ASSEMBLY
7004123-313	SC800	SV	1	SENSOR SOURCE CONTROL
7004206-901	SP-717	SV	2	CSAS COMPUTER
7004402-977	NZ920	AR	2	NAVIGATION COMPUTER
7004402-978	NZ920	AR	1	NAVIGATION COMPUTER
7004402-997	NZ920	AR	1	NAVIGATION COMPUTER
7004577-902	VN801	SV	1	VNAV CTL
7005383-911	TM410	OH	1	TRIM SERVO
700700-947		SV	1	COMPUTER
7007062-932	MC800	SV	1	MODE CONTROLLER
7007062-941	MC-800	SV	1	MFD CONTROLLER
7007689-905	IJ-410	SV	1	RADAR - PARALLEL EPIS INTERFACE
7007700-201		FN	2	Radar Indicator
7007700-803		AR	1	Weather Radar Indicator
7007990-902	PC880	SV	1	TURN PITCH CONTROL
7008138-903		SV	3	DIGITAL FLIGHT CONTROL COMPUTER
7008470-822		AR	1	WU-650 RADAR R.T.A.
7008470-914		US	1	WU-650 RADAR R.T.A.
7008470-924		OH	1	WU-450 RADAR R.T.A.

7008471-7418		FN	1	Wx Controller for RDR-7000
7008471-7710		FN	1	WC-7000 RADAR CONTROLLER
7008471-7712		FN	1	WC-7000 RADAR CONTROLLER
7009289-804	MGB20	SV	1	SYMBOL GENERATOR
700-D36115A-004		SV	1	MARKER CONTROL HEAD
700-D36407A-006		SV	1	COMM CTL
700-D36409A-004		SV	1	NAV CONTROL HEAD
700-D36409A-005		SV	1	NAV CONTROL HEAD
700-D36411A-004		SV	1	ADF CONTROL HEAD
700-D36411A-005		SV	1	ADF CONTROL HEAD
700-D36415A-003		SV	1	MKR PANEL
700-D36415A-004		SV	1	MKR PANEL
700Y17-183587		NS	1	FREQ SELECT
7011672-606	SG-605	SV	1	SYMBOL GENERATOR
7011673-661		SV	1	MFD SYMBOL GENERATOR
7011673-667	MG-605	SV	1	MFD SYMBOL GENERATOR EFS
7012100-821	RM850	SV	1	RADIO MANAGEMENT UNIT
7012100-825		AR	4	RM-850 RMU, CRT, 8.33 kHz, TCAS
7012409-901	SM512	OH	1	PITCH ACTUATOR ASSY
7012640-901	WU870	SV	2	RADAR R.T.A.
7012640-901		AR	1	WU-870 Radar Antenna
7012693-901		SV	3	SERVO MONITOR
7012977-707		AR	1	DISPLAY CONTROL
7012977-772		AR	1	DISPLAY CONTROL
7013348-921	DA800	AR	1	DATA ACQUISITION UNIT
7013512-912		SV	1	CONTROLLER, BEACON
7014700-601		AR	2	AZ-850 MICRO AIR DATA COMPUTER
7014803-901		SV	1	RACK
7014840-801		SV	1	INSTALLATION MODULE
7016000-901	DL-900	SV	2	DATA LOADER
7016000-902	DL-900	SV	3	DATA LOADER
7016954-907	R-553	SV	1	INSTRUMENT REMOTE CONTR
7016986-723	DC-550	SV	1	DISPLAY CONTROL
7018352-6		NS	1	CONNECTOR
70219-01041-044		SV	1	ABSORBER
70-2420-8TAS600	9900BX	SV	1	TRAFFIC ADVISORY SYSTEM
70250-01004-101	9059-1	SV	4	PARKING BRAKE VALVE
7025-21-258-0587		SV	2	DATA ACQUISITION UNIT
7025891-901		SV	1	PROTECTIVE DEVICE
70265N02D01		OH	1	BAROMETRIC ALTIMETER (BLACK)
7028432-1902		FN	2	Actuator I/O Proc (AIOP) Modu
7029782-1912		FN	2	MAU-12L Modular Avionics Unit 12 slot
7030-C27	7030	SV	1	VSI
7030-C29	7030	SV	1	VSI
7036333-1906		FN	2	CIO-AP2 Dual Chan Generic CIO Module
7036410-1904		NE	2	MAU ADVANCED GRAPHICS
7036410-1904		FN	4	MAU advanced grap. Module
7038231-1801		FN	4	NIC-210 Network Interface Card (NIC)
7038248-1901		FN	4	PWR-200 Power Supply Module
703A53-0000-04		SV	1	OIL TANK
704A31-211-020		NS	10	FLEXIBLE MONTING
704A34410035		NS	1	PIPE
704A35333053	5985-14-534-7649	NE	1	MOBILE ANTENNA
704A37641095		SV	1	HYD PRESSURE EMERG IND
704A37643002		SV	1	FUEL PRESSURE TRANSMITTER
704A44820006		OH	1	RELAY, BREAKING CURCUIT
704A45751263	7900100-10M10.0W10.0	SV	1	VIDEO RADAR UNIT
704A45751263	7900100-10M10.0W10.0	NE	1	VIDEO RADAR UNIT
704A46580088		SV	1	DERATING BOX
704A47310017		OH	1	SYSTEM UNIT, AIR DATA
704A47-315-011		NE	1	CONTROL UNIT, EGPWS
704A47621089		OH	1	INDICATOR, TORQUEMETER
7050A4252012		SV	1	PILOT SEAT
7050A4316017		SV	1	VEHD
705906-801	RT1168/ARC164V	OH	1	TRANSCENER
705906-802	RT1168/ARC164V	OH	1	TRANSCENER
705906-803	RT1168/ARC164V	OH	1	TRANSCENER
705906-804	RT1168/ARC164V	OH	1	TRANSCENER
706077-801	RT-1167/ARC-164V	SV	2	RECEIVER TRANSMITTER
706077-802	RT-1167/ARC-164V	SV	2	RECEIVER TRANSMITTER
706077-803	RT-1167/ARC-164V	SV	2	RECEIVER TRANSMITTER
706077-804	RT-1167/ARC-164V	SV	2	RECEIVER TRANSMITTER
706077-805	RT-1167/ARC-164V	SV	2	RECEIVER TRANSMITTER
706177-801	ARC-164	SV	6	TXR MOUNT
7064-4656	MS24178-D1	SV	2	LEACH RELAY 55 AMP
706567-801	C-10116	OH	2	CONTROL BOX, ELECTRICAL



706A31213063		SV	1	ECLAIRAGE PANNEAU PLAFOND
706A37-721-001		SV	4	TRANSDUCER, GLYCOL PRESS
707074-801	RT1168B/ARC164V	SV	4	TRANSCENER
707074-802	RT1168B/ARC164V	SV	4	TRANSCENER
707074-804	RT1168B/ARC164V	SV	4	TRANSCENER
707074-805	RT1168B/ARC164V	SV	2	TRANSCENER
707648-801	RT1505/ARC164V	SV	1	TRANSCENER
707648-802	RT1505/ARC164V	SV	1	TRANSCENER
707648-803	RT1505/ARC164V	SV	1	TRANSCENER
707648-804	RT1505/ARC164V	SV	1	TRANSCENER
709-0104-01-101		SV	1	BLADE ASSY MAIN ROTOR
709-0160-48-101		AR	1	TR BLADE ASSY
709-0160-55-101A1		NE	4	BUSHING OVERSIZE
70-907		NS	3	CONTACTOR
709149-801	5821-00-078-1342	SV	1	RCVR TRANS RADIO
709149-802	RT823ARC131	SV	2	RCVR TRANS RADIO
70EM016100		OH	1	MODULE REDUCTION GEAR ARRILUS 2K1
70HF10		NS	8	DIODE / RECTIFIER
7-101005	2915-00-716-1794	SV	2	DEFUEL/REFUEL VALVE
710696-100		SV	4	CABLE
71-2480		SV	1	TAS SYSTEM W/O DISPLAY
714042-9005		SV	3	PRINTER
716-686		SV	1	FUEL QTY IND
716-760-3		OH	1	INDICATOR PANEL, FUEL KG
716-760-4	704A47-653-057	OH	1	INDICATOR PANEL, FUEL
716-879	704A47-650-078	SV	1	INDICATOR, FUEL QUANTITY
7185-15	206-062-721-15	SV	1	LINEAR ACTUATOR
7200-0500-001		AR	1	ENGINE MONITOR
720-7719		SV	1	WHEEL
7220-2	204-070-483-003	NE	1	AIR OUTLET
7236-1-150		NS	1	SENSOR CONTROL
724855-801	C-2000	SV	1	MAGNASTAR ARTU
724855-802	C-2000	AR	3	MAGNASTAR ARTU
724855-803	C-2000	SV	1	MAGNASTAR ARTU
724866-805WH	724866-805	SV	1	HANDSET
724866-807WH	724866-807	SV	1	HANDSET
724866-808PD	724866-808	SV	1	HANDSET
724868-802	724868	SV	1	MOUNTING TRAY
724986-801		SV	5	AIU
724986-802		NE	1	AIU
725058-801		SV	1	COCKPIT PHONE
725729-802WH	725729-802	SV	2	CONFERENCE TABLE HANDSET
725729-807BK		SV	1	HANDSET
725729-807BK	725729-807	SV	2	HANDSET WITH RETRACT CORD
725729-807WH	725729-807	SV	5	HANDSET WITH RETRACT CORD
725729-815BK	725788-802BK	SV	1	HANDSET WITH RETRACT CORD
725729-815WH		SV	3	HANDSET WITH RETRACT CORD
7260151-415		NS	5	SEAT BELT
7-26-409		SV	1	INDICATOR
730152760A		SV	1	EXHAUST PIPE, EXTENDED
730152760A		SV	1	EXHAUST PIPE, EXTENDED
730152760C		SV	1	EXHAUST PIPE, EXTENDED
7315-0050-1		SV	1	ADAPTER
732-8101		SV	1	CONTROL STICK TRIGGER ASSY
73415-1460		NS	1	CONNECTOR KIT
736-3652	CU-3001-A	NS	1	MINIBOX
739CX-4-023		SV	1	AIRSPD
741C0000-03		SV	1	ACTUATOR TAIL ROTOR
743425-801	1LZU1-743425-801	NE	1	CONNECTOR KIT
744-082-3	704A47-671-031	SV	1	INDICATOR, FLOWMETER
749852-1-1		SV	3	CONTROL PANEL
75-0341-27		SV	1	LIGHT ASSY ANNUNCIATOR
75-0341-7		SV	1	LIGHT ASSY ANNUNCIATOR
7510100-711	RN2850	SV	1	INTEGRATED NAV UNIT
7510100-713	RN2-850B	SV	2	UNIT, INTEGRATED NAVIGATION
7510100-733	RN2-850	SV	1	UNIT, INTEGRATED NAVIGATION
7510124-920	MT-851	AR	1	MOUNT ASSY
7510700-765	RC2-833K	SV	2	COM UNIT, 25/8.33 KHZ, DIVERSITY
7510700-766	RC2-833E	SV	3	INTEGRATED COMM UNIT
7510700-901	RC2850	SV	2	INTEGRATED COMM UNIT
7510700-951	RC2852	SV	4	MODE S DIVERSITY XPDR
7511001-915	AV850A	SV	3	AUDIO CONTROL PANEL
751-2417-001		NS	2	CABLE
751-2417-002		NS	1	CABLE
7513006-911	DH851	SV	2	DME IND
7517455-902		SV	1	MOUNTING TRAY

7517900-55004	RT951	SV	2	TCAS COMPUTER
7517943-22		NS	200	CONTACT
7517943-9		NS	1	CONNECTOR
7519248-911		NS	4	CABLE ASSY
7519248-913		NS	4	CABLE ASSY
7519349-3		NE	1	SPLITTER, RF
75-258V2M1		SV	1	COMPUTER
75-270M2	75-270	SV	1	SFENA COMPUTER
754-0073-005	5826-01-065-9996	NE	1	PANEL LIGHTING
756-0115-300-101	MT-3317-101	NE	3	DFDAU TRAY ASSY (G200)
756-122		OH	1	ENGINE STARTER
76088-61043-050		SV	2	PILOT BEARING & HS I SWITCH
76088-61043-051		SV	2	CO-PILOT BEARING & HS I SWITCH
76088-60276-041		SV	1	FUSE BOX
761110-4	76900-01807-104	SV	1	AFCS AMPLIFIER ASSY
761111-3		SV	2	SLICE AMP
761112-3		SV	2	SLICE AMP
761240-1		SV	1	AFCS CONTROL PANEL
761272-3	76900-01804-103	OH	4	AFCS INDICATOR
761-6205-001	5930-00-911-1794	NE	1	SWITCH
761-7226-001		NS	2	SWITCH
7-6277G		SV	1	INDICATOR FEED UNIT
76378-200	KIT- 76378-200	SV	2	WINCH AGGREGATE
76378-300		AR	2	WINCH
76403-01104-041		SV	1	ADJUSTER ASSY, PEDAL
76450-00907-102		OH	1	INDICATOR
76450-01015-046		SV	1	PANEL ASSY
76450-01041-041		SV	1	HEATER CONTROL
76450-01072-109		OH	1	TORQUE IND-
76450-01076-102		OH	1	T.S IND-
76550-01001-103		SV	1	MASTER CAUTION PANEL
76550-01001-104	843766	SV	1	MASTER CAUTION PANEL
76550-02001-063		SV	1	COCKPIT FLOODLIGHT
76550-02014-042		SV	1	PANEL
76550-09005-102	PC00401C	SV	1	TRANSFORMER
76550-09005-104		SV	1	GENERATOR CONTROL UNIT
76600-02014-046		SV	1	RELAY
76600-04162-045		NE	1	HOLD DOWN/HF ANTENNA
76650-01802-102		OH	1	VTA ACTUATOR
76650-02802-103		OH	1	CONTROL VALV
7-676-10		NS	4	HOMING ADAPTOR
768-10		SV	1	NARDA ATTENUATOR
768-128		SV	1	TRANSMITTER, FUEL GAUGER
768-129		SV	1	TRANSMITTER, FUEL GAUGER
768-20		SV	2	NARDA ATTENUATOR
76900-01803-101		OH	1	CONTROL PANEL
76900-01805-102		SV	1	SWITCH
76900-01810-103	76900-01810-103B	SV	1	PEDAL DAMPER
76900-01851-042		SV	2	VTA AMP
771523-2		SV	1	AMP SLICE
772-0738-001	68071	SV	1	HF SLICE
772-5132-001		SV	1	MODE COUPLER
777-1029-002	714E3D	OH	1	CONTROL
777-1034-001	345A7A	SV	1	SENSOR, RATE OF TURN
777-1061-001	334C6	OH	1	PRIMARY SERVO
777-1061-001	334C6	AR	1	PRIMARY SERVO
777-1062-001	251B6	OH	1	MOUNTING SERVO
777-1062-001	251B6	AR	1	MOUNTING SERVO
7801-13000		SV	1	FUEL FLOW TRANSMITTER
780926-1	76900-01826-101	SV	1	AMPLIFIER
78200000-07	HAI-222-070-105	OH	1	INDICATOR
78200000-08	222-375-021-113	OH	1	TRIPLE TACH INDICATOR
78300000-03		OH	1	INDICATOR
78300000-09	222-375-071-107	OH	2	INDICATOR, TRIPLE TORQUEMETER
78340MK4C		SV	5	SARBE BEACON MK4C
785340-5-024	3117090-05	SV	1	CTRL UNIT ENGINE ELECTRONIC
787-6173-217	ADI-84	OH	1	FLIGHT DIRECTOR INDICATOR
787-6366-006		SV	2	CONTROL BOX, ADF
78-8051-9160-4	WX1000	AR	1	PROCESSOR
78-8051-9170-3	WX-1000	SV	1	STORMSCOPE DISPLAY
78-8051-9200-8	WX1000	SV	1	ANTENNA
78-8060-5900-9		AR	1	DISPLAY
7883470-011		SV	2	CAROUSEL SIX NAV UNIT
7892740-051		AR	1	CAROUSEL SIX CTL UNIT
78CF9919		OH	1	FLEXBALL CONTROL
7900100-10	7900100-10M10.0W10.0	SV	1	VIDEO RADAR UNIT

7900100-10	7900100-10M10.0W10.0	NE	1	VIDEO RADAR UNIT
792-6091-009	331A9G	OH	1	H.S.I INDICATOR
792-6091-011	331A9G	OH	1	H.S.I INDICATOR
792-6091-019	331A9G	OH	1	H.S.I INDICATOR
792-6216-001	51Y7A	OH	2	ADF RCVR
792-6275-001	614L13	SV	1	ADF CONTROL
792-6275-002	614L13	SV	1	ADF CONTROL
792-6672-002		OH	1	ADC
792-6784-001	351B6A	OH	1	MOUNTING SERVO
792-6784-001	351B6A	AR	4	MOUNTING SERVO
792795-1		SV	1	FUEL PROBE
794-165		SV	1	PROBE, FUEL GAUGE
794-166		SV	1	PROBE, FUEL GAUGE
7C304		SV	1	SWITCH
800006-1A		NE	1	RACK
800-010655-1		SV	1	PANEL
80-0093-1		SV	1	MASTER WARN PANEL
80-0093-5		SV	1	MASTER WARNING PANEL
800496-E	800496	SV	1	BATT TEMP
80-0500-33	222-375-010-149	SV	1	ANNUNCIATOR PANEL
80-0533-3		NE	1	PANEL ANNUNCIATOR
800-G-5392L	G5392L	SV	1	DUAL COMM CONTROL
800-G-5868C	G5868C	SV	1	DUAL COMM CONTROL
800J814AH19		SV	1	METER
80-1-026/H402A		SV	1	SWITCH PANEL
801-40011		SV	1	ENG-RPM-SENSOR
802-10-0006	HLD-7260	SV	1	SWFT BROAD BAND DUPLEXER
802-10-0016	SDU-7310	SV	1	SWFT BROAD BAND SDU
80265-00-0311	TNL-3100	SV	1	GPS
80265-01-0210	TNL2100	SV	1	GPS
80265-01-0234		SV	2	GPS SENSOR
802GCO1		NS	1	CIRCUIT BOARD
8032-1	704A44831118	SV	1	SERVOCONTROL/MAIN ROTOR
8033-3000	ACU-810	SV	1	AMPLIFIER COUPLER
804-001		SV	3	KING AIR SWITCH PANEL
804-10-0011	5895-01-538-5542	SV	4	DIPLEXER/LNA DAU-7050
8047-20		OH	1	STANDBY ALTMETER
805-001		SV	2	KING AIR SWITCH PANEL
80-500-1		SV	1	ANNUNCIATOR PANEL
805-10024-001		SV	1	MOUNTING TRAY
80654BSW		SV	1	HOVERMETER
80790A01		SV	1	RECEIVER DECCA MK 3
80792A03S303		SV	1	NAVIGATION COMPUTER UNIT
80792J40T090050		SV	1	COMPUTER RNAV2 S76A+
80794E5003		SV	1	CONTROL DISPLAY UNIT
80794NS301	80794	SV	1	CDU
80822-00-0235		SV	1	GPS
80822-10-0224		SV	1	GPS
8095361-2404	CC2024F	SV	1	CONTROL
8095444-4103		SV	1	NAV CONTROL CD413B
809908-3-2		SV	2	TRANSDUCER CABIN PRESSURE
81170753-4		NS	2	CARTRIDGE
8118		SV	3	CLOCK
8118-1		OH	1	CLOCK
8125-20		SV	1	VALVE
8136-AB-08	901F	SV	1	INDICATOR TACHYMETRIQUE
8136-BA	901F	SV	1	INDICATOR TACHYMETRIQUE
81438-00-0237	TNL2101	SV	2	GPS
81438-02-240D	TNL2101	SV	2	GPS
81439-00-0237	TNL2101	SV	2	GPS
81439-02-240B	TNL2101	SV	2	GPS
81439-02-240M	TNL2101	SV	2	GPS
81439-02-240P	TNL2101	SV	2	GPS
81439-32-240M	TNL2101	SV	1	GPS
81439-32-240N	TNL2101	SV	1	GPS
81439-32-240P	TNL2101	SV	1	GPS
81439-32-241P	TNL2101	SV	1	GPS
81440-00-0229		SV	3	GPS
81440-00-0233	TNL2101	SV	1	GPS
81440-00-0233		SV	2	GPS RECEIVER
81440-00-0238	TNL2101	SV	1	GPS
81440-00-0243M	TNL2101	SV	1	GPS
81440-00-0243N	TNL2101	SV	1	GPS
81440-00-0243P	TNL2101	SV	1	GPS
81440-02-0241J	TNL2101	SV	1	GPS
81440-02-0241M	TNL2101	SV	1	GPS

81440-02-0241N	TNL2101	SV	1	GPS
81440-02-0241P	TNL2101	SV	1	GPS
81440-02-0241Q	TNL2101	SV	1	GPS
81440-12-0241E		SV	1	GPS
81440-12-0241M		SV	1	RECEIVER GPS
81440-42-241M		SV	1	RECEIVER, GPS 2101U/APP+, NV
81440-42-241N		SV	1	RECEIVER, GPS 2101U/APP+, NV
81440-42-241P		SV	1	RECEIVER, GPS 2101U/0
81440-42-241Q		SV	1	RECEIVER, GPS 2101U/0
81448-21		NE	1	2101 I/O INSTALL KIT
81567404A102020		SV	1	SATELLITE DATA UNIT
817-10009-001		NE	1	KIT INSTALL L-BAND ANT 40N
81821/20		SV	1	DIPLEXER/LNA
81821/AA	81821/ACA	SV	2	TWO AXIS STAB PLATFORM
81821/FD1A001	81821CGA001	SV	1	TASPI/ACU ASSY
81821B01A001004	81821B01A001	SV	1	SATCOM ANTENNA ASSY
81821G01A001004	81821G01A001	SV	2	SATCOM ANTENNA ASSY
81B		SV	1	COAXIAL RESISTOR
81F09GX10-30		NE	1	FILTER
81N2581		NS	10	SOCKET, BAYONET
8210-007-01		AR	1	PROP GOVERNOR
822-1109-011	ADC3000	SV	3	AIR DATA COMPUTER
822-1-17		SV	2	COMM CONTROL
822-1349-001	SRT-2000	SV	1	SATELLITE DATA UNIT
822-1484-201		SV	2	OCM-3100 OPTIONS CONTROL MODUE
822-1484-241		SV	2	OCM 3100
822-2175-001		FN	7	CTL-22D
822-2177-003	CTL23D	SV	1	CONTROL UNIT VHF COM
822-2182-107	CTL93T	SV	1	TCAS CONTROL
822-2215-302	DBU-5000	SV	1	DATA BASE UNIT AFS
822-2578-050		NS	1	DIU-3110 Display Interface Unit
822-2578-051		FN	1	DIU-3110 Display Interface Unit
822-2578-051		SV	1	DIU-3110 Display Interface Unit
822835-5-105		SV	1	ELECTRONIC ENGINE CONTROL
822835-5-106		SV	1	ELECTRONIC ENGINE CONTROL
822835-5-107		SV	1	ELECTRONIC ENGINE CONTROL
8230B528	8230	OH	1	MAX ALLOWABLE AIRSPEED IND
82821CGA001	82821CGA	SV	1	TASPI/ACU ASSY
8330450100-1		NS	1	VACUUM OUTLET
834610-00-002		SV	1	TUBE, PITOT ELEC HEATED
8350-0262-03	AHRS500GA	SV	1	AHRS
8383AU		OH	1	INDICATOR PYROMETRIQUE
84303-210DEB		NS	1	PLUG
84327-50-XXXX		FN	2	1203C GPS/SBAS RECEIVER
8-436-10		OH	1	TACH INDICATOR
843-67-6	109-0729-33-1	OH	2	INDICATOR, VERTICAL SPEED
843-67-6-R	446000275	OH	1	INDICATOR, VERTICAL SPEED
8438-BA	901F	SV	1	INDICATOR TACHMETRIQUE
843772-149	76550-01001-149	SV	2	MASTER CAUTION/ADVISORY PANEL
8444-19477-30201		SV	1	RACK ASSY RNAV 2 MODIFIED
8502-600-1	1159SCAV408-1	SV	1	0-400 KTS MACH AIRSPEED
8502C-520LW		OH	1	AIRSPEED INDICATOR
8503S20LW-MB5V-ES		OH	1	BAROMETRIC ALTMETER
85097-02	85097	NE	1	HOBBS HOUR METER
85-41320-1340		NS	3	PRINTED CIRCUIT BOARD ASSY
8590A	HP8590A	SV	1	SPECTRUM ANALYZER
8595-03	704A47152004	OH	1	VERTICAL GYRO
85A30-C24-AA0495	74-00040-002	NS	1	RESISTOR
85AP-105		NE	1	8500C+APPLIC KIT B0105
85AP-135		NE	1	8500C+APPLIC KIT EC135
85AP-135DS		NE	3	8500C+APPLIC KIT EC135DS
85B-ECD		NE	1	8500C(+J)T&B KIT, BASIC, ECD
85B-FA		NE	1	FASTRACK ASSY BASIC
85B-FA		NE	1	FASTRACK ASSY, BASIC
85B-SA		NE	1	STROBEX ASSY, BASIC
8-6137-1A		NS	4	CAM
875A0000-02		SV	4	TAIL ROTOR SERVO ACTUATOR
875A0000-02		NE	4	TAIL ROTOR SERVO ACTUATOR
87F2959		NS	100	PLUG
8800-T		SV	1	ALTITUDE SENSOR
885-2142		NS	1	TEST JACK
890114-940	3AA78/63-211397-001	AR	2	LASERCAM BRACKET
89095-0031		SV	2	COCKPIT VOICE RECORDER
892121-0350	892121-0350-R	SV	1	CONTROL UNIT
8948710G001	8948710G1	SV	1	COL
894TS05NY		SV	1	SWTICH LANDING GEAR

8A584-001	206-040-555-001	NE	1	THERMOSTAT
8D120WAA1	206-070-265-7	OH	1	INDICATOR, TACHOMETER
8D1278WAD1		OH	1	INDICATOR, ROTOR SPEED
8D181LZE4		SV	1	TACH IND
8D181LZF4		SV	2	TACH IND
8D181WB84		SV	1	INDICATOR
8E5003417-00	704A46830026	SV	1	POWER SUPPLY UNIT, STROBE
8TW003-491-00		NE	10	PUMP
900-000-05		NE	14	RING ALUMINUM
90004-00311111009	90004	SV	1	AIR DATA COMPUTER
90004-00311131000	90004	SV	1	AIR DATA COMPUTER
90004-00321111000	90004	SV	1	AIR DATA COMPUTER
90004-00321111009		SV	1	AIR DATA COMPUTER
90004-00321111009		FN	5	Air Data Computer
90004-00321111051	90004	SV	1	AIR DATA COMPUTER
90004-00342111038		SV	1	AIR DATA COMPUTER
90004-00343111061	90004	SV	1	AIR DATA COMPUTER
90004-00348111011		SV	1	AIR DATA COMPUTER
900101-806	RT-1505A/ARC164V	SV	1	UHF AIRBORNE RADIO
900101-807	RT-1505A/ARC164V	SV	1	UHF AIRBORNE RADIO
900-700-036-72		OH	1	OXYGEN REGULATOR
9007000-57001		SV	1	MST-70B ADS-8 Out Xpr
9009-3004	206-075-188-001	OH	1	OIL TEMP PRESS IND
9000D51508	D51508	SV	1	RECORDER, CVFDR
900E2752137-101		SV	1	PANEL
901002-11	706-11	OH	1	GYRO DISPLACEMENT
9011-100-2013	16020-3001	NE	12	RF FILTER
901-12631		SV	1	UNIT, 139 VXP POWER SUPPLY
90153-5	222-375-025-111	OH	2	INDICATOR, DUAL AMMETER
9020-3026		SV	1	PRESSURE SWITCH
9020-3042	222-375-025-111	OH	2	DUAL AMMETER IND
902205-804		NE	1	MAGNASTAR ISDN TERM ADPT
90245A012		NS	1	THREAD REPAIR KIT
9030-1017		NE	1	PRESSURE INDICATOR
9030-1017		SV	1	PRESSURE INDICATOR
9030-3046	260-2351-1	OH	1	IND-, DUAL FUEL PRESSURE
9036-3010	109-0729-27-1	SV	1	OIL/TEMP PRESSURE IND
90-380037-1		SV	1	INDICATOR CONDITIONER UNIT
90380V5		OH	3	ARTIFICIAL HORIZON
906-16789		SV	1	ACCELEROMETER/JCP W/ D38999
90R8554		NS	2	SENSOR
90G196-2		SV	1	PRESSURE SWITCH
910020-238	AIRSHOW	SV	1	AIRSHOW DIJ
911010-1		NE	1	TTD CONTROLLER
911010-1		SV	1	TTD CONTROLLER
911010-2		NE	1	AIRSHOW TTD CONTROLLER
911010-2		AR	2	AIRSHOW TTD CONTROLLER
9120-1000-21		SV	1	UNIT
913210-3-1-2-2-X-2	913200AR-3-1-2-2-X-2	SV	1	ENGINE TREND MONITOR
9-138-15		SV	1	FUEL SV IND
914095-100		SV	1	AERA DISTRIBUTION BOX
917-1208-000		NE	7	CAPACITOR, VARIABLE
919C70200		NE	3	RF SWITCH
9200-18000-02		FN	1	Camera IRIS "180" degree
9203CF		SV	4	ANTENNA, DECCA
92070-55017-041		SV	1	PANEL ASSEMBLY, NO-3 RELAY
92070-55017-042		SV	4	PANEL ASSEMBLY, NO-4 RELAY
92070-55039-011		SV	1	MOD KIT, WIRING PUMP SENSOR
92101-11003-102		SV	1	BARREL ASSEMBLY, TRIPITCH ROD
9222-0130-002		SV	1	ROSEN AVIATION
92382LR008-02		NE	6	OUTER SLEEVE
923V11		SV	1	HORIZON GYRO
92410-04830-106		AR	1	TRIM SERVO ROLL
92410-04830-106	DR3840M23-2	SV	1	TRIM SERVO ROLL
92550-01817-101	0230636-006	NE	1	SEARCHLIGHT
92550-02813-104		SV	1	CONTROLLER, RIPS
92602-21400-049	21400-049	NE	4	RAD ALT XMT
926125-10-1	214000-049	NE	4	RAD ALT HARNESS
9290K98		SV	5	SPRING
930121-7		NS	1	CABLE ASSY
930-500-25-1		SV	1	SEARCH LIGHT
930-500-50-1		SV	3	DUAL SEARCH LIGHT
932810-01		NE	1	BARO CONVERTER
933612-02		SV	1	SERIAL CONVERTER
933810-01	6220-01-232-7723	SV	2	IRS/RMS ADAPTER
93921-1	13636-93921-1	NE	1	MOUNTING TRAY

93-A055-95		SV	1	AREA MIC
93-A151-20	A151B	SV	1	CVR CONTROL
93-A151-30		OH	1	CVR CONTROL UNIT
93-A152-70		SV	1	CVR CONTROL
941063-1	TAC200	SV	1	DUAL AUDIO CONTROLLER
94290701-01	HAI-222-070-145	SV	1	INDICATOR, TOT
94290703-01	HAI-222-070-135	SV	1	INDICATOR, TACH
943210/943200-3	943200-3	SV	1	KEY AND DISPLAY PANEL
9506-0-0		NE	2	CREW SEAT 230/260
9507-0-0		NE	3	PASSENGER SEAT
9507-0-0-3X21310		OH	1	PASSENGER SEAT LH
9507-0-0-XXXX3XX		NE	1	PASSENGER SEAT
95-210	MODEL95-210	AR	1	NAT PANEL
95-220-1G		NS	1	BLOWER
95-40-17-06-56911		NS	1	INDICATOR
95-40-18-86-64235		NS	1	SWITCH ASSY
9543705-1		OH	1	NOSE WHEEL ASSY
95-46-11-S2-70583		OH	1	SWITCH ASSY
9550BN577	9550B	OH	1	TURN AND SLIP
9599-607-12305	9599-	SV	2	RAD ALT ANTENNA
9599607-14169		SV	1	RADIO ALTIMETER INDICATOR
9599-607-14191	IND 821A	SV	1	RAD ALT INDICATOR
9599-607-4535		SV	1	RADIO ALTIMETER TRANSMITTER
95-XX-17-H6-50624		NE	3	CIRCUIT BREAKER
95-XX-18-86-64438	95-XX	NS	1	CAP ASSY
95-XX-18-86-64439	95-XX	NS	1	CAP ASSY
95-XXX-6D1-19552		NS	2	CAP ASSY
9601-2		SV	2	SEAT BELT
9603-560-L5		NE	1	FRONT SUPPORT BAR LH
9603-560-R5		NE	1	FRONT SUPPORT BAR RH
9603-570-L5		NE	1	REAR SUPPORT BAR LH
9603-570-R5		NE	1	REAR SUPPORT BAR RH
9603A	704A46860001	SV	1	PANEL, FAILURE ADVISORY
960453-1	7515	SV	1	RESERVOIR ASSY HYDRAULIC 375CUIN
9606-10-03-3X21910R		OH	1	PILOTSEAT HEIGHT ADJ
9609-505-RX		NE	1	REAR MEDIUM SUPPORT BAR
9609-505-RX		NE	1	REAR MEDIUM SUPPORT BAR
96-10-500-50		NS	3	FASTNER
96-10-500-50		NE	3	FASTENER
96202(B)	96202	FN	2	LAP JACKET
962820-1		SV	1	FUEL/AIR DATA COMPUTER
962820-2		SV	1	AIR DATA COMPUTER
962830A-1-S-8	ADC2000	SV	1	FUEL AIR DATA COMPUTER
962830AR-3-X		SV	1	FUEL/AIRDATA COMPUTER
962831A-3-S-8	ADC2000	SV	1	FUEL AIR DATA COMPUTER
962861-01-01	ADC-6000R	SV	2	RVSM AIR DATA COMPUTER
963001-103		SV	3	ENCODER DIGITAL INTERFACE BOX
963A05-100-015		NE	1	CABLE ASSY
964-0421-001	2940	OH	1	8300 AIR DATA SENSOR
965-0678-006	MKV	SV	1	GPWS COMPUTER
965-0686-001	MKV	SV	2	MARK VI GPWS
965-0686-020	MKV	SV	2	MARK VI GPWS
965-1198-005		AR	1	EGPWS
965-1595-020		SV	1	EGPWS PROCESSOR
96774-18-1842-7	96774-412-075-205-101	OH	3	PRESSURE TORQUE TRANSMITTER
96774-412-075-205-101	96774-18-1842-7	OH	2	PRESSURE TORQUE TRANSDUCER
9701-500-5		NE	2	HIGH SUPPORT FRAME ALU
97-3057-10		NS	1	CONNECTOR
97-389002		SV	1	TRANSMITTER TORQUE PRESS
97499-18-1842-7	97499-412-075-205-101	OH	1	TORQUE PRESSURE TRANSMITTER
97536-02	23308	OH	1	INDICATOR
9768-03	NDN9768	SV	1	FLT PATH CTL COMPUTER
978F-1D		SV	1	INSTRUMENT TEST SET
979-0223-001		SV	1	BIAXIAL ACCELEROMETER, LINEAR
979142-1-1		NE	1	VALVE OUTLINE
9809-0-0		NE	2	PASSENGER SEAT
981-24C28		SV	2	NAV SWITCH RELAY
9813-25-15	412-075-008-101	SV	1	DUAL TORQUE IND
983403-1	0401907-G1	OH	1	ANTENNA
98571/843766	76550-01001-104	SV	2	MASTER CAUTION/WARNING PANEL
98571/843772	76550-01001-103	SV	1	MASTER CAUTION/ADVISORY PANEL
987-6038-001		SV	10	DATA PORT INTERFACE
990-2993-001	M7852	NE	8	AUDIO AMPLIFIER
990-3250-001	M1084PS	SV	1	AUDIO AMPLIFIER
990-3273-002	M1081PS	SV	1	AUDIO AMPLIFIER
990-3307-002	S4000-2	SV	1	PASSENGER BRIEFING SYSTEM

990-3333-069	B1045-F356-HMD3	SV	1	AUDIO CONTROL SYSTEM
990-3334-112	B1035-J290-HWZ5	SV	2	AUDIO CONTROL SYSTEM
990-3338-000		SV	1	AUDIO AMP SUMMING
990-3342-028		SV	1	PANEL AUDIO SELECTOR
990-3392-001	M1086	SV	3	AUDIO AMP
990-3392-002	M1086H	SV	1	AUDIO AMP
990-3393-001		SV	2	M1084 AUDIO AMP
990-4063-002	LF91	NE	4	SPEAKER
990-4074-002		SV	1	AUDIO AMP
990-4099-001	VDA600	SV	1	VIDEO DISTRIBUTION AMP
990-4140-005		SV	1	DISPLAY
990-4144-001		SV	2	DISPLAY
990-4150-002	HB1500AAB	SV	1	MONITOR DISPLAY
990-4152-027		SV	2	CABIN MANAGEMENT SYSTEM
990-4300-001	AS200	SV	1	AUDIO SYSTEM
990-4500-001		SV	1	CABIN MANAGEMENT SYSTEM
990-5734-100		NE	1	XM CONTROL HEAD
990-6000-000	M4010	SV	1	DIGITAL BRIEFING SYSTEM
990-6820-001		SV	1	CABIN MANAGEMENT SYSTEM
990-9104-036		SV	1	CABIN MANAGEMENT SYSTEM
990-9104-037		SV	1	CABIN MANAGEMENT SYSTEM
990-9700-004		SV	1	CABIN LAN
990-E1900-002	1901-102H	NE	4	19IN HD MONITOR
990-G7104-004		SV	1	CABIN MANAGEMENT SYSTEM
99-230-181-19640	A0164	NS	1	IND- LIGHT
996-G7000-002		SV	4	C-SERIES OLED
996-G7000-224		SV	6	OLED DISPLAY
996-G7002-140		SV	1	CABIN MANAGEMENT SYSTEM
996-G7004-012		SV	1	COCKPIT SWITCH
996-G7100-004		SV	2	SWITCH PANEL
996-G7100-144		SV	1	SWITCH PANEL
996-G7101-004		SV	1	SWITCH PANEL
999-0057-27-619		NE	7	SHM
999-0300-55-102		NE	1	ELBOW FITTING
999-1000-04-103		NE	2	SPRING HELICAL TENSION
9A2043		SV	8	HOUSING
9B-81040-15		SV	1	ANALOG INTERFACE UNIT
9B-81040-26		SV	1	ANALOG INTERFACE UNIT
9D0271-101T	CB4020V3N6-750	NS	10	RIGHT ANGLE MOUNT
A0164BC050014LT	A1077	NS	3	SCREW
A1077F	76550-00902-103	SV	1	RELAY
A119-3040-1		OH	2	COMPRESSOR CLUTCH ASSY AC
A119-3040-1		NS	2	COMPRESSOR CLUTCH ASSY AC
A119-5010-T7		NE	2	AC TUBE
A119-6014-1		NE	1	AIR BOX ASSY
A119-6018-2		NE	2	RESISTOR PLATE ASSY
A119-6018-5		NE	3	BLOWER CONDENSER ASSY
A119-6020-2		NE	9	EVAPORATOR AIRCOMM
A119-8422-3		NE	1	ASSY RELAY PANEL
A1218	A1280	SV	4	ACCELEROMETER
A1280-1	A1301	NS	1	LENS
A13018-5	A15-L	SV	1	INERTIA, CVFDR
A14.3	A14.05	NS	2	SEAT BELT
A146A2209DW		NE	8	SEAL MATERIAL
A1500		NS	2	CIRCUIT BOARD
A153A2312RB		NE	10	EXTD RUBBER SILICONE
A1600		SV	1	INDICATOR, TURN & SLIP
A19A6196-2		SV	1	DC MOTOR
A24081-1	2995-00-992-9399	SV	3	BLOWER, AIR INLET
A2455		SV	1	SWITCH PANEL_WINDOW SHADE
A2475		SV	1	SWITCH PANEL
A24A9430-1		SV	1	WINDOW TEMP CONTROL
A2928710001	A29287	OH	2	INDICATOR SLAVE TRUE AIRSPEED
A301-61ACVR	A301C	SV	2	ICS CONTROL
A301CM222	A3374	NE	1	GAUGE
A33747	A3392	NS	1	LINER
A33925	A-35-	AR	1	HEAT SHIELD
A41322.10.003		OH	2	ALTMETER
A413A.HAD.-CF-14/28	A413A	SV	2	POWER SUPPLY
A413A.HAD.-CF-14/28	HAD.-CF-14/28	SV	1	POWER SUPPLY
A414371066	A4442	SV	2	MACH AIRSPEED
A4442000002		SV	2	PITOT TUBE
A490ATSCF	01-0770062-03	SV	1	POWER SUPPLY
A490ATSCF14/28	A490A	SV	3	POWER SUPPLY
A490ATSF14/28	01-0285055-18	SV	3	POWER SUPPLY
A596A07		NE	2	JUNCTION

A691-2		SV	1	AUDIO AMP-
A6912-1	A692-	SV	1	AMPLIFIER SUMMING, HUMS
A692-1	SGB-A692-1	SV	1	AUDIO AMP-
A-700AAP	205-075-642-1	SV	1	CUTOUT RELAY GENERATOR
A-700ZC-7	205-075-642-1	SV	1	CUTOUT RELAY GENERATOR
A-700ZG		SV	1	VOLT REGULATOR
A-703G		SV	1	VOLT REGULATOR
A-772XTA		SV	1	RELAY
A81-59	5831-00-539-1471	SV	1	CONTROL PANEL
A825F	AA20-	SV	1	GENERATOR CONTRL
AB841308E022F		NE	16	SHM
AB82A06A		NE	7	LOCKTAB WASHER
AA12S-001		SV	2	AUDIO PANEL
AA20-KC	AA31-	NS	2	P-A- CONTROL INSTALL KIT
AA31-002	AA32-	SV	1	AUDIO INTERFACE
AA32-001	AA34-	NE	1	AUDIO INTERFACE
AA34-001		SV	1	NAT MODULE
AA34-105		SV	1	NAT MODULE
AA34-200	AA82-	SV	3	AUDIO INTERFACE
AA3701-2		SV	3	ADF RCVR
AA82-060		SV	1	6 PLACE STEREO INTERCOM
AA83-001		SV	2	PLT/COPLT STEREO INTERFACE
AA95-210	AA95-	SV	2	AUDIO BOX
AA95-488	AA95	SV	2	STATION BOX
AA95-748		SV	1	AUDIO PANEL
AA95-894		SV	2	AUDIO CONTROL PANEL
AA95-894		NE	1	AUDIO CONTROL PANEL
AAC-4483A		SV	1	CONTROL BOX
AAC4616		SV	1	NAV HEAD CONTROL
AB44-12	AB5-5	SV	1	RELIEF VALVE
AB5-5	ABD21	SV	1	SEAT BELT
ABD211-01		SV	1	ANTENNA
ABD211-03		SV	1	ANTENNA
ABU-5/A	86000-1107	OH	1	CLOCK ACFT MECH
AC131	AC-16	SV	1	AIRSPEED INDICATOR
AC7-13280B	AC899	SV	1	CONTROLLER
ACA103		SV	1	RPM SIGNAL TX
ACA109		SV	1	RPM SIGNAL TX
ACA-AS117-02-00		SV	1	ABSORBER ASSY
ACA-AS117-03.00		NE	1	VIBRATION ABSORBER
ACS-1278	ACU61	SV	1	AUDIO MIXER PANEL
ACS-2080	ACS-2080-300	SV	3	AIR COMM AUDIO MIXER
ACT-01-001		SV	1	AC TRANZORB ASSY
ACT-01-001		SV	1	AC TRANZORB ASSY
AD.32.32.35F.28.1.EA		FN	1	Air Data Display >CONFRG 8104<
AD10077D1527	AD1007	NS	1	CODE GENERATOR
AD43011-01C	013-1909-010	SV	1	RAD ALT ANTENNA
ADS43010-1AC	ADS43010	NE	2	ANTENNA
AE6100E0360-180	AE702	NS	1	HOSE ASSY
AE70280084-180	AE981	NS	1	HOSE ASSY
AE705780-3		NE	1	HOSE ASSY
AE705827-2		NE	1	HOSE ASSY NG12
AE706292-4		SV	1	HOSE ASSY
AE706292-5		SV	1	HOSE ASSY
AE98148N	AFD50	NS	1	ADAPTER ASSY
AFD50-24-1085N-6094	80937363	NS	2	CONNECTOR
AFG013176		AR	1	INERTIA REEL MOUNT
AFG0391653	AI-16	SV	1	STRAP BLOCKING
AFG0424879		NE	6	INERTIA REEL MOUNT
AFG763300-02		NE	4	FUEL INDICATOR
AG34		AR	1	TACH
AHA1121M0D1-2-3-4-5		SV	2	BRAKE HAND ASSY
AI-1611-1G	AI-36	SV	1	SAT TV ANTENNA
AI-360		OH	1	ATTITUDE GYRO
AI-BSE65-01-2		SV	4	MONITOR RECEPTICLE
AI-EQ1	A1-EQ1	SV	1	AUDIO INTL MODULE
AI-LCD65-01-SWL		SV	2	MONITOR DISPLAY
AIM500E		OH	1	HORIZON REF IND
AIR-AP1220B-A-K9		SV	1	WIRELESS ACCESS POINT
AIRC0M55	AIS20	SV	1	CONTROL PANEL
AIS200-35		SV	1	REMOTE SWITCH UNIT
AIS80-1		SV	1	CDI SWITCH UNIT
AIS80-1		NE	2	CDI SWITCH UNIT
AI-STR-01A		SV	1	AUDIO INTL INTERFACE MODULE
AJ6-60		NS	4	DZUS STUD
AK-950-KLN89B	AK950	SV	1	GPS/NAV SWITCHING ANNUC



AK9507NL2000-28V	AL-05	NE	9	ANNUNCIATOR
AL15-8005	AL-16	SV	1	CVR CONTROL
AL-1611-1G	1302168-001	SV	1	ORBIT TECH POSITIONER
AL-215G	AL-215G	NS	6	FILTER
AL-2600-3	AL-26	NS	7	ANTENNA CONTROL UNIT
AL-2600-SRR	1302167-001	SV	1	ORBIT TECH S-R-R-
AL-5117		NE	1	PROTECTED POWER SUPPLY
AM1779/ARA48	5996-00-617-1676	OH	2	AMPLIFIER, ELECTRONIC CONTROL
AM-1964F/AIC	5996-00-777-0173	SV	1	AMPLIFIER, AUDIO FREQ
AM-1965B/AIC	5831-00-952-3453	NE	2	AMPLIFIER, AUDIO FREQ
AM-3209/ASN		SV	1	AMPLIFIER ELECTRONIC CONTROL
AN161 4RS	AN302	NS	1	TURNBUCKLE, FORK
AN3025-100	A-718AP	OH	3	CUTOUT RELAY, AIRCRAFT
AN310-8	AN3H4	NS	5	NUT
AN3C46A		NE	13	BOLT HEX
AN46-17A	AN4H6	NS	2	EYEBOLT
AN4-7		NE	13	BOLT
AN5544-3		SV	1	TACH GENERATOR
AN565F1032H9		NE	13	SET SCREW
AN5760L2	671CKL-010	OH	1	ALTIMETER
AN5770-1A		AR	1	MANFOLD PRESSURE IND
AN5795-6	10499-A	OH	1	DUAL OIL TEMP INDICATOR
AN814-3DL		NE	5	PLUG BLEED
AN8516-2		SV	1	HANDLE, SPANNER WRENCH
AN913-6D	AN937	NS	6	FITTING
AN924-12D		NE	5	NUT
ANV1425Z		SV	2	VHF ANTENNA
AOA5001		NE	1	CONTROL BOX RG FUEL TANK
APR05C-032-01		SV	2	HYDRAULIC PUMP
AP2034C	AP2034A	SV	1	TEAM
AP51979A		OH	1	AUDIO FREQ AMPLIFIER
APT-100-1000-2030SG	APT-100-1000-2030	OH	1	PRESSURE TRANSDUCER
APT-100-1000-2030SG	APT-100-1000-2030	AR	3	PRESSURE TRANSDUCER
APTE51C-70D		AR	1	TRANSDUCER
AR2010/15		SV	1	COMM 2000 SYSTEM
AR2010/25		SV	1	COMM 2000 SYSTEM
AR209-11		OH	3	FLOW RATE IND
AR-209-11		OH	3	RATE INDICATOR
AR-209-6		OH	1	RATE INDICATOR
AR-209-8		OH	3	RATE INDICATOR
AR-2E-825-30000-302		NE	1	CONNECTOR
AR75-500		NE	11	ESCUTCHEON PLATE
AS21-15		AR	1	CARGO HOOK
AS2264		SV	1	DOUBLE CARGO HOOK FIX PROV
AS22-64		NE	1	DOUBLE CARGO HOOK FIXED PROV.
AS22-83		NE	1	DUAL CONTROLS CARGO HOOK
AS2284		NE	1	DOUBLE CARGO HOOK FIX
AS-2890/APR-39(V)	5985-01-026-3927	SV	2	ANTENNA, BLADE
AS3100-(31N)-09		NE	1	COMM. CONTROL (NVG)
AS3100-11	0497-797-921	NE	1	COMM CONTROL
AS3209-146		NE	4	ORING
AS5174D0606		NE	2	FITTING
ASH671-1	ASNA0	OH	2	STATIC INVERTER
ASNA0045-120BCL		NS	1	NUT
ASU-ADI-A119-1		NE	1	NVG FILTER
ASU-BK-155165-1		NE	1	NVG FILTER KX165 LEFT SIDE
ASU-BK-155165-2		NE	1	NVG FILTER KX165 RIGHT SIDE
ASU-IND-3		NE	1	NVG FILTER
AT-206-2		OH	1	FUEL QTY IND
AT-209-NL		OH	1	TOTALZR IND-
AT-209-NL-05		OH	4	TOTALZR IND-
AT-884/APX-44		SV	2	ANTENNA
AT-884/APX-44		AR	2	ANTENNA
AV16E1293	222-366-680-101	OH	1	FUEL SHUTOFF VALVE
AV17125-1		SV	1	SUPPLY VALVE
AVS420-ZX-28-OCU	AVS420-ZX-28-CH	SV	1	AERIAL VIEW SYSTEMS
AW-5544-3		SV	1	TACHOMETER GENERATOR
B-00368-5		AR	1	ALTERNATOR CONTROL
B03C02		NE	1	MOD KIT
B183M2010101		SV	1	CONTROL UNIT Z
B183M2010102		NE	8	CONTROL UNIT
B18-945-22.28-4.AZ		NE	1	CLOCK(NVG)
B18-945-32-28-1AJ		SV	1	CLOCK
B19030NA02		SV	1	VEMD NVG
B19030NA04		SV	1	VEMD V2003 NVG
B19030NA04		NE	1	VEMD V2003 NVG

B19030NA05		SV	1	VEND BK 117 NVG
B212M2049101		SV	5	VENTILATION BLOWER ASSY
B212M20C1013		NE	1	BLOWER ASSY
B212M20C1015		NE	1	BLOWER ASSY
B234M1020881		NE	1	RETROFIT SWITCH GEAR
B24000		SV	2	FUEL DUMP VALVE
B246K3002-109		NE	1	WIRED ASSY - DISTRIB BOX 1
B281K2753-051		NE	1	SUPPLY TANK
B281K2757-051		SV	2	AFT MAIN TANK
B284K3751-051		NE	4	TRANSMIT FUEL QTY SUPPLY TANK
B284M30C1002		NE	1	FUEL SENSOR SUPPLY TANK
B290P007201		NE	2	HOUSING
B311M3010101		NE	1	MAIN SWITCH PANEL
B311M3038101		NE	1	TERMINAL JUNCTION
B31521-10-008		SV	1	INDICATOR,TR,TACH,NF-NR
B327M2001102		NE	1	SNOW SKIDS PREASSY LH-S
B327M5007102		NE	1	SETTL,PROTEC,EF5 ASSY LH-S
B327M5008102		NE	2	SETTL,PROTEC,EF5 ASSY RH-S
B334M3006104		SV	1	ELT-UNIT L/S-LIGHT ASSY
B344M3089102		NE	1	SUPPORT VERTICAL ASSY RDR1800
B34610-00-002	B3550	SV	2	TUBE, PITOT ELEC HEATED
B3550-7-307	B4553	NS	1	DOME LIGHT
B4515210005		OH	1	Encoding Altimeter
B45531-10-002		SV	2	ALTIMETER (IN/HG WITH ENC.)
B45531-10-004		SV	1	ALTIMETER (IN/HG W/O ENC)
B4B-D		SV	1	INDICATOR, BANK & TURN
B521M3067101		NE	1	ARM WELDED LH-S
B551M0005101		NE	1	END PLATE ASSY LH
B620M0001103		NE	1	ROTOR SYSTEM
B621M1002053		SV	2	BLADE ARM 2
B622M1004201		SV	1	QUADRUPLE NUT UPPER
B622M1005201		SV	1	QUADRUPLE NUT LOWER
B671M1002101		NE	1	SHORTING PLUG
B671M5001104		SV	1	COLLECTIVE LEVER RH
B671M5801102		NE	1	COLLECTIVE LEVER LH
B671M7001101D131-01		NE	1	MOUNTING TABLE
B672M1805102		NE	1	BELL CRANK
B711M3530101		NE	12	COVER XMSN COWLING RH
B711M4121101		NE	1	FRONT HINGE LH
B716M1024101		NE	1	FLANGE
B7-213-001-00		SV	1	CLOCK
B851M10X2001		NE	1	LOAD ROPE AFT
B851M2012052		NE	2	INST GRAB RING F HOOK EH
B851M2085101		NE	1	GRAB RING ASSY
B851M2105101		NE	3	HOLDER CONTROL PEND.EH COMPL.
B9845-1-305	BAC08	NS	1	DOME LIGHT
BAC086-338		SV	1	COCKPIT WINDOW
BAC086-8		SV	1	COCKPIT WINDOW
BC1-0002-022		SV	1	COMPIT LIGHT
BC1-0002-023		NE	1	EXIT SIGN
BC1-0002-024		NE	1	EXIT SIGN
BC1-0002-025		NE	1	EXIT SIGN
BC147-252	BD755	NS	1	BUTTON
BD755-212	BDW-A	SV	1	RADOME
BE369	BH185	SV	2	T-I-T- INDICATOR
BH185R4B	BHL-S	SV	2	T-I-T- INDICATOR
BHL-STD1036-331	BI197	SV	1	STAND OFF
BI1977A		SV	2	JUNCTION BOX, ICS
BLSABX-SWS32CS	BP-13	NS	1	LINER BALL BEARING
BN846-03		NE	1	TE450
BP-134-3616		OH	1	AUDIO CONTROL
BP230-6		OH	1	LH FUEL PUMP
BP-600C-01		SV	1	PWR/COMM UNIT
BR398		SV	2	ANGLE POSITION IND
BR5000-517		SV	1	OUTLET PLUG
BT1-600-2A		SV	1	BATT TEMP
BT1-600-3A		SV	2	BATT TEMP IND
BWS01		NE	1	BALANCE WEIGHT SYSTEM
C0001-81103		OH	1	ALTMETER PRESSURE
C1-22306	67-523-412-21	SV	3	MICRO SWITCH
C12847BB		SV	2	AVIONIC RACK
C12847BB		NE	2	AVIONIC RACK
C12847CB		NE	1	AVIONIC RACK
C12847CB		SV	3	AVIONIC RACK
C13077AA		SV	2	RACK 4 SLOTS
C145-6034-1		SV	1	AFT EVAPORATOR

C1611D-AIC		OH	3	ICS PANEL
C16287CA	704A47612135	SV	1	SIMPLE INDICATOR NR
C17591-105		NE	1	VALVE ASSY
C175F3C		SV	1	VENT BLOWER
C19209VF11		SV	1	SMD 45 H
C19243AB02		SV	1	CAD
C19243AB07		SV	1	CAD 2002
C19243AB08		NE	1	CAD V2003 DISPLAY
C19243AB08		NE	1	EC135 CAD V2003 DISPLAY
C19243AB09		SV	1	CAD SW V2005 NVG DISPLAY
C19243AB09		SV	1	CAD SW V2005 NVG DISPLAY
C19243EA02		SV	1	CAD NVG
C19243EA04		SV	4	CAUTION ADVISORY DISPLAY
C19243EB04		SV	3	CAD V2003 NVG
C19243EB05	B316M30S1001	SV	1	CAD BK117 NVG
C19252F806		NE	1	FLIGHT CONT. DISPLAY MODULE
C19252FC07		NE	1	FCDM
C19252FC07		SV	5	FLIGHT CONTROL DISPLAY MODULE
C19252JC07		SV	4	FCDM FBL3 SHS
C19252LC07		NE	1	FCDM
C19253AA		SV	4	INSTRUMENT CONTROL PANEL
C19254AA		NE	3	RCU
C19254AA		SV	2	RCU
C19267NG10		SV	3	SMART MULTIFUNCTION DISPLAY
C19267SG10		SV	3	SMART MULTIFUNCTION DISPLAY
C19267VF11		AR	3	SMD NVG
C19267VG11	SMD45	SV	1	MULTI-FUNCTION DISPLAY - NVG
C19267VG11	SMD45	AR	2	MULTI-FUNCTION DISPLAY - NVG
C19267VG11		SV	5	SMD45 FBL4 NVG MOD2
C-2106A/AIC-18	5831-809-3180	OH	1	CONTROL, INTERCOMM SET
C-2106A/AIC-18	5831-809-3180	OH	1	CONTROL, INTERCOMM SET
C-2106A/AIC-18	5831-809-3180	AR	3	CONTROL, INTERCOMM SET
C215A1930103		SV	1	BOX CONTROL, EQUIP COWLING
C-2323A/AIC	5831-00-539-1471	SV	1	PANEL MONITOR
C24160045-2		SV	1	PUMP, HYDRAULIC, LH
C3495100045		SV	1	OVERSPEED WARNING SWITCH
C-3835/ARC-54		SV	1	CONTROL, RADIO SET
C38E4825A01		SV	1	PANEL, WARNING
C4PF4613A05		NS	2	FALCON 50 OVERLAY PANEL
C5175Y		NS	1	INDICATOR,EMER-FUEL VALVE
C594502-0102		AR	1	FLASHER
C622010-0101	156-0019R	SV	1	NAV STROBE POWER SUPPLY
C622010-0102	156-0019G	SV	1	NAV STROBE POWER SUPPLY
C622010-0104		AR	1	NAV STROBE POWER SUPPLY
C-6287/ARC-51BX	C632A	SV	1	CONTROL
C631A1101101		SV	1	COUPLING ASSY,FLARED
C642A0201104		SV	1	PLATE ASSY, CONTROL
C661035-0101		SV	1	VSI
C661035-0101		SV	1	VSI
C661053-0103		OH	1	DIRECTIONAL GYRO
C661056-0202	5000F10	OH	1	GYRO
C668511-0102		SV	1	ALTIMETER
C67TS/1		OH	1	IGNITION UNIT
C6SC10373		OH	1	PROP TACH IND
C-79-2KAI		NE	1	PUSH LATCH
C826A-AIC10	CA-10	SV	1	CONTROL
CA-101A		SV	4	DISPLAY UNIT
CA3100E24-28PF80		NS	4	CONNECTOR
CA3106F32-1P-F80	CA-41	NS	1	CONNECTOR
CA-412-98-94		NE	1	KIT
CA-52-1A	7000T	OH	1	VSI
CB-2100-T4	AN5766-T4	SV	1	COMPASS, MAGNETIC PILOTS
CB2100T6D	CB301	SV	2	COMPASS
CBC43W2F00JVL0		NS	5	CONNECTOR
CCU-01-001	CCU-01	SV	1	COOLING CONTROL UNIT
CDM-630		SV	1	VIDEO CONVERTER
CDP250C		SV	1	DISPLAY UNIT,ISAT
CD5-728FK	CDX-W	SV	1	VCR
CDX-757MX		SV	1	CD CHANGER
CDX-WA04	CE-00	SV	15	10 DISK CD CHANGER
CE394/UJ	CE413	NS	1	SWITCH BOX
CE413490073		SV	1	EGPWS RELAY UNIT
CE443490003-01		SV	1	EGPWS RELAY UNIT
CE53000-2	SES-83-1018-12	SV	1	SAS CTL AND IDLE CH TEST SET
CGS962U050V4C		NS	3	CAPACITOR
CH150-14-00		SV	1	CONTROL HEAD, RADIO TETRA

CHA-5634		SV	1	CD AUTO CHANGER
CI-105-7		NS	1	DME/TRANS ANT
CI-105-9		AR	1	ANTENNA
CI-120-1		SV	1	ANTENNA
CI-125		SV	1	VHF COMM ANT
CI-222		SV	1	AM/FM ANTENNA
CI-2RR		SV	1	JENSEN MODULE
CH401-420		SV	1	ANTENNA
CI-5000-1-L	CI5000	SV	1	TRANS/RADIO TELE ANT
CI-818A	3500-137-1D	SV	1	PC BOARD
CI-884		SV	1	PC BOARD
CI-9051		SV	1	PC BOARD
CI-A-100		SV	1	RGB AMP INTERFACE
CK94K6-74	CL-33	NS	1	SWITCH CABLE ASSY
CL-33	209-375-096-103	SV	2	CURRENT LIMITER
CN-405/ASN		SV	1	COMPENSATOR
CNS022		NS	1	PLUG
CP-1285A		SV	6	TEAM AUDIO CONTROL
CP-1285D		SV	1	TEAM AUDIO CONTROL
CP1766G	704A45360043	OH	1	AUDIO SELECTOR PANEL
CP1976FB01	704A45360097	SV	2	SELECTOR SWITCH
CP1976FEB01		SV	1	SWITCH, PRINCIPAL
CP1976FEB01		SV	1	SWITCH, PRINCIPAL
CP2618DB01		SV	1	SWITCH SELECTORJCS45
CP-5129/AYQ-507V3	C20709-1	OH	1	DATA ACQUISITION UNIT
CPW-ELW35		NS	2	MOUNTING CLIP
CR2795B105A1		SV	1	REGULATOR
CR2795E100A1	CTA33	SV	1	VOLT REG
CR3523-5-11		NE	100	RWET CHERRY MAX
CRN6-83-1	704A45354002	SV	1	UNIT,SWITCHING
CSIBF14501-MANT		NE	1	IBF KIT 145
CTA33981	D091-	SV	1	DME INDICATOR TEST ADAPTOR
CTI120E03D513		NS	2	MODULE,TERMINAL
CTI-3D-05		NE	1	RACK,ELECTRONIC JUNCTION
CTI420E044D513		NS	1	MODULE,TERMINAL
CTI420E128-513		NS	1	MODULE,TERMINAL
CW0622-1010		NE	3	SHROUD A119 MD41 HTAWS
CZ92A5-9		SV	1	PRESSURE TRANSDUCER
D00282-0005		NE	1	LAST SENSOR
D091-1		SV	1	REGULATOR,VOLTAGE
D0C20-06		SV	1	ANTENNA COUPLER
D107318E		NE	4	FUEL PUMP ASSY
D107318E		SV	1	FUEL PUMP ASSY
D107318E		NE	4	FUEL PUMP ASSY
D107319		SV	1	FUEL PUMP
D107611E		SV	1	SERVO MOTOR
D107611E		NE	4	SERVO MOTOR
D120-P2-T	5120-P1	SV	2	ALTRITUDE DIGITIZER
D134-1463		NE	1	CARD
D134-994		NE	1	WIRING HARNESS 38VB
D136-1010		NE	1	COPILOT SEAT
D136-1013.03		NE	1	STRENGTHENING
D136-1013.04		NE	1	BAR SPLINED
D136-1014		NE	1	SEAT RAIL RH
D163-1013		NE	2	SEAT RAIL LH
D19-035	704A46211023	SV	1	VOLTAGE REGULATOR
D20516-L		SV	1	NAV ANTENNA
D20516-R		SV	1	NAV ANTENNA
D205-523-011		SV	2	HELI-RAPPEL KIT LH
D240845	D24AB	SV	1	PUMP
D240845	D240845F	NE	3	PUMP
D24AB1042	D2979	OH	1	RELAY, BREAKING CURCUI
D3040E		SV	1	LANDING LIGHT GRIMES
D34160-101	D5150	SV	1	FLOAT ASSY FWD LH
D38999/26WJ-20PA		NS	1	CONNECTOR,RCPT,ELECTRICAL
D4703-041		NE	2	LOGKOUT PIN
D50020-111W		NE	3	CEILING PANEL ASSY
D50020-111W		NE	2	CEILING PANEL ASSY
D50020-112W		NE	1	CEILING PANEL ASSY
D50022-121W		NE	1	ROOF SIDE PANEL RH
D50023-111W		NE	2	CEILING SIDE PANEL ASSY LH
D50026-2W		NE	1	WINDOW TRIM ASSY RH
D50026-2W		NE	1	WINDOW TRIM ASSY RH
D50027-1W		NE	1	SIDE POST COVER ASSY RH
D50042-121W		NE	1	PANEL ASSY UPPER LH
D50042-131W		NE	1	PANEL ASSY SIDE

D50043-111W		NE	1	PANEL ASSY
D50043-112W		NE	2	PANEL ASSY RH
D50043-1W		NE	1	PANEL ASSY
D50043-2W		NE	1	PANEL ASSY
D50055-111W		NE	1	JOINER PANEL UPPER CARGO
D51506	900/D51506	SV	1	CVFDR,VOICE/DATA RECORDER
D51546-011	D5161	OH	2	CVFDR
D60268MK11112	D6026	SV	2	AIR DATA SENSOR
D60268MK21121	D6026	SV	2	AIR DATA SENSOR
D60268MK21123		SV	1	AIR DATA SENSOR
D-9961-3		NS	3	COVER (RED)
D0113-00980	80008030	SV	1	ARINC RACK
DA-24658-31		NE	4	BACKSHELL SUB-D
DAAB0786CH061	CP-1828/ARN-148	OH	1	COMPUTER, AIRSPEED
DAPSHDMI-1		SV	1	HDMI SPLITTER
DB438	438	SV	1	AMP
DB600		SV	1	TONE GENERATOR
DBASWSSA197F0		NS	4	CONNECTOR
DBD-01-001		SV	6	DUAL BAND DETECTOR
DBMAM25S		NS	1	CONN KIT
DC7ZX+071W		AR	1	MOTOROLA RADIO
DCR-1A-06		NE	4	CONNECTOR RAIL
DCR-1A-10		NE	1	CONNECTOR RAIL
DD44F10JVL0		NS	2	CONNECTOR
DDL-OC119A	76450-01076-105	OH	1	T5 INDICATOR
DE-24652	DF-88	NS	2	BACKSHELL
DF-88A		OH	2	DIR FINDER IND
DH78C		SV	1	RELAY
DHS433-141-05		NS	10	NUT
DK041-1		NE	1	OIL PRESSURE PICK-OFF 14 IN
DL016-3		SV	1	RPM TRANSMITTER
DL016-3		NE	1	RPM TRANSMITTER
DL404-38		SV	1	TRIPLE RPM INDICATOR
DL404-39		SV	1	TACHOMETR
DL404-40		SV	1	TRIPLE RPM INDICATOR
DL404-40		SV	1	TACHOMETR
DL404-53	105-957201	OH	1	TRIPLE RPM INDICATOR
DL412-39		OH	1	SINGLE RPM INDICATOR
DL412-39	105-90845	NE	2	SINGLE INDICATOR
DL412-40		OH	1	SINGLE RPM INDICATOR
DL412-40	105-90845	OH	1	RPM INDICATOR
DL436-38		OH	1	TRIPLE RPM INDICATOR
DL457-021	L771M40C1005	SV	1	TRIPLE INDICATOR RRM
DLA900-85-M-SB76		NE	1	CRYSTAL FILTER UNIT
DMC63-2		SV	1	ANTENNA
DMC63-4/A	DMC70	SV	1	ANTENNA
DMC70-1A	DMELT	NE	1	ANTENNA VHF
DM-C70-1A		SV	1	ANTENNA
DMH21-1		NE	1	VORLOC ANTENNA COUPLER
DMH21-1		SV	2	VORLOC ANTENNA COUPLER
DMH24-1		SV	1	COUPLER, GLIDE ANTENNA
DMN4-17-1/N		SV	3	VORLOC/GS ANTENNA
DMNI-24		SV	1	ANTENNA DME TRANS
DMNE0-10-2		NS	1	ANTENNA
DMNE0-6-2		SV	10	ANTENNA
DMNE0-9		SV	1	ANTENNA
DMNE0-9		SV	1	ANTENNA
DMNE0-9		SV	1	ANTENNA
DPP4FS464	MS27644-1	NE	10	BEARING
DPX2MA-A106P-A106P-33B-0001		NS	1	CONNECTOR
DPX2MA-A106P-A106P-33B-0001		NS	1	CONNECTOR
DPXBMA57-33S-0001		NS	4	CONNECTOR
DRA45C-26		SV	4	OVERSPEED WARNING SWITCH
DSRM-10		NE	1	REMOTE CONTROL UNIT
DST1017-5	850568-1	SV	1	ITT IND
DT410-2	412-075-008-113	OH	1	DUAL TORQUE IND
DT501-2		SV	1	DOUBLE TORQUE INDICATOR
DT501-9		NE	1	TORQUE INDICATOR
DT-ABGA		SV	8	SPEAKER
DT-AX2		SV	14	DT SYSTEMS SPEAKER ASSY
DTE12-001		SV	1	NAT DTRM PAD
DV00514-0291-0002-03	0514AD3	SV	1	ELECTRONIC FICTION BOX
DVD-023-01-1		SV	1	AUDIO INTERNATIONAL
DVD-024-03-1		SV	1	DVD PLAYER
DVD1270E-H01A	DVD1270E	SV	1	MULTIFORMAT DVD WRITER
DV-EL320-240	DB586	SV	1	DYNALIGHT SEISBAG
DV250A		SV	1	ISAT100 CONTROL HEAD

DVI-250C		SV	1	ISAT100 CONTROL PANEL
DVP-S5301	DWFS	SV	1	DVD/CD PLAYER
DZP_04-800W		FN	1	DZMx DZUS with Sat.4G,WfLBT
E00101E00010100		NE	1	TRIPLE RPM INDICATOR
E07391-10-057		OH	1	AIRSPEED IND (KNOTS)
EA124AN-124		SV	1	FUEL QTY IND
EAD01		NE	3	FIXED EXTERNAL ABSEIL DEVICE
E82BW		SV	1	FLOATING ELT
ECD-AMG-11	CD402B-NVG	SV	3	CONTROL DISPLAY UNIT
ECD-AMG-17	CD671C-NVG	NE	1	CONTROL DISPLAY UNIT
ECJ504-8		NE	1	CONNECTOR
ECU76A		AR	1	CONTROL UNIT
EE4-1450		NE	1	CONE GUIDE
ELWS-480102-001		NE	1	LAV LED LIGHT ASSY
EMSE377-2	ES400	SV	1	POWER SUPPLY
EMU-A-010-2		SV	1	PROCESSOR ADAS
EMU-A-010-3		SV	1	PROCESSOR ADAS
EPT941		SV	1	B LINE ELT LOCATOR
ES40020-4	ES721	NS	2	NUT
ES61104-1		NE	4	MOTOR
ESB-36C/3		SV	1	AIRBORNE COMM
ESB76A/3		SV	1	CONTROL
F15-0141-1	F2MA6	NS	2	BASE RAIL
F2MA60023211082	600232	SV	1	ELT CONTROL PANEL
F32827.5		NE	4	NEEDLE BEARING
F32828-5		NE	4	NEEDLE BEARING
F36C2S28LEAE		NS	1	FLEX LIGHT
F50-11202-501	F50-1	SV	10	PC BOARD
F50-11203-501A	F50-11510A	SV	1	PC BOARD
F50-11205-501B	F50-1	SV	8	PC BOARD
F50-11891-505-701		SV	1	P- ANNUNC- FRAME ASSY
F50-11891-505-703		SV	1	P- ANNUNC- FRAME ASSY
F50-11891-505-704		SV	1	P- ANNUNC- FRAME ASSY
F50-11894-501		SV	1	JUNCTION BOX
FD104ARM		FN	1	Display 10,4" with arm
FD104ARM-VERSION_180		NE	2	Display 10,4" 180 deg version
FD151DMT		FN	1	15" Cabin Display Mount
FD70ARM		FN	1	FD70CV-V Display w/FD70DMT
FDS81-1029		FN	7	MAU - MODULAR ACQUISITION UNIT
FE463		AR	1	PC CARD
FER97	704A47131019	SV	1	UNIT INDICATING
FERN0-SRPW-12-2		NE	1	FERNO-TYP LITTER
FGFB600232		SV	1	ELT CONTROL PANEL
FLX2645		SV	1	ANTENNA
FLYM23800-2		SV	1	MOTOR DIRECT MAGNET
FM10-12		SV	1	FLUGH MARKER BEACON
FM10-12G		SV	1	ANTENNA, MARKER BEACON
FM20-66		NE	2	HYBRID COUPLER
FM2510		SV	1	FURLING PM TRANSCIEVER
FM504		OH	1	AIRSPEED INDICATOR
FM504-49		AR	1	AIR SPEED
FM810-272-1		SV	1	ANTENNA MARKER BEACON
FN-100		NE	1	AVIONICS FAN, 11-32 VOLTS
FV-0910		SV	1	CAMERA CONTROL UNIT
G-1684		SV	1	ATC CONTROL PANEL
G-2139		SV	1	CONTROL
G2581-03		SV	1	SELCAL PANEL
G300103	704A47720100	SV	1	ROTOR RPM WARNING
G3849A		SV	2	TACAN CONTROL
G4345		AR	2	AUDIO PANEL
G-4433A		SV	1	ADF CONTROL
G-4434		SV	1	VHF CONTROLLER
G-4434A		SV	1	VHF CONTROLLER
G-4436A		SV	1	TRANSPONDER CONTROL
G-4483-14		SV	1	COMM CTL
G-4483B		OH	1	COMM CTL
G-4484D		SV	1	ATC CONTROL PANEL
G4501A		SV	1	CONTROL
G-4518		SV	1	CONTROL
G456		SV	1	VACUUM PUMP
G4649		SV	1	COMM ATC CONTROL
G-4688		SV	1	AUDIO PANEL
G4710A11		OH	1	LIGHT ASSY
G-4745A		SV	1	ATC CONTROL
G-4876A		SV	1	ATC/NAV CONTROL
G-4876C		SV	1	ATC/NAV CONTROL

G-5325A		SV	1	COMM 1-2, NAV 1-2 CONTROL
G-5515		SV	1	COCKPIT SPEAKER
G-5565		SV	1	MKR / ATC CONTROL
G5922-13		SV	1	CONTROL
G5934		SV	1	VHF/NAV CONTROL
G6119A	G6136	SV	1	ADF CONTROL
G6136B	G6240	SV	1	CONTROL RACK
G6240-4		OH	1	SEARCH LIGHT
G-6250		OH	1	SEARCH LIGHT
G-6325		SV	1	AUDIO MONITOR
G-6345		OH	1	AUDIO CONTROL
G6478-001-40		SV	1	CONTROL COMPUTER
G6644-01		SV	1	ATC CONTROL
G6644C		SV	1	CONTROL
G6861-01		SV	1	CONTROL
G6930-03		SV	1	CONTROLLER
G6944-01		SV	1	ATC CONTROL
G6969-04		SV	1	TCAS CONTROL
G6969-05		SV	1	TCAS CONTROL
G7008-64		SV	1	CONTROL
G-708-1		AR	1	INTERPHONE AMP
G7275-04		FN	2	Cursor Control Device (CCD)
G7632-108		SV	3	NAV, VHF, CTL, CTL-32G
G7740A19-24	G8385	SV	1	LOWER ROTATING BEACON
G8385-7		NE	2	LANDING LIGHT
G8385-7		OH	1	LANDING LIGHT
G993-01-1A		OH	1	RATE OF CLIMB INDICATOR
G993-01-1B		OH	1	RATE OF CLIMB INDICATOR
G9950-1		OH	1	BEACON ASSY, UPPER
GA223280002-257		SV	1	PANEL
GA341200009-01		SV	3	PANEL
GA341200009-13		SV	5	FSU 1 FSU 2 PANEL
GA341200009-23		SV	5	FSU 1 FSU 2 PANEL
GA341200010-01		SV	3	PANEL
GA343700002-67		SV	1	FMS CONTROL PANEL
GC13422-4-1		SV	1	PRINTED CIRCUIT BOARD
GC1346142		SV	1	PRINTED CIRCUIT BOARD
GC514280073-01	4280073-01	AR	1	LAN SWITCHING UNIT
GC514280075-01	4280075-01	SV	2	WIRELESS ACCESS POINT
GC514740002		SV	1	BATTERY
GC543350007-7	720-7719D	SV	5	GULFSTREAM CONTROL WHEEL
GG301ED-A2	3001EDK	OH	1	GYRO, VERTICAL
GM11953		NE	6	LINEAR TRANSDUCER
GN565-26-160SW		NE	1	HANDLE
GPX428001013-301		NE	1	BRACKET ASSY
GS-15-25-GG-K50146-400N		NE	1	GAS SPRING 400N
GS-19-250-GG-K45299		NE	1	SPRING WITH DAMPER
GT-900R7441000-TD		SV	1	TOOL
GV-620-16	GV-620-16-87	SV	1	PANEL
GV-620-17	GV-620-17-87	NE	1	PANEL
H140ABM1		OH	1	HORIZON GYRO
H140ABM2		OH	1	HORIZON GYRO
H140ACM1		OH	2	HORIZON GYRO
H140ACM2		OH	2	HORIZON GYRO
H140ADM1		OH	1	HORIZON GYRO
H140ADM2		OH	1	HORIZON GYRO
H140ALM1		OH	1	HORIZON GYRO
H140AMM1		OH	1	HORIZON GYRO
H140AMM2		OH	1	HORIZON GYRO
H140ARM2		OH	1	HORIZON GYRO
H140ASM1		OH	1	HORIZON GYRO
H140ASM2		OH	1	HORIZON GYRO
H140ATM1		OH	1	HORIZON GYRO
H140ATM2		OH	1	HORIZON GYRO
H140AUM1		OH	1	HORIZON GYRO
H140AUM2		OH	1	HORIZON GYRO
H140BHM		OH	2	HORIZONT
H140BHM1		OH	2	HORIZONT
H140BHM2		NE	4	HORIZON GYRO
H140BHM2		OH	2	HORIZONT
H140BLM		OH	1	HORIZON GYRO
H140CAM		OH	2	HORIZON GYRO
H140CAM1		OH	2	HORIZON GYRO
H140CJM		OH	2	HORIZON GYRO
H140CJM1		OH	2	HORIZON GYRO
H140CLM1		OH	2	HORIZON GYRO

H140CPM		OH	1	HORIZON GYRO
H140CPM1		OH	1	HORIZON GYRO
H140CSM1		OH	1	HORIZON GYRO
H140CWM		OH	2	HORIZON GYRO
H140JAM1		OH	1	HORIZON GYRO
H140JKM1		OH	1	HORIZON GYRO
H2301-9		NE	1	LATCH
H321ABM1		OH	1	ATTITUDE INDICATOR
H321AKM1		OH	1	ATTITUDE INDICATOR
H321ALM1		OH	1	GYRO
H321ASM1		OH	1	HORIZON GYRO
H321BHM1		OH	1	HORIZON GYRO
H321CMM		OH	1	HORIZON GYRO
H321CZM	704A47150120	OH	3	HORIZON GYRO
H321EGM		OH	2	HORIZON GYRO
H600S160A434		NE	1	LOCKING MECHANISM
H930-6		SV	1	INDICATOR
HAF118	704A35333053	NE	1	MOBILE ANTENNA
HAI-222-070-150		SV	1	INDICATOR
HAI-222-070-160		SV	1	INDICATOR
HAI-222-070-170	AES-0007-SCSH	SV	1	AES
HCA3		OH	1	ELECTRIC MOTOR
HD365-15-6008-01		NS	1	BEARING
HD365-15-6053-01		NS	2	HANDLE
HD412-05-6004-01	HD412	NS	3	BRACKET
HD412-15-6039-03	HD412	NS	1	BRACKET
HD412-75-6018-10	HD900	NS	2	DOUBLER
HD900-62-3003-02	HDATD	NS	1	SUPPORT
HDAD-15-6096-21	HDSS2	NS	4	BUSHING
HDSTD-04-6004-02	HDSTD	NS	1	AMP
HDSTD-15-6096-09	HDSTD	NS	2	PIN
HDSTD-15-6096-09		NE	2	PIN
HDSTD-15-6101-03		NS	2	TELESCOPING TUBE
HDSTD-98-6004-02	HDSTD	NS	2	SPRING
HDSTD-98-6004-2		NS	2	SPRING
HDSTD98-6011-02	HE641	NS	5	GRAPHITE HINGE
HE64100	HG202	SV	1	CONTROLLER
HG2021GB01	HG709	SV	1	SENSOR UNIT
HG7095A1		SV	1	RAD ALT RCVR
HGA-48		SV	2	ANTENNA
HI-400		SV	1	COMPASS
HL19PB5-7	HN4H4	NS	35	HI LOC
HMF-BG-135-115		NE	2	TW-SPRUEHSCHLAUCH GARDENA
HMF-BG-135-600		NE	1	DOWING BAR
HN4H41-1	HR-DR	NS	10	BUSHING
HR-DR-28	HS565	SV	1	STOBE LIGHT
HS5659ME6PN	HS583	NS	4	CONNECTOR
HS5835-15	HSAA0	NS	13	DECAL
HSAA04549-001	HSAS0	FN	19	LIFE VEST KIT
HSAS00328-011	HSAS0	NE	1	CB SEGMENT, VHF-FM 5A
HSAS04534-001	HTE20	NE	1	PLACARD "MOBIL AERO HF" LARGE
HTE200016	HTE20	OH	1	ACTUATOR BALL VALVE
HTE200016	HTE90	AR	1	ACTUATOR BALL VALVE
HTE9061	HTE90	OH	1	VALVE ASSY
HTE9061	HUCAB	AR	1	VALVE ASSY
HTE920018		NE	3	ACTUATED BALL VALVE
HTE9482		SV	1	FIRE SHUTOFF VALVE
HUCAB2BP		SV	1	CONTROL-BRIEFER
HUCG-1-BPE		SV	1	CHECKLIST
I-81-A		OH	1	INDICATOR
IC3100-(2)-01		SV	1	IC-AMPLIFIER
IC3100-2		SV	1	IC-AMPLIFIER
ICM11		SV	1	VHF TRANSCIVER
ID-1103/ARN	5826-00-952-3709	OH	1	ID-1103/ARN INDICATOR
ID-1351B/A		OH	1	INDICATOR HEADING
ID-310A/ARN	5826-00-691-4893	OH	1	INDICATOR RANGE
IN222A		SV	1	CONVERTER INND VORVILS
IN224A		SV	1	CONVERTER INND VORVILS
PT20RT1-1000-80G		SV	1	PRESS- TRANSMITTER
PT70RT1-1000-250G		SV	1	PRESS- TRANSDUCER
ISAT-100		AR	1	SATCOM TRANSCIVER
JB37-405		NE	7	JUNCTION BOX, 5 STATION
JBS223-1		SV	1	COMPRESSOR ASSY
JBS880-3		NE	4	MIXING VALVE
JBS880-3		SV	3	MIXING VALVE
JBS880-3		AR	1	MIXING VALVE



JCPB1830B		SV	1	MOTOR
J-D4N-300M		NS	1	LEACH RELAY
JE2-1978-ONG		SV	1	ELT
JG206D4	ID-1345/ARN-171(V)	SV	1	INDICATOR, ALTITUDE RADAR
JG873B1		SV	1	INDICATOR
J-12A		NE	1	RELAY
JR28259		OH	1	AIR FLOW CONTROL
J-W4N-005		NS	1	LEACH RELAY
K00-00074-00		NE	1	ANTENNA KIT
K11695		NE	1	DAEMPFER HD1B
K12054		NE	2	TAWS CONFRG KIT
K38490	K60AB	SV	2	CO2 CYLINDER
K402AC		NE	1	CHP DETECTOR
K60ABM		SV	1	ACT POSITION DISPLAY
K9323030A000		FN	1	12" Display Unlr (DU)
KDL569R		SV	1	TEST BOX
KHF950	KHF950SYSTEM	SV	3	HF SYSTEM
KHF990	KHF990SYSTEM	SV	3	HF SYSTEM
KIT:117-902051	117-902051	NE	1	RPM BOX
KIT:B793M5004051	B793M5004051	NE	1	FUZZ BURNER COMMON KIT
KIT:L332M3802051	L332M3802051	NE	1	BELT AND NO SMOKING SIGNS, INST.
KIT:L334M6860101	L334M6860101	NE	1	SX-16 HAND CONTROL
KIT:L642M1806051	L642M1806051	NE	3	FEN.GEARBOX COVER
KIT:L642M1806051	L642M1806051	NE	1	FEN. GEARBOX COVER
KS-502A		SV	1	POWER SUPPLY
KSS216H2	L108A	FN	1	CLAMP
KSS216H2		NE	1	CLAMP
L108AAM		SV	2	ARTIFICIAL FEEL UNIT
L110M180288		NE	1	PLACARD ROTORBRAKE
L132M0090101		NE	1	SHORT
L133M6205206		NE	1	SUPPORTING SLEEVE
L133M6205206		NE	1	SUPPORTING SLEEVE
L133M6205206		NE	1	SUPPORTING SLEEVE
L133M6205206		NE	2	SUPPORTING SLEEVE
L133M6205207		NE	2	THRUST PIECE
L134M2801101		NE	1	FUEL TANK LEAK TEST EQUIP
L20420-13	L209C	NS	2	LAMP ASSY
L209CCM2	L281M	SV	1	FEEL AND TRIM ACTUATOR
L210M1820114		NE	1	EVAPORATOR COCKPIT ASSY
L210M1831105		NE	1	COND MODULE ASSY
L2-117-93		NE	2	CONTROL BOX ASSY
L212M40X1001		NE	1	MIXING VALVE
L214M1038102		NE	1	BRACKET ASSY
L219M28X3001		NE	1	SLIM BLOWER
L221M75X3101		NE	1	TRIMACTUATOR
L251M2011205		NE	1	SEAT TRACK FENDER SERIES
L251M4002101		NE	1	MAP CASE RH ASSY
L258M2079101		NE	1	CARGO COMP PANEL LH
L281M2008101		SV	3	FUEL SENSOR MAIN TANK
L281M2009101		NE	2	FUEL SENSOR MAIN TANK
L281M2011101		SV	3	FUEL PROBES SUPPLY TANK
L281M2011101		SV	1	FUEL SENSOR SUPPLY TANK
L281M2012101		SV	5	FUEL PROBES MAIN TANK
L281M2012101		SV	10	FUEL SENSOR MAIN
L281M20C1006		NE	1	FUEL MAIN TANK
L281M20C1006		SV	5	MAIN TANK
L281M20C1007		NE	1	SPLIT SUPPLY TANK
L281M20C1007		SV	1	SPLIT SUPPLY TANK
L281M20C1008	FT25084	SV	1	TANK
L281M20C1008	FT25084	NE	3	TANK
L281M20C1010		NE	1	TANK
L281M20C1026		SV	1	EC135 MAIN FUEL TANK
L282M20X1006		NE	1	HOSE DN08
L284M30C1001		SV	5	FUEL SENSOR MAIN TANK
L284M30C1002		SV	3	FUEL SENSOR SUPPLY TANK
L284M30C1002		SV	4	SUPPLY FUEL PROBE
L311M1009102		SV	4	SWA PNL-20VE SMALL-NVG
L311M1009103		SV	5	SWA UNIT-20VE SMALL-NVG
L311M1009150		SV	1	SWITCH UNIT 20VE SMALL-NVG
L311M1009881		NE	1	SWITCH UNIT
L311M1034101		SV	2	SWITCH UNIT 20VE
L311M1034101-001		SV	3	SWITCH UNIT 20VE/EMS
L311M1034102		SV	1	SWITCH UNIT 20VE
L311M1075101		NE	1	SWITCH UNIT 20VE SMALL NE
L311M1075102		NE	1	SWITCH UNIT 20VE 217
L311M1075102		SV	2	SWITCH UNIT 20VE 217

L311M1075156		SV	1	SWITCH UNIT 20VE 217
L311M1075156		NE	1	SWITCH UNIT 20VE 217
L311M1085103		NE	2	SWITCH PANEL
L311M1085103		SV	1	SWITCH PANEL 20VE TM ADAC
L311M1085106		SV	1	SWITCH UNIT
L311M1610168	L311M1610168A001	SV	45	MOUNTING PLATE
L311M1907210		NE	1	BLOCK
L315M5001881		SV	1	WARNING UNIT
L315M5001881	L315M5001881A002	NE	1	WARNING UNIT
L315M5001881		SV	1	WARNING UNIT
L315M5001881A001		SV	1	WARNING UNIT
L315M502051		NE	1	WARNING UNIT ASSY (STAND. -97%)
L315M5003101		SV	2	WARNING UNIT ASSY NVG
L315M50C1001	6300-00-00	SV	1	WARNING UNIT
L315M50C1011		SV	1	WARNING UNIT
L316M20C1001		SV	2	ENG/XMSN OIL T/P INDICATOR
L316M20C1002		SV	1	ENG/XMSN OIL T/P INDICATOR
L316M20C1002		NE	1	ENG/XMSN OIL T/P INDICAT
L316M20C1003	KM455-5	NE	2	ENG/XMSN OIL INDICAT
L316M20C1005		SV	1	ENG/XMSN OIL T/P INDICATOR
L316M20C1005	KM455-4	SV	1	ENG/XMSN OIL INDICAT
L321M1001205		NE	1	SKID SHOE ASSY
L321M1021230		SV	1	BRACKET FWD LOWER
L321M1021231		SV	1	BRACKET FWD UPPER
L321M1021236		SV	1	BRACKET REAR UPPER
L321M1025101		SV	1	HIGH SKID SHOE ASSY
L321M5823101		SV	1	BRACKET PRESS. TUBE COMPL.
L321M5827205		SV	1	BRACKET FWD
L321M5827206		SV	1	BRACKET FWD
L321M5827207		SV	1	BRACKET AFT
L321M5827208		SV	1	BRACKET AFT
L331M5861101		NE	1	CHARTHOLDER NVG LH DET PART
L331M5862102		NE	1	CHARTHOLDER NVG RH DET PART
L331M5862103		NE	1	CHARTHOLDER NVG RH DET PART
L334C6002003		NE	1	SX-16 DETACH PART
L334C6802002		NE	1	SX-16 ADAPT KA
L334M3843101		NE	1	LANDING LIGHT
L341M10C1001	8000L-8709	OH	2	AIRSPD
L341M10C1001	8000L	OH	2	AIRSPD
L341M20C1001		NE	1	ALTIMETER
L341M20C1001		SV	2	ALTIMETER
L341M30C1001		SV	1	VSI
L344M3817101		NE	1	BRACKET ASSY RDR 1600
L521M1031105		NE	1	COVER PILOT DOOR LH
L521M3034101		NE	1	COVER
L521M3104101		NE	1	LOCK RH
L535A3501131		NE	1	INSERT, TUNNEL
L535A3501131		NE	1	INSERT, TUNNEL
L535A44201102		NE	1	STATOR ASSY
L535M2002051		NE	1	INST.FENESTRON-SHAFT MGB
L563M20X2003		NE	1	SLID.DO.PANE LH W.SLD.WOO
L563M20X3967		NE	2	SLIDING WINDOW/LARGE LH
L621M1010056	EC135	AR	1	ROTOR BLADE ASSY
L623M2005103		NE	1	SWASHPLATE
L634M20C1001		NE	1	PRESS TRANSDUCER
L635M1021001		NE	1	CALIPER UNIT
L635M1025230		NE	1	ADAPTER
L635M1025230		NE	1	ADAPTER
L635M1025231		SV	1	MGB-FLANGE REWORKED
L652A2008201		NE	1	OUTPUT CASE
L652A2011202		SV	1	CONTROL BOX
L682C1024101		SV	1	HUBCAP STANDARD
L671M1003104		NE	1	CYCLIC STICK RH
L671M1809102		SV	1	CYCLIC STICK LH
L671M20V1005		NE	1	ROD END ASSY
L671M3011205		SV	1	LEVER
L671M5020101		NE	1	BELLOWS
L671M50C1004		NE	2	SWITCH UNIT
L671M50C1008		NE	2	SWITCH UNIT COLLECTIVE P/L
L671M50C1013		NE	1	SWITCH UNIT COLLECTIVE
L671M50C1026	G2-0055	NE	3	SWITCH UNIT COLLECTIVE P/L
L671M50C1030		NE	6	SWITCH UNIT COLL P/L
L671M50C2026		NE	2	SWITCH UNIT COLL P/L
L673M20A1012	S4-3000561	AR	1	MHA - COLLECTV
L711M1065101		NE	1	ENG.COWLING LH
L713M1052101		SV	1	ENGINE FX FIREWALLS TM RH

L713M2048101		SV	1	SHEET LOWER RH ASSY
L713M2048102		SV	1	SHEET LOWER RH ASSY
L713M2053101		SV	1	EJECTOR ASSY (P&W)
L713M2054102		SV	1	EJECTOR COMPL-PW RH
L713M2055102		SV	1	EJECTOR COMPL-TM LH
L713M2056102		SV	1	EJECTOR COMPL-TM RH
L713M2067102		NE	4	FIREWALL FRONT LH
L713M2068102		SV	1	FIREWALL FRONT RH
L713M2071101		SV	1	INLET CHANNEL LH
L713M2072101		SV	1	INLET CHANNEL RH
L713M2072104		SV	2	INLET CHANNEL RH
L713M2072105		SV	1	INLET CHANNEL RH
L771M100C1002		SV	1	N1-TACHO INDICATOR
L771M100C1003	DL458-121	NE	2	N1 TACHO INDICATOR
L771M200C1001	DT413-120-120	SV	1	DUAL TORQUE INDICATOR
L771M200C1003	DT413-121	SV	3	DUAL TORQUE INDICATOR
L771M200C1005	DT413-021	SV	1	DUAL TORQUE INDICATOR
L771M400C1004	DL457-300	NE	1	TRIPLE INDICATOR RRM (NVG)
L771M400C1004		SV	1	TRIPLE RPM INDICATOR
L771M400C1005		SV	1	TRIPLE TACHO INDICATOR
L771M400C1006		NE	2	TRIPLE INDICATOR RPM(NVG)
L771M400C1007	DL457-310	SV	1	TRIPLE TACHO INDICATOR
L771M400C1010	DL457-600	NE	1	TRIPLE RPM INDICATOR
L771M400C1012		SV	1	TRIPLE INDICATOR RRM
L771M400C1026		NE	1	TRIPLE INDICATOR RPM (NVIS)
L771M400C1028		NE	5	TRIPLE INDICATOR
L772M100C1002		NE	1	DUAL TOT INDICATOR
L772M100C1003	TM477-122	NE	1	DT INDICATOR
L853C1002103		NE	1	WIRE HARNESS
L853M2044101		NE	1	COVER CONN BRACKET ASSY
L853M2932881	DSR-20P	NE	1	VCR DSR-20P MOD
L854M4807210		NE	1	RELAISHALTER SERIE M500
L882M1010106		NE	1	WIRE HARNESS 10VB
L882M1036101		NE	1	WIRING HARNESS
L882M1828115		NE	1	WIRE HARNESS
LC41-103011-01	103011-01	SV	1	SATCOM ADAPTER
LC41-306001-01	306001-01	SV	1	PHONE CONTROL UNIT
LC41496002-01		SV	1	BATTERY UNIT
LC42216045-23		SV	1	PANEL
LD12-002		SV	2	LAMP DIMMER
LD8016		SV	1	DME TEST PANEL
LDM-171		SV	1	LEADER DISTORTION METER
LD550-50-20-55	LE-50	NS	24	VARISTOR
LED-40-15-HE-34387		NS	1	SWITCH ASSY
LED-40-17-HE-31351		NS	1	SWITCH ASSY
LED-40-18-BB-33599		NS	1	SWITCH ASSY
LED-40-18-BB-34384		NS	1	SWITCH ASSY
LED41-148G32272		NE	2	274 HF 304 FM
LG14C11		OH	1	TRANSDUCER PRESSURE RATIO
LH1PGFO0001		NE	1	LIFE HAMMER
LN29930-08X26	LN299	NS	1	SCREW
LN29952-0815M	LN943	NS	7	WASHER
LN9438M5X32	LN943	NS	30	SCREW
LN9439M5X32	LR600	NS	2	SCREW
LPG111		SV	1	LP GOVERNOR
LPG126		SV	1	LP GOVERNOR
LR6003		SV	1	CTL TEST PANEL
LS03-05001		AR	1	DC CONVERTER
LT-100		SV	1	LIGHT DIMMER SUPPLY
LT-25F		SV	3	AC TO DC POWER SUPPLY
LT-488	222-375-012-101	SV	4	LIGHT DIMMER SUPPLY
LT48D		SV	1	LIGHT DIMMER PWR SUPPLY
LT48D		SV	1	LIGHT DIMMER SUPPLY
LT-52A		SV	1	LIGHT DIMMER SUPPLY
LT-70		NE	1	LIGHT DIMMER SUPPLY
LT-71		SV	1	DC TO DC CONVERTER
LT-71A		SV	1	DC TO DC CONVERTER
LT-71G		SV	1	DC TO DC CONVERTER
LV2024		SV	4	MKRIGS TEST PANEL
LZ30		NE	1	GUARD
M025277-300-08	3045802-01	OH	1	FUEL PUMP
M031-01S021-046		NE	1	SKID SHOE RH AFT
M1035E-3A		SV	1	SPARE UNIT
M1045-F356-HMD3		SV	2	AUDIO CONTROL SYSTEM
M1045-I762-ESC3	990-3342-028	SV	2	AUDIO CONTROL SYSTEM
M1045I762GNK3		SV	4	CABIN AUDIO

M1050-8324-01	990-1254-051	SV	4	AUDIO SYSTEM
M1050B-7F		SV	1	AUDIO AMP
M1050-C447-01		SV	1	AUDIO SYSTEM
M1050-G448-01	990-1254-008	SV	1	AUDIO SYSTEM
M1050-L358-02	L358-02	SV	1	AUDIO AMP
M1050S-1G		SV	1	AUDIO AMP
M1052		SV	1	AUDIO SYSTEM
M105-23301-2		NE	2	WINDOW ASSY RH
M1060-01501-07		SV	1	AUDIO SYSTEM
M1080B		SV	1	AUDIO AMP
M1082B		SV	1	AUDIO AMP
M1082D		SV	2	AUDIO AMP
M12883/40-01		NS	1	SOCKET,RELAY
M12883/44-01		NS	1	SOCKET,RELAY
M12883/53-001		NS	1	CONNECTOR,RCPT,ELECTRICAL
M2050K	M2620	SV	1	AMPLIFIER
M24251/6-1		NE	3	SHIELD
M24251/6-2		NE	3	SHIELD
M24308/2-2F		NS	1	CONNECTOR,RCPT,ELECTRICAL
M24308/2-3F		NS	1	CONNECTOR,RCPT,ELECTRICAL
M24308/2-4F		NS	1	CONNECTOR,RCPT,ELECTRICAL
M24308/4-1F		NS	1	CONNECTOR
M24308-2-1F		NS	1	CONNECTOR
M2620BJ		SV	1	MOTOR
M3088-11		SV	2	PANEL
M33GMC09C2AA	M3901	SV	1	RADIO VHF FM GM300
M39012-20-0504	M3902	NE	100	CONNECTOR
M39029/29-12-12	M4630	NS	188	INSERT
M463080/M503540		SV	2	RACK
M6241		SV	1	ANTI-ICE VALVE
M655		OH	1	OAT GUAGE
M7950-11	990-1769-005	SV	1	PAGING AMP
M81714/2-AB1		NS	2	TERMINAL JUNCTION BLOCK
M81714/2-DB1		NS	9	TERMINAL JUNCTION BLOCK
M81714/67-02		NS	1	TERMINAL JUNCTION BLOCK
M83536-2-024M		NE	4	RELAY
M83723/82K1212N		NS	2	CONNECTOR
M83723/86R1212N	X9234-115	NS	10	CONNECTOR W PINS AND EXT TOOL
M83723/95R0803N		NS	1	CONNECTOR
M85049/49-2-12W		NS	2	CLAMP
M85049-52-1-20W		NS	1	STRAIN RELIEF
M85049-52-1-22N		NS	1	STRAIN RELIEF
M850-5V-G	1159SCAV409-2	SV	2	DIGITAL CLOCK
M-BK117-243021-4		NE	1	ASSY, CARGO DOOR WINDOW
MC235MH089		NE	3	INDICATOR
MC4741CP		NS	25	IC
MC700-4NVG		SV	5	MAGNETIC COMPASS
MC7014-1-00		SV	1	PRESSURE SWITCH LP
MC25-300		OH	1	STANDBY AIRSPEED INDICATOR
MD41-1308	MD41-13085V	AR	1	ANNUNCIATOR
MD41-1308		AR	1	TAWS ANNUNCIATION CTL
MD41-1448	MD41	AR	1	ANNUNCIATOR
MD41-1628	MD41-1628(SV)	SV	1	GPS ANNUNCIATION CTL UNIT
MD41-628	MD41	SV	1	ANNUNCIATOR
MFA370-1		NS	2	FILTER ELEMENT
MI-585002	AVI-202	SV	1	RMV/CONVERTER
MI-585031	AVN-220	SV	1	VHF NAV SYSTEM
MI-585067	AVN-204	OH	1	AUTO VOR CONVERTER
MI-585072-3	MI-58	SV	2	NAV ILS40CH MKR RX
MI-585074-7	AVC-110A	SV	1	VHF COMM
MI-585084	FP-900	SV	1	ANTENNA RADAR
MI585297-3		SV	1	DATA NAV PANEL
MI-585297-3		SV	1	DATA NAV III CONTROL PANEL
MI-585300-4		SV	1	RADAR RTI
MI-585302		SV	2	RADAR ANTENNA
MI-585396-4	DNC-1001	SV	1	DATA NAV
MI-585397-5	DNC-1002	SV	1	DATA NAV
MI-585398-2	DNCP-1001	SV	1	DATA NAV CONTROL
MI-585399-1		SV	1	DATA NAV
MI-585399-2		SV	1	DATA NAV
MIL-G-6036B	AW-17/8-27-E5	SV	1	GAGE - HIGH PRESSURE OXYGEN
MI10023	5961-01-176-5661	NE	1	TRANSISTOR
ML335	MP498	NS	10	LAMP
MP498-103	MP498	SV	1	YAW MAG-BRAKE
MP498-105	204-001-376-105	SV	1	YAW MAG-BRAKE
MPRD9639	MS166	SV	2	BARCO DISPLAY

MS16627-1125		NS	1	RINGS
MS17983-4	CB2125-28A	OH	1	COMPASS
MS17985C411	MS208	NS	10	PIN
MS1801		SV	1	MODULE
MS1803-3		SV	2	MICROTOUCH INTERFACE MODULE
MS1804		SV	1	MODULE
MS1805		SV	1	MODULE
MS1817		SV	1	MODULE
MS1826		SV	1	MODULE
MS1829-B		SV	1	MICROTOUCH INTERFACE MODULE
MS1833		SV	1	MODULE
MS1858		SV	1	MODULE
MS1863		SV	1	MODULE
MS2012		AR	1	MICROTOUCH INTERFACE MODULE
MS20825-8	MS210	NS	2	TEE FITTING
MS21048-3K	MS210	NS	36	NUTPLATE
MS21074-3K	MS220	NS	50	NUTPLATE
MS21075-3N		NE	100	NUTPLATE STEEL
MS21225-6		NE	3	NUT
MS22034-4	MS245	NS	1	JAW FITTING STUD
MS22073-10	7274-11-10	NS	1	CIRCUIT BREAKER
MS22073-15	7274-11-15	NS	1	CIRCUIT BREAKER
MS22073-2	7274-11-2	NS	3	CIRCUIT BREAKER
MS22073-3	7274-11-3	NS	7	CIRCUIT BREAKER
MS24183D1	24183D1	SV	1	RELAY SOLENOID
MS243906308C4		SV	1	HYDRAULIC MOTOR
MS24576-2	18-1701	OH	1	OIL PRESSURE INDICATOR
MS246938B52		NE	189	SCREW
MS24694C99		NE	39	SCREW
MS24694-SB4		NE	150	SCREW
MS25056-1B		NE	1	SLEEVE/ANTENNA WIRE
MS25056-1B	MS252	NS	1	SLEEVE/ANTENNA WIRE
MS25069-1495		NE	10	LAMP
MS2657-4-1	7274-70-1	NS	3	CIRCUIT BREAKER
MS27472T24B-2S	MS274	NS	1	CONNECTOR
MS27472T24B61P	MS277	NS	4	CONNECTOR
MS27473T14B18S		NE	2	CONNECTOR
MS27782-2F	MS280	NS	1	SWITCH
MS28041-2A	MS280	OH	1	TURN AND SLIP
MS28043-T2	273-77N112	OH	1	GAGE UNIT - ENGINE
MS28075-1	RCS-60-1L	OH	1	IND. RATE OF CLIMB
MS28773-03		NE	20	RETAINER PACKING
MS28774-138	MS310	NS	7	RETAINER
MS28774-138		NE	7	RETAINER
MS3101A10SL-4P		NS	11	CONNECTOR
MS3106A18-11S		NS	1	CONNECTOR
MS3106A24-11P		NS	1	CONNECTOR
MS3106E14S-2S	MS310	NS	1	CONNECTOR
MS3106E28-16P	MS310	NS	2	CONNECTOR
MS3106F24-A24S		NS	3	CONNECTOR
MS3108F24-58P	MS347	NS	2	CONNECTOR
MS3116F10-6S		NE	1	CONNECTOR
MS3126F-16-23P		NS	10	CONNECTOR
MS3416-8EN		NS	31	BACKSHELL
MS3470L12-10P		NS	1	CONN KIT
MS3470L20-39PY		NS	4	CONNECTOR
MS3470L24-61PY		NS	1	CONNECTOR
MS3470W20-415W	MS347	NS	1	CONNECTOR
MS3474W12-8P		NS	4	CONNECTOR
MS3476W20-39S		NS	5	CONNECTOR
MS35489-120	MS357	NS	8	GROMMET
MS35489-69		NE	25	GROMMET SYNTHETIC RUBBER
MS35769-20	MS361	NS	2	GASKET
MS3614-8EN	MS910	NS	36	BACKSHELL
MS9105-55	N000-	NS	2	PIN
MS9152B-2N2B6		NE	1	KNOB
MS9575-09		NE	5	BOLT
MT1-1079-102		SV	1	ATC MOUNTING TRAY
N001-0001		SV	1	CONTROL DISPLAY UNIT
N200-151		NE	1	EMERGENCY ENG CONTROL
N300-005		SV	2	AUDIO CONTROL PANEL
N300-006		NE	1	CABIN CREW AUDIO PANEL
N303-10167-53-A	5985-01-297-5162	NE	5	RADIO FREQ SWITCH
N335-023		NE	2	AUDIO CONTROL PANEL
N3844-20		SV	1	ARRA ATTENUATOR
N48-1-2		SV	2	ANTENNA

NAS135	NAS11	SV	1	AUDIO FREQ DECODER
NAS1149C0532B		NE	50	WASHER
NAS1330H08K161		NE	70	NUT PLAIN RVET BLIND
NAS1333A3C10D		NE	3	QUICK RELEASE PIN
NAS1376A08SD018		NE	1	DUCT
NAS1738M5-6		SV	10	R/VT
NAS1836-06-08		NE	1	INSERT
NAS1922-0400-1H		NE	6	CLAMPS
NAS557-8B	NAT35	NS	40	GROMMET
NAS561C4-9		NE	99	PIN SPRING
NAS6904D58		NE	5	BOLT
NAS77-4-012		NE	10	BUSHING
NAT352-001	NAT380-005	OH	2	AUDIO PANEL
NDN8595-03	704A47152004	OH	1	VERTICAL GYRO
NDN9768-03	NDN9768	SV	1	FLT PATH CTL COMPUTER
NT-308-000WR	NT308-000	SV	1	FM TRANSCENER
NT450	CH250-020	OH	1	FM TRANSCENER
NT450	CH250-ONE	OH	1	FM TRANSCENER
NY-6M0-3	NY-6M0-3	NE	1	FITTING
O33203	BC407/332	OH	1	AMETEK ROTRON INVERTER
O50084	1250435	OH	1	BLOWER
O50084	1250435	AR	1	BLOWER
OB1303-003		SV	1	DZUS CONT (HORIZONTAL NON-NVG)
OBS-85A		OH	1	OMNIBEARING SELECTOR
P057634	P1208	SV	1	PRINTED CIRCUIT
P058312	704A46610010	SV	1	PRINTED CIRCUIT Z200
P100-205A		NS	4	SCREW
P-10A		SV	1	INVERTER
P12064		NS	1	CONN KIT
P12248-002	AIRCELL	SV	1	AIRCELL HANDSET
P12339		SV	1	AIRCELL AXCESS II
P12347		SV	2	AIRCELL MODULE
P12861-001	P12861-003	NE	1	ASSY, TOP BASE STATION
P155-15A-E1A		SV	2	ADAS TRANSDUCER ASSY
P200100AFCAU	704A47134186	SV	3	BOX CONTROL
P3-03-0041-101		SV	1	SURVIVAL RESCUE BEACON
P356-5000		SV	1	ADAS TRANSDUCER ASSY
P600-14A	P6021	NS	1	CURRENT PROBE
P8304-1		SV	1	INVERTER
PAI700		SV	1	COMPASS, BACKUP
PANL-2016-05-01		NE	2	SKYQUEST VCR REMOTE CONT
PC06E8-4S-SR		NS	11	CONNECTOR PLUG, ELECTRICAL
PC-125-123C		OH	2	STATIC INVERTER
PC12A		NE	1	CONVERTER 28/12 VDC
PC-12A		SV	1	STATIC INVERTER
PC-12A	PC-12	SV	1	CONVERTER
PC-12VR		OH	1	DC TO DC CONVERTER
PC18-3	PC-16-3	SV	1	STATIC INVERTER
PC17A	PC17A	SV	3	STATIC INVERTER
PC-251-123K	76550-23800-102	SV	1	STATIC INVERTER
PC820-101A		SV	2	SIGNAL CONDITIONING UNIT
PC900-1A0600PH1		SV	1	FUEL FLOW INDICATOR
PC900-1A0600PH1-1		SV	1	FUEL FLOW INDICATOR
PC-900-ECAP-0001		SV	1	INDICATOR CONDITIONER UNIT
PCC-15V	PF10-	NS	1	CURTAIN RACK
PF10-167		SV	1	ANTENNA
PH502-BKC		NE	1	PITOT TUBE
P058312	704A46610010	SV	1	PRINTED CIRCUIT
PR-10		SV	1	CURRENT PROBE AMPLIFIER
PS1230		AR	1	BATTERY PACK
PS18125-1		SV	1	POWER SUPPLY, USB
PS7016006-202	PT06A	NS	2	O RING
PT00SE14-19S		NS	2	CONNECTOR, RCPT, ELECTRICAL
PT06A84SSR	PW206	NS	1	CONNECTOR
PT06CEB-2P(SR)		NS	16	CONNECTOR
PT06SE2-55PX		NS	1	CONNECTOR
PW-28D-13FJ-4	222-375-065-101	SV	1	POWER SUPPLY
PW-28S-40CC-2		SV	11	POWER SUPPLY
PW727MVB07		OH	1	EGI INDICATOR
PVL850487-1	R1467	OH	3	V/V ANTI-ICE/EAPS
R-1123A/ARC73		SV	1	RECEIVER, RADIO
R1467M20	214-001-347-101	OH	1	ACTUATOR
R-252220-00		AR	1	CAMERA UNIT, DOWN ZOOM
R460M15-11	204-001-376-3	AR	1	MAG BRAKE
R460M44-105	204-001-376-105	OH	2	MAGNETIC BRAKE HELICOPTER
R460M44-107	204-001-376-107	OH	2	MAGNETIC BRAKE HELICOPTER

R50U-15-N		NS	1	CONVERTER
RBE12-03	LMP027	SV	1	RPM WARNING SYS
RC-30-V-10-1	100-384054-1	SV	1	IVSI 0-3000 FPM
RC-30-VIL	212-070-239-001	OH	3	VSI
RC-60-10DE2	RC-60-10	OH	1	IVSI
RCA15B3		OH	1	INDICATOR GYRO DIR
RCA15BL1		OH	1	INDICATOR, DIR GYRO
RCA26BK-2	102-0054-03	OH	2	INDICATOR, GYRO ATT
RCA28WZD2S		OH	1	INDICATOR
RCAB2A-2		OH	1	TURN COORDINATOR
RCD-021-402		SV	1	AICD PLAYER
RCLD14-5-B2/28		SV	1	DISPLAY
RCLD14-7/28		SV	1	DISPLAY
RCM-10-3		OH	1	RATE OF CLIMB INDICATOR
RCM60ACL		OH	1	RATE OF CLIMB INDICATOR
RD25FV/L0		NS	1	CONNECTOR
RD29M00000		NS	3	CONNECTOR
RD29M10JV30		NS	1	29 PIN M DSUB KIT
RD50M10JV/L0		NS	1	CONNECTOR
RD8180K	4440-00-780-1039	OH	1	DEHYDRATOR UNIT
RD9F10JV/L0		NS	2	CONN KIT
RD9M10JV30		NS	1	CONN KIT
RD9S10GV/L0		NE	1	CONNECTOR
RD-AV7052-1		SV	7	LCD MONITOR
RDR1400SYSTEM	RDR1400	SV	1	WEATHER RADAR SYSTEM
RECT1-812-1A998000		SV	1	POTENTIOMETER
RG-15980-E		OH	1	FUEL PUMP
RG40		SV	1	DC TO DC CONVERTER
RGD-9-D-PS-R		SV	5	SHARP/ROSEN DISPLAY
RGD-9-R	6M-40U	NS	5	SHARP/ROSEN DISPLAY
RA01-01-00		NE	1	RETRACTABLE INTERFACE ADAPTER SET
RISR-28-12-6		SV	6	PWR CONV
RL5026		NE	18	READING LIGHT
RLB-35	2744	SV	1	ACR ELT
RLCD14-5-B2/28		SV	1	ROSEN DISPLAY
RLCD14-7/28	RLCD1	SV	1	VIDEO DISPLAY
RM300CA-9W		SV	1	DIODE ASSY
RN-222AE		SV	1	NAV RCVR
RNVAP-2LL		NS	1	ROSEN CONNECTOR
RNVAP-SULL-L-WO/28		SV	1	VIDEO MONITOR
RS4220	70307-23908-101	OH	1	PUMP DUMP FUEL SYSTEM
RS08-001		AR	4	AUDIO BOX
RS08-500		SV	1	AUDIO BOX
RS16-001		SV	1	RELAY UNIT
RS8031	RSLM-	SV	1	VOLTAGE CONVERTER
RSLM-55B/28		SV	2	MONITOR BASE
RSLM-55LA-L/28		SV	3	MONITOR DISPLAY
RT100M1E		SV	2	MEM. CARD READ/WRITE U-
RT100-PC-M1		AR	1	CARD READER
RT-1115C/APN209V	HG7209AB01	SV	2	RECEIVER TRANSMITTER
RT651N-A	SRT651	NE	1	V/UHF TRANSCIVER
RT8	XANTECH	SV	1	ADDRESSABLE INFRARED ROUTER
S15-005	706A31213061	SV	1	ECLAIRAGE PANNEAU CARB 3Q
S1609.1.118A		NE	3	LOAD HOOK
S1609.6		OH	1	SLING CARGO HOOK
S1820513-11		AR	1	ELT SWITCH
S1840501-01		AR	1	ELT
S212-850		SV	1	AC CURRENT LEVEL SENSOR
S-3008EC-6		OH	1	COMPRESSOR ASSY
S4000-4		SV	1	PASSENGER BRIEFING SYSTEM
S4-3402250		NE	1	MAGNET VENTIL
S6130-63049-000	S65-5	OH	1	DEFUEL/REFUEL VALVE
S65-5366-10L		SV	1	L-BAND ANTENNA DME/XPDR
S65-5366-850L		SV	1	ANTENNA RADIO PHONE
S65-8282-25		SV	1	ANTENNA
S658-17-30	S67-1	OH	1	AIRSPD MAX ALLOW/IND
S67-1575-20		SV	4	ACTIVE GPS ANTENNA
S67-1575-232		SV	10	ACTIVE GPS ANTENNA
S67-1575-39		SV	8	S
S67-2002-14		AR	1	ANTENNA
S72-1750-32L		AR	1	ANTENNA
SA106509	SA106	SV	1	TAPE CARTRIDGE ASSY
SA106572	SA-40	SV	1	HARVARD BI-PHASE CARD
SA40-1	8000T-812	SV	1	AIRSPD IND
SA-40-1	8000T-812	OH	1	AIRSPD 0-200 MPH
SA-40-1RB	8000T	OH	1	AIRSPD 0-200 MPH

SAT-550		NS	1	GLOBALSTAR SATELLITE PHONE
SB093-1		NE	1	KIT F. AIR CONDIT.
SB-117-90-119-3.1		NE	1	RETROF CIP DET TAILR INTERM GEARBOX
SB120		SV	1	POWER STATIC INVERTER
SB-135-33-004-2C1		NE	1	LED POS LIGHT
SB-135-34-034-2C1		NE	1	RET STBY HORIZON
SB-135-52-006-2C1		NE	1	JETTISON COCPIT DOOR
SB-135-53A-018-2C1		NE	1	CHANGE OF DRAIN HOSE
SB-135-85-030-2C1		NE	1	CONVERSION HELLAS
SC41-37002-01	SC41-	SV	1	PANEL
SC41-471001-01		SV	2	TELCOM TRANSFER UNIT
SC41-471002-01	471002-01	SV	1	SATCOM INTERFACE COMPUTER
SC41-472001-01		SV	1	HANDSET TRANS UNIT
SC44104048-537	59734/SC44104048-537	SV	1	PANEL
SC44104058-51		SV	1	PANEL
SC44453002-27		SV	1	PANEL
SC44468035-37		NS	1	EXT LTS/MASTER ETC PANEL
SD15F10I/0		NS	1	CONNECTOR
SE13826	704A42713044	SV	2	HEATING MAT POWER UNIT
SE13851	704A42713045	SV	1	MPA POWER UNIT
SE-3130-D-73-71-905		OH	4	SERVO COMMANDE TYPE 4300
SEL0C19EL		OH	1	T5 INDICATOR
SEL-OC19AM	76450-01076-106	OH	1	TURB TEMP IND
SEL-OC19AP	76450-01076-107	OH	1	TURB TEMP IND
SEL-OC19EL		OH	1	T-5 INDIC
SEL-OC19EL1	SEL-OC19EL1	OH	2	T5 INDICATOR
SEL-OC29CB	76450-00903-101	OH	2	TRIPLE TACH
SEL-OC29F	76450-01076-101	OH	2	GAS GEN TACH IND
SETL-OC329A	76450-01076-103	OH	2	TRIPLE INDICATOR, TACH
SETL-OC329G	76450-00901-104	OH	2	TRIPLE TACH
SG1525AJ		NE	10	MICROCIRCUIT
SK106L106-581.4		NE	2	ROD TUBE
SK355-078-01	SKCP2	SV	2	WHEEL ASSY
SKCP2456-3	SL204	SV	1	DRIVE SHAFT
SKCP2456-3		NE	1	DRIVE SHAFT
SKCP2456-3		SV	1	DRIVE SHAFT
SL2049-1	SLZ76	NS	4	NUT
SLZ7600		OH	1	TRANSMITTER, STAT-429
SLZ9125A	6610-903-0714	OH	1	INDICATOR, VERTICAL VELOCITY
SLZ9155	D6H	SV	1	IVSI
SLZ9157	D6HL	OH	1	IVSI
SLZ9157-3	D6HL	SV	1	IVSI
SLZ9644		OH	1	TRANSMITTER, ANGLE OF ATTACK
SM15CXD20		SV	1	RELAY 60 AMP 1PDT
SM20ACD200A21		SV	2	CONTACTOR
SM20ACD300A21		SV	2	CONTACTOR
SM20CCD200B21		SV	2	CONTACTOR
SM600B450A1		NS	1	CIRCUIT BREAKER
SM600B475N1		NE	1	CIRCUIT BREAKER
SM-D-374989	5821-00-089-9207	NE	2	A1500 RF TUNER
SN3500-010N	SN3500	SV	1	EHSI NVS
SO-1055-8690		NS	1	RELAY SOCKET
SOC108		OH	1	HP FUEL COCK
SP401		SV	1	TELPAR PRINTER
SP67-9		SV	1	SMARTPACK
SPC-10(H)		NE	1	INVERTER
SPC-308	SPC-6	SV	1	INVERTER
SPC-60A	SPH-1	SV	1	INVERTER
SPH-1006	SPH-1	SV	1	STATIC FREQ CHANGER
SPH-1606B-3	SPS-1	OH	1	STATIC FREQ CHANGER
SPR87378		NE	1	JACK 7T MODIFIED
SPR87378		NE	2	JACK 7T MODIFIED
SPS-1-1-331	SPS-1	NS	1	SWITCH
SPS-1607	SPS-1	OH	1	STATIC INVERTER
SPS-306B-3		SV	1	STATIC INVERTER
SRM6.TA		NS	2	BEARING
SS9013-2409	SSP23	NS	1	IDENT PLATE
SSP23-604B		NS	1	LABEL, MAR, VHF
SSP23-622-3		NS	1	INTERCOMM HARNESS RADIO
SSPD-113-39		NS	1	ANTENNA POWER DIVIDER
ST10107		NE	2	MOTOR-TACHOMETER GENERATOR
ST3400H-001		FN	10	TAWS-A & RMI
SX-16		OH	1	SEARCH LIGHT
SX7EJ3		SV	1	BATTERY CONTACTOR
SVLCS2086-2	230-360-701-101	OH	1	ACTUATOR ELECTROMECHANICAL
SVLCS-9548-1		SV	2	LINEAR ACTUATOR



S265-001-1		SV	1	MOTOR COMPRESSOR COND UNIT
T1890A6C		AR	1	METAL PART
T2067		SV	1	FAN CONDENSOR
TA3F-94V0		NS	1	CONNECTOR
TBM150365	TE-17	SV	1	VIDEO POWER SUPPLY
TDH7050-2000		NE	2	RELAY
TE450		AR	1	LS AMPLIFIER
TE450BN846		AR	1	TRANSISTOR
TH250-2NN	TLNB-	SV	1	FM CONTROL
TJG120403		NS	1	TERMINAL JUNCTION
TLH451115		NE	1	SLIDING PIECE
TLNB-10		NE	1	TRK DUAL LNB
TM105-2		SV	1	TEMP. SWITCH
TM105-2		NE	1	TEMP SWITCH
TM-105PSN	TM410	SV	1	TV
TM410-39		SV	1	TRIPLE OIL TEMP. INDICATOR
TM410-40		SV	1	TRIPLE OIL TEMP INDICATOR
TM410-53		SV	1	TRIPLE OIL TEMP. INDICATOR
TM410-54		OH	1	TRIPLE OIL TEMP. INDICATOR
TM427-39		SV	3	EXHAUST TEMP. INDICATOR
TM427-40		SV	3	TEMP INDICATOR
TM427-45		NE	2	TEMPERATURE INDICATOR
TM427-45		SV	1	TEMPERATURE INDICATOR
TM477-020-020		SV	1	DUAL TOT INDICATOR
TNC3844-20	N3844-20	SV	1	ADAPTER
TRAWID9-25		NE	1	BREAK OUT BOX
TRDU24A2	TSG42	SV	1	TIME DELAY RELAY
TS-642/U	AN/UPM-56	SV	2	TEST SET, RADAR
TS-8077ARM-10		SV	1	TEST SET, RADIO
TSG420-103	TWN-1	SV	1	STATIC INVERTER
TWN-12	UC-28	NS	2	TWIN PILLOW BLOCK
TWN-12-ADJ		NE	2	TWIN PILLOW BLOCK
TYE3007-3-18		NE	1	INSERT
TYP8124K		SV	1	AVIONICS FAN
UC-28-14	UCB16	SV	4	DC TO DC CONVERTER
UCB16530-02	UCB16530	SV	1	CONTROL UNIT
UT12-000		NE	1	tone ENCODER
V084C-CA		AR	5	MONITOR
V5000-172	V094-	SV	2	SOLENOID VALVE
VE-328		NE	1	BELLOWS
VE3A010-00-001-001	V63A010	SV	2	MULTI-FUNCTION DISPLAY
V694-6-1	V694-	SV	1	VOICE GENERATOR
V694-7-5	V8500	SV	1	VOICE GENERATOR
V694-7-7		SV	1	VOICE GENERATOR
VA 3660		NE	1	AXIAL FAN
VA 3660		SV	3	AXIAL FAN
VA1A300		SV	1	INDICATOR, DC VOLT AMP METER
VA400		SV	1	VIDEO SWITCH
VA-400-1	VCT15	SV	1	AIRSHOW/VIDEO AMP
VCL16501-02		SV	1	TRIM ACTUATOR
VCP-014-01-2		SV	1	VIDEO PLAYER
VCP-015-01-1	30500056	SV	1	VIDEO PLAYER
VCT1518C	9560156790	AR	2	BLOWER
VCT1518C	9560156790	OH	1	BLOWER
VFS10-90-1		SV	2	ANTENNA, VHF
VFS10-90-2		AR	7	ANTENNA, VHF
VG204AB	76600-02113-103	OH	1	REMOTE GYRO
VG204V	76600-02113-102	OH	1	REMOTE GYRO
VLT12-CV	VM-20	SV	1	DC TO DC CONVERTER
VM-202RRT	VM202	SV	1	PHASE ANGLE VOLTMETER
VP4805		SV	1	RF MOUSE
VR2011	VR300	SV	1	VOLTAGE REGULATOR
VR2011		SV	1	VOLTAGE REGULATOR
VR300-14-50		NS	1	VOLTAGE REGULATOR
VR-L11-0023.100		NE	1	COLD BONDING TOOL SET EC135
VT044		NE	20	ROD TUBE
VT426-39		NE	2	FUEL INDICATOR
VT426-40		SV	1	FUEL PRESSURE INDICATOR
VT426-41		SV	1	FUEL QTY IND (US GALS)
VT443-1		SV	1	FUEL QTY IND (US GALS)
VTR11-11		NE	1	REMAINING FUEL INDICATOR
VXAP-135		NE	1	VXP APPLICATION KIT T&B EC135
VXAP-135DS		NE	1	VXP APPLICATION KIT EC135 DRI
W0314		NE	2	LAP BELT
W21ADCQX-5	W33-7	NS	1	RELAY
W21ADCQX-5		NS	1	RELAY

W281M20C1010	L281M20C1010	NE	1	SELF SEALING SUPPLY TANK
W33-7510-10	98429-W33-7510-10	OH	1	CLOCK
W33-7510-10A		OH	1	CLOCK
W33-7510-10ET20	WL/51	OH	1	CLOCK
W671M50C1001		NE	1	SWITCH UNIT COLLECTIVE
WA1967		NE	1	SAFETY DISK
WA2014		NE	1	STELLMOTOR
WA4337		NE	1	GEAR ASSY
WA4339		NE	1	GEAR ASSY
WA4346		NE	1	RECORDING RING
WAP-01-001		SV	1	WIRELESS ACCESS POINT
WB4365		NE	1	PISTON
WB4366		NE	1	DRIVE CAM DISK
WE-3821-4		SV	1	HOIST ASSEMBLY
WEMACP93510-10		SV	10	READING LIGHT
WGE-0090-00		SV	1	DIPLXER
WL519CUF1	WL/519CLF1	SV	1	ALTITUDE ALERTING UNIT
X00042-413		SV	1	STALL PROTECTION COMPUTER
X98545		SV	1	EMERGENCY VHF TRON AIR
XD4N		NS	2	LEACH RELAY
XE-90MKII		SV	2	STEREO GRAPHIC EQUALIZER
XL1327		SV	1	ANTENNA PLATE
XMC100-01		NS	1	XM RADIO CONTROLLER
XMD076-01	RS232	SV	1	XM DATA RCVR
XMR100-01		NS	1	XM RCVR UNIT
XW21160-M1		NE	3	MOTOR
XW23513-1	222-325-001-25	SV	1	MOTOR CONVERTER
Y1242-31-1		AR	1	MOTOR
Y-E4N-024		NS	1	LEACH RELAY
ZC-83N		SV	1	RELAY
ZE3-276		SV	3	GUIDE ASSY
ZR8263-00		NE	3	PRESS TRANSDUCER



























